

# ARC-10W37

10.1" WXGA LED with P-cap Touch Fanless Rugged Touch  
Panel PC with IET Expansion

## Quick Reference Guide

1<sup>st</sup> Ed – 21 May 2024

### Copyright Notice

Copyright © 2024 Avalue Technology Inc., ALL RIGHTS RESERVED.

## Document Amendment History

Revision	Date	By	Comment
1 <sup>st</sup>	May 2024	Avalue	Initial Release

## Declaration of Conformity



This device complies with part 15 fcc rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class "a" digital device, pursuant to part 15 of the fcc rules.

These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### CE statement

The product(s) described in this manual complies with all application European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

## Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

## Copyright Notice

© 2024 by Avalue Technology Inc. All rights are reserved. No parts of this manual may be copied, modified, or reproduced in any form or by any means for commercial use without the prior written permission of Avalue Technology Inc. All information and specification provided in this manual are for reference only and remain subject to change without prior notice.

## Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows is registered trademark of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

## Disclaimer

This manual is intended to be used as a practical and informative guide only and is subject to change without notice. It does not represent a commitment on the part of Avalue. This

product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

## **A Message to the Customer**

### ***Avalue Customer Services***

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

### ***Technical Support and Assistance***

1. Visit the Avalue website at <https://www.avalu.com.tw/> where you can find the latest information about the product.
2. Contact your distributor or our technical support team or sales representative for technical support if you need additional assistance. Please have following information ready before you call:
  - Product name and serial number
  - Description of your peripheral attachments
  - Description of your software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wording of any error messages

To receive the latest version of the user's manual; please visit our Web site at:

[www.avalu.com](http://www.avalu.com)

## ***Product Warranty (Returns & Warranties policy)***

### **1. Purpose**

Avalue establishes the following maintenance specifications and operation procedures for providing the best quality of service and shortened repair time to our customers.

### **2. Warranty**

#### **2.1 Warranty Period**

Avalue endeavors to offer customers the most comprehensive post-sales services and protection; besides offering a 2-year warranty for standard Avalue products, an extended warranty service can also be provided based on additional request from the customer. Within the warranty period, customers are entitled to receive comprehensive and prompt repair and warranty.

Standard products manufactured by Avalue are offered a 2-year warranty, from the date of delivery from Avalue. For ODM/OEM products manufactured by Avalue or PCBA with conformal coating, will follow up the define warranty of the agreement, otherwise will be offered 1-year warranty for ODM/OEM products but non-warranty for PCBA with conformal coating. For outsourcing parts kit by Avalue (ex: Motherboard, LCD touch panel, CPU, RAM, HDD) are offered a 6-month warranty, and Mobile/Tablet PC battery are offered a warranty of the half year, from the date of delivery by Avalue. Products before the mass production stage, i.e. engineering samples are not applied in this warranty or service policy. For extended warranty and cross-territory services, product defects resulting from design, production process or material are covered by the pre-set warranty period after the date of delivery from Avalue. For non-Avalue products, the product warranty and repair time shall be based on the service standards provided by the original manufacturer; in principle Avalue will provide these products a warranty service for no more than one year.

#### **2.2 Maintenance services within the warranty period**

In the case of Avalue product DOA (Defect-on-Arrival) when the customer finds any defect within 1 month after the delivery, Avalue will replace it with a new product in a soonest way. Except for custom products, once the customer is approved of a Cross-Shipment Agreement, which allows for delivery a new product to the customer before receiving the defective one, Avalue will immediately proceed with new product replacement for the said DOA case. On validation of the confirmed defect, Avalue is entitled to reserve the right whether to provide a new product for replacement. For the returned defective new product, it is necessary to verify that there shall be no bruise, alteration, scratch or marking to the appearance, and that none of the delivered accessories missing; otherwise, the customer will be requested to pay a processing fee. On the other hand, if the new product defect is resulting from incorrect configuration or erroneous use by the user instead of any problem of the hardware itself, the customer will also be requested to pay for relevant handling fees.

## **ARC-10W37**

As for other conditions, Avalue will handle defects by way of repair. The customer will be requested to send the defective product to an Avalue authorized service center, and Avalue will return the repaired product back to the customer as soon as possible.

### **2.3 Ruling of an out-of-warranty defect**

The following situations are not included in the warranty:

- The warranty period has expired.
- Product has been altered or its label of the serial number has been torn off.
- Product functionality issues resulting from improper use by the user, unauthorized dismantle or alteration, unfit operation environment, improper maintenance, accident or other causes. Avalue reserves the right for the ruling of the aforementioned situations.
- Product damage resulting from lightning, flood, earthquake or other calamities.
- The warranty rules of non-Avalue products and accessories shall be in accordance with standards set up by the original manufacturer. These products and accessories include RAM, HDD, FDD, CD-ROM, CPU, FAN, etc.
- Product upgrade request or test request submitted by the customer after expiration of the warranty.
- PCBA with conformal coating.
- Avalue semi-product and outsourced products without Avalue serial number.
- Products before the mass production stage, i.e. engineering samples.

## **3. Procedure for sending for repair**

### **3.1 Attain a RMA number**

A customer's rejected product returned for repair shall have a RMA (Return Merchandise Authorization) number. Without a RMA number, Avalue will not provide any repair service for the rejected product, and the product will be returned to the customer at customer's cost. Avalue will not issue any notice for the return of the product.

Each returned product for repair shall have a RMA number, which is simply the authorization of the return for repair; it is not a guarantee that the returned goods can be repaired or replaced. For applying for a RMA number, the customer may enter the eRMA webpage of Avalue <https://www.avalue.com/en/member> and log-in with an account number and a password authorized by Avalue. The system will then automatically issue a RMA number.

When applying for the RMA number, it is essential to fill in basic information of the customer and the product, together with detailed description of the problem encountered. If possible, avoid using ambiguous words such as "does not work" or "problematic". Without a substantial description of the problem, it is hard to start the repair and will cause prolonged repair time. Lacking detailed statement of fault steps also makes the problem hard to be identified, sometimes resulting in second-time repairs.

In case the customer can't define the cause of problem, please contact Avalue application engineers. Sometimes when the problem can be resolved even before the customer sends back the product.

On the other hand, if the customer only returns the key parts to Avalue for repair, it is necessary that the serial number of the entire unit is given in the "Problem Description" field, so that warranty period can be ruled accordingly; or Avalue will handle the case as an Out-of-warranty case.

### 3.2 Return of faulty product for repair

It is recommended that the customer not to return the accessories (manual, connection cables, etc.) with the products for repair, devices such as CPU, DRAM, CF memory card, etc., shall also be removed from the faulty goods before return for repair. If these devices are relevant to described repair problems and necessary to be returned with the goods; please clearly indicate the items included in the eRMA application form. Avalue shall not be responsible for any item that is not itemized. Moreover, make sure the problem(s) are detailed in the "Problem Description" field.

In the list of delivery, the customer may fill-in a value which is lower than the actual value, to prevent customs levying a higher tax over the excessive value of the return goods. The customer shall be held responsible for extra fees caused by this. We strongly recommend that "Invoice for customs purpose only with no commercial value" be indicated on the delivery note. Also for the purpose of expedited handling, please printout the RMA number and put it in the carton, also indicate the number outside of the carton, with the recipient addressing to Avalue RMA Department.

When returning the defective product, please use an anti-static bag or ESD material to pack it properly. In case of improper packing resulting in damages in the transportation process, Avalue reserves the right to reject the un-repaired faulty good at the customer's costs. Furthermore, it is suggested that the faulty goods shall be sent via a door-to-door courier service. The customer shall be held responsible for any customs clearance fee or extra expenses if Air-Cargo is used for the delivery.

In case of a DOA situation of a new product, Avalue will be responsible for the product and the freight. If the faulty goods are within the warranty period, the sender will take responsibility for the freight. For an out-of-warranty case, the customer shall be responsible for the freight of both trips.

### 3.3 Maintenance Charge

Avalue will charge a moderate repair fee for the following conditions:

- The warranty period has expired.
- Product has been altered or its label of the serial number has been torn off.
- Product functionality issues resulting from improper use by the user, unauthorized dismantle or alteration, unfit operation environment, improper maintenance, accident

## ARC-10W37

or other causes. Avalue reserves the right for the ruling of the aforementioned situations.

- Product damage resulting from lightning, flood, earthquake or other calamities.
- The warranty rules for non-Avalue products and accessories shall be in accordance with standards set up by the original supplier. These products and accessories include RAM, HDD, FDD, CD-ROM, CPU, FAN, etc.
- Product upgrade request or test request submitted by the customer after expiry of the warranty.
- PCBA with conformal coating.
- Avalue semi-product and outsourced products without Avalue serial number
- Products before the mass production stage, i.e. engineering samples.
- In case the products received are examined as NPF (No Problem Found) within the warranty period, the customer shall be responsible for the freight of both trips.
- Please contact your local distributor to examine in advance to prevent unnecessary freight cost.

For system failure of out-of-warranty products, Avalue will provide a quotation prior to repair service. When the customer applies for the cost, please refer to the Quotation number. In case the customer does not return the DOA product that has already been replaced by a new one, or the customer does not sign back the quotation of the out-of-warranty maintenance, Avalue reserves the right of whether or not to provide the repair service. In case the customer does not reply in 3 months, Avalue shall directly scrap or return the product back to customer at customer's cost without further notice to the customer.

### **3.4 Maintenance service of phased-out products**

For servicing phased-out products, Avalue provides an extended period, starting the date of phase-out, as a guaranteed maintenance period of such products, for continuance of the maintenance service to meet customer's requirements. In case of unexpected factors causing Avalue to be unable to repair/replace a warranted but phased-out product, Avalue will, depending on the availability, upgrade the product (free of charge with continued warranty period as of the original product), or, give partial refund (based on the length of the remaining warranty period) to solve this kind of problem.

### **3.5 Maintenance Report**

On completion of repair of a defective product, a Maintenance Report indicating the maintenance result and part(s) replaced (if any) will be sent to the customer together with the product. If the customer demands an additional maintenance analysis report, a service fee of various level will be charged depending on the warranty status. In case the analysis result shows that the defect attributes to Avalue's faulty design or process, the analysis fee will be exempted.

### 4. Service Products

Avalue provides service products to manage with different customer needs. Should you have any need, please consult to Avalue Sales Department.

#### **Defect Analysis Report (DAR)**

Avalue provides DAR (Defect Analysis Report) services aiming to elevating customer satisfaction. A DAR includes defect cause identification/verification/suggestion and improvement precautions, with instructions on correct usage for the avoidance of any reoccurrence.

#### **Upgrade Service**

Avalue is capable to provide system upgrade service for customization requirements. This upgrade service is applicable for main parts, such as CPU, memory, HDD, SSD, storage devices; also replacements motherboards of systems. Please contact Avalue sales for details to evaluate the possibility of system upgrade service and obtain information of lead time and price.

## Safety Instructions

### Safety Precautions

Before installing and using this device, please note the following precautions.

1. Read these safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Disconnected this equipment from any AC outlet before cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
8. Use a power cord that has been approved for using with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to

## **ARC-10W37**

avoid damage by transient overvoltage.

12. Never pour any liquid into an opening. This may cause fire or electrical shock.


13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel. If one of the following situations arises, get the equipment checked by service personnel:

- The power cord or plug is damaged.
- Liquid has penetrated into the equipment.
- The equipment has been exposed to moisture.
- The equipment does not work well, or you cannot get it work according to the user's manual.
- The equipment has been dropped and damaged.
- The equipment has obvious signs of breakage.

14. **CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

15. Equipment intended only for use in a **RESTRICTED ACCESS AREA**.

## Explanation of Graphical Symbols

	Warning	A WARNING statement provides important information about a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Caution	A CAUTION statement provides important information about a potentially hazardous situation which, if not avoided, may result in minor or moderate injury to the user or patient or in damage to the equipment or other property.
	Note	A NOTE provides additional information intended to avoid inconveniences during operation.
		Direct current.
		Alternating current
		Stand-by, Power on
		FCC Certification
		CE Certification
		Follow the national requirements for disposal of equipment.
		Stacking layer limit
		This side up

ARC-10W37

		Fragile Packaging
		Beware of water damage, moisture-proof
		Carton recyclable
		Handle with care
		Follow operating instructions of consult instructions for use.

## Disposing of your old product

### **WARNING:**

There is danger of explosion if the battery is mishandled or incorrectly replaced. Replace only with the same type of battery. Do not disassemble it or attempt to recharge it outside the system. Do not crush, puncture, dispose of in fire, short the external contacts, or expose to water or other liquids. Dispose of the battery in accordance with local regulations and instructions from your service provider.

### **CAUTION:**

- Lithium Battery Caution: Danger of explosion if battery is incorrectly replaced. Replace only with same or equivalent type. Dispose batteries according to manufacturer's instructions.
- Disposal of a BATTERY into fire or a hot oven, or mechanically crushing or cutting of a BATTERY, that can result in an EXPLOSION
- Leaving a BATTERY in an extremely high temperature surrounding environment that can result in an EXPLOSION or the leakage of flammable liquid or gas.
- A BATTERY subjected to extremely low air pressure that may result in an EXPLOSION or the leakage of flammable liquid or gas.

### **Mise en garde!**

AVERTISSEMENT : Il existe un risque d'explosion si la batterie est mal manipulée ou remplacée de manière incorrecte. Remplacez uniquement par le même type de batterie. Ne le démontez pas et ne tentez pas de le recharger en dehors du système. Ne pas écraser, percer, jeter au feu, court-circuiter les contacts externes ou exposer à l'eau ou à d'autres liquides. Jetez la batterie conformément aux réglementations locales et aux instructions de votre fournisseur de services.

### **MISE EN GARDE:**

- Pile au lithium Attention : Danger d'explosion si la pile n'est pas remplacée correctement. Remplacer uniquement par un type identique ou équivalent. Jetez les piles conformément aux instructions du fabricant.
- L'élimination d'une BATTERIE dans le feu ou dans un four chaud, ou l'écrasement ou le découpage mécanique d'une BATTERIE, pouvant entraîner une EXPLOSION
- Laisser une BATTERIE dans un environnement à température extrêmement élevée pouvant entraîner une EXPLOSION ou une fuite de liquide ou de gaz inflammable.
- UNE BATTERIE soumise à une pression d'air extrêmement basse pouvant entraîner une EXPLOSION ou une fuite de liquide ou de gaz inflammable.

# Content

<b>1.</b>	<b>Getting Started .....</b>	<b>18</b>
1.1	Safety Precautions .....	18
1.2	Packing List.....	18
1.3	System Specifications .....	20
1.4	System Overview .....	25
1.4.1	I/O View .....	25
1.5	System Dimensions .....	26
<b>2.</b>	<b>Hardware Configuration .....</b>	<b>27</b>
2.1	ARC-10W37 connector mapping.....	28
2.1.1	Serial port 1 connector (COM1).....	28
2.1.2	Serial port 2 connector (COM2).....	29
2.2	Powering On the System .....	30
2.3	ARC-ADLN Overview.....	31
2.4	ARC-ADLN Jumper and Connector List.....	32
2.5	ARC-ADLN Jumpers & Connectors settings .....	34
2.5.1	Clear CMOS (JRTC1).....	34
2.5.2	Serial port 1/2 pin9 signal select (JRI1/JRI2) .....	34
2.5.3	Serial port 1 in RS-232/422/485 mode (JCOM_SEL1).....	35
2.5.4	LVDS Back Light power selection (JSBKL1) .....	35
2.5.5	AT/ATX Input power select (JSATX1) .....	36
2.5.6	M.2 KEY power select (JP1).....	36
2.5.7	LCD Inverter connector (JBKL1) .....	37
2.5.8	Firmware Update connector (JPD1).....	37
2.5.9	Touch connector (JTP1) co-lay USB2.0 header (JUSB1) .....	38
2.5.10	On-board header for USB2.0 (JUSB2).....	38
2.5.11	LVDS connector (LVDS1).....	39
2.5.12	AMPLIFIER_R (JSPKR1) .....	40
2.5.13	AMPLIFIER_L (JSPKL1) .....	40
2.5.14	SPI connector (JSPI1) .....	41
2.5.15	EC Debug connector (JEC1) .....	41
2.5.16	B2B connector (JB2B1) .....	42
2.5.17	SATA Power connector (SATAPW1).....	43
2.5.18	Front Panel connector (JFP1) .....	43
2.5.19	Battery connector (BT1) .....	44

2.6 ARC-BYT DB-A/B/C/D/E/F/G/H/K Overviews ..... 45

    2.6.1 ARC-BYT DB-A ..... 45

    2.6.2 ARC-BYT DB-B ..... 45

    2.6.3 ARC-BYT DB-C ..... 45

    2.6.4 ARC-BYT DB-D ..... 46

    2.6.5 ARC-BYT DB-E ..... 46

    2.6.6 ARC-BYT DB-F ..... 46

    2.6.7 ARC-BYT DB-G ..... 47

    2.6.8 ARC-BYT DB-H ..... 47

    2.6.9 ARC-BYT DB-K ..... 47

2.7 ARC-BYT DB-A/B/C/D/E/F/G/H/K Connector list ..... 48

    2.7.1 ARC-BYT DB-A ..... 48

    2.7.2 ARC-BYT DB-B ..... 48

    2.7.3 ARC-BYT DB-C ..... 48

    2.7.4 ARC-BYT DB-D ..... 48

    2.7.5 ARC-BYT DB-E ..... 48

    2.7.6 ARC-BYT DB-F ..... 49

    2.7.7 ARC-BYT DB-G ..... 49

    2.7.8 ARC-BYT DB-H ..... 49

    2.7.9 ARC-BYT DB-K ..... 49

2.8 ARC-BYT DB-D Connectors settings ..... 51

    2.8.1 Serial Port 1 connector (D\_COM1) ..... 51

    2.8.2 Serial Port 2 connector (D\_COM2) ..... 51

2.9 ARC-BYT DB-E Jumpers & Connectors settings ..... 52

    2.9.1 CAN2.0 Switch (E\_JCAN20) ..... 52

    2.9.2 For user update FW (E\_JBOOT0) ..... 52

    2.9.3 For user update FW (E\_JIAP1) ..... 53

2.10 ARC-BYT DB-F Connectors settings ..... 55

2.11 ARC-BYT DB-G Connectors settings ..... 56

    2.11.1 Serial Port 1 connector (G\_COM1) ..... 56

    2.11.2 Serial Port 2 connector (G\_COM2) ..... 56

    2.11.3 Serial Port 3 connector (G\_COM3) ..... 57

2.12 ARC-BYT DB-H Jumpers settings ..... 57

    2.12.1 USB Power selector (H\_USB\_PWR\_SEL1) ..... 57

2.13 ARC-BYT DB-H Connectors settings ..... 58

    2.13.1 Serial Port 1 connector (H\_COM1) ..... 58

    2.13.2 Serial Port 2 connector (H\_COM2) ..... 58

2.14 ARC-BYT DB-K Connectors settings ..... 59

    2.14.1 Serial Port 1 connector (I\_COM1) ..... 59

    2.14.2 Serial Port 2 connector (I\_COM2) ..... 59

<b>3.</b>	<b>Installation .....</b>	<b>60</b>
3.1	Installing Hard Disk & Memory .....	62
3.2	Installing ARC-BYT DB .....	64
3.3	System Mounting .....	66
3.3.1	Wall Mounting .....	67
3.3.2	ARM/ Stand Mounting .....	69
3.3.3	Panel Mounting .....	70
3.3.4	VESA Mounting .....	72
<b>4.</b>	<b>Drivers Installation.....</b>	<b>73</b>
4.1	Install Chipset Driver .....	74
4.2	Install VGA Driver.....	75
4.3	Install ME Driver.....	76
4.4	Install Serial IO Driver .....	77
4.5	Install Audio Driver (For Realtek ALC888S).....	78
4.6	Install LAN Driver .....	79
<b>5.</b>	<b>BIOS Setup.....</b>	<b>80</b>
5.1	Introduction .....	81
5.2	Starting Setup .....	81
5.3	Using Setup .....	82
5.4	Getting Help.....	83
5.5	In Case of Problems.....	83
5.6	BIOS setup.....	84
5.6.1	Main Menu .....	84
5.6.1.1	System Language.....	85
5.6.1.2	System Date .....	85
5.6.1.3	System Time.....	85
5.6.2	Advanced Menu.....	85
5.6.2.1	CPU Configuration.....	86
5.6.2.1.1	Efficient-core Information.....	87
5.6.2.2	Power & Performance .....	87
5.6.2.2.1	CPU – Power Management Control .....	88
5.6.2.2.1.1	View/Configure Turbo Options.....	<b>88</b>
5.6.2.3	PCH-FW Configuration.....	89
5.6.2.3.1	Firmware Update Configuration.....	89
5.6.2.3.2	PTT Configuration.....	90
5.6.2.4	Trusted Computing .....	90
5.6.2.5	APCI Settings .....	91
5.6.2.6	IT5782 Super IO Configuration.....	91
5.6.2.6.1	Serial Port 1 Configuration .....	92
5.6.2.6.2	Serial Port 2 Configuration .....	93

5.6.2.6.3	Serial Port 3 Configuration .....	93
5.6.2.6.4	Serial Port 4 Configuration .....	94
5.6.2.6.5	Serial Port 5 Configuration .....	94
5.6.2.7	HW Monitor .....	95
5.6.2.8	S5 RTC Wake Settings .....	95
5.6.2.9	Serial Port Console Redirection .....	96
5.6.2.10	USB Configuration .....	96
5.6.2.11	Network Stack Configuration .....	97
5.6.2.12	NVMe Configuration .....	98
5.6.3	Chipset .....	98
5.6.3.1	System Agent (SA) Configuration .....	99
5.6.3.1.1	Memory Configuration .....	99
5.6.3.1.2	Graphics Configuration .....	100
5.6.3.2	PCH-IO Configuration .....	100
5.6.3.2.1	PCI Express Configuration .....	101
5.6.3.2.1.1	PCI Express Root Port 4 (M.2 KeyE) .....	101
5.6.3.2.1.2	PCI Express Root Port 7 (LAN1-I226) .....	102
5.6.3.2.1.3	PCI Express Root Port 9 (B2B) .....	103
5.6.3.2.1.4	PCI Express Root Port 10 (LAN2-I226) .....	104
5.6.3.2.2	SATA Configuration .....	105
5.6.3.2.3	HD Audio Configuration .....	105
5.6.3.3	Board & Panel Configuration .....	106
5.6.4	Security .....	107
5.6.4.1	Secure Boot .....	108
5.6.5	Boot .....	108
5.6.6	Save and exit .....	109
5.6.6.1	Save Changes and Reset .....	109
5.6.6.2	Discard Changes and Reset .....	109
5.6.6.3	Restore Defaults .....	110
5.6.6.4	Launch EFI Shell from filesystem device .....	110
<b>6.</b>	<b>Maintenance &amp; Troubleshooting .....</b>	<b>111</b>
<b>7.</b>	<b>Product Application .....</b>	<b>117</b>
<b>8.</b>	<b>Operating the Device .....</b>	<b>118</b>

# 1. Getting Started

## 1.1 Safety Precautions

### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

## 1.2 Packing List

Before installation, please ensure all the items listed in the following table are included in the package.

Item	Description	Q'ty
1	ARC-10W37 Panel PC	1
2	Power Adapter	1
3	Screws for VESA	4
4	Screws for HDD	4
5	Bracket & screws for panel mount	8



If any of the above items is damaged or missing, contact your retailer.

## Purposes and Applications

ARC-10W37 is used the Intel Atom (Alder-Lake N platform), which has stronger performance and lower power consumption(6~12W). it also inherits from ARC-series strength, Modularized, Flexible Expansion, Reliability and Stability.

The customer can choose ARC-10W37 to use wide temperature environment, and also ARC series have been passed stricter vibration and shock testing. It can be used on extreme environment like manufacture or factory.

Typical applications are HMI, Automation, POI, KIOSK.

It also can be suitable for the customer's various application and scenario that need more ruggedized, vibration and water/dust-proof environment (IP65 Front Panel, IP41 Rear (except I/O)).

## Unpacking

### Note:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the Avalue reseller or vendor the product was purchased from or contact an Avalue sales representative directly by sending an email to [sales@avalue.com](mailto:sales@avalue.com).

To unpack the flat bezel panel PC, follow the steps below.

### WARNING!

The front side LCD screen has a protective plastic cover stuck to the screen. Only remove the plastic cover after the fiat bezel panel PC has been properly installed. This ensures the screen is protected during the installation process.

Step 1: Carefully cut the tape sealing the box. Only cut deep enough to break the tape.

Step 2: Open the outside box.

Step 3: Carefully cut the tape sealing the box. Only cut deep enough to break the tape.

Step 4: Open the inside box.

Step 5: Lift the panel PC out of the boxes.

Step 6: Remove the peripheral parts box from the main box.

## 1.3 System Specifications

System Information	
<b>SBC</b>	ARC-ADLN
<b>Processor</b>	Intel® Alder Lake-N (N97, 12W) Intel® Alder Lake-N (X7425E, 12W)
<b>CPU Cooler (Type)</b>	Fanless Heatsink
<b>System Memory</b>	1 x 262-pin DDR5 4800MHz SO-DIMM socket, supports up to 16GB Max (non ECC only)
<b>System Fan</b>	Fanless
<b>I/O Chipset</b>	EC: ITE IT5782VG
<b>Watchdog Timer</b>	H/W Reset, 1sec. ~ 65535sec
<b>H/W Status Monitor</b>	CPU & system temperature monitoring and Voltages monitoring
<b>TPM</b>	TPM 2.0
<b>Speaker</b>	2W*2
<b>Wireless LAN</b>	Default N/A; Optional support by M.2 Key-E 2230 slot (Support PCIe1, USB2.0 Wi-Fi/BT module)
<b>Bluetooth</b>	Default N/A; Optional support by M.2 Key-E 2230 slot (Support PCIe1, USB2.0 Wi-Fi/BT module)
<b>Operating System</b>	Win 10/11 Linux
<b>Expansion Card</b>	1 x M.2 (Key-B, 2242/3042/3052, SATAIII, USB3.2 Gen1x1 (default, 5Gbp/s)) or PCIe1 (via OEM BIOS request), USB2.0, SIM Slot for LTE Cards (*Not support PCIe2 device) 1 x M.2 (Key-E, 2230, PCIe1, USB2.0) 1 x 80-pin Expansion IET interface
<b>Other Component</b>	SIM card slot (for 4G or 5G module) for M.2 Key-B 2242/3042/3052
Storage	
<b>Hard Disk Drive</b>	1 x 2.5" Drive Bay
<b>Solid State Drive</b>	1 x 2.5" Drive Bay
<b>Other Storage Device</b>	1 x M.2 Key-B 2242/3042/3052 for M.2 SATAIII SSD by default
Panel	
<b>LCD Panel</b>	10.1", 16:10 Please note that long-term operation in an environment exceeding 50°C (122°F) will affect the service life of the Panel.
<b>Display Type</b>	WXGA
<b>Resolution</b>	1280 x 800
<b>Pixel pitch</b>	0.1695mm(H) x 0.1695mm(V)
<b>Luminance</b>	400 cd/m2

<b>Contrast ratio</b>	800
<b>Viewing angle</b>	85 (U), 85 (D), 85 (L), 85 (R)
<b>Response time</b>	25 ms
<b>Backlight</b>	LED
<b>Touch Type</b>	Projective capacitive multi-touch up to 10 points
<b>Touch Light Transmission</b>	88%
<b>Touch Controller</b>	EETI
<b>Rear I/O</b>	
<b>Serial Port</b>	1 x DB-9 COM1 (RS-232(default)/422/485) 1 x DB-9 COM2 (RS-232)
<b>USB Port</b>	2 x USB3.2 (1 x Dual Deck, Type A) 1 X USB Type C (w/ PD (20V/3A Input), USB3.2(Gen2x1, 10Gbps, 5V/3A output), Display function)
<b>DIO Port</b>	12-bit GPIO + 2-pin CAN Bus (by ARC-BYT DB-E)
<b>Video Port</b>	(Option By IET module only, (DB-B, DB-C)
<b>Audio Port</b>	Realtek ALC888S
<b>LAN Port</b>	2 x Intel® I226LM 2.5 Gigabit Ethernet
<b>Wireless LAN Antenna</b>	3 x Antenna hole on Top of back cover (2 x Antenna hole on empty IET bracket)
<b>Indicator Light</b>	HDD LED, Power LED (Green for Power, Yellow for HDD)
<b>Expansion Slots</b>	1 x M.2 (Key-B, 2242/3042/3052, SATAIII, USB3.2 Gen1x1(default, 5Gbp/s)) or PCIe1(via OEM BIOS request), USB2.0, SIM Slot for LTE Cards (*Not support PCIe2 device) 1 x M.2 (Key-E, 2230, PCIe1, USB2.0) 1 x 80-pin Expansion IET interface
<b>DC in Connector</b>	Lockable DC Jack (option for phoenix connector)
<b>Onboard I/O</b>	
<b>COM</b>	JRI1/2: 3 x 2 header, pitch 2.00mm (for serial port 1/2 pin9 signal select)-jumper JCOM1_SEL1: 4 x 3 header, pitch 2.00mm (COM1 RS-232/422/485 mode)-jumper
<b>USB</b>	JUSB1: 1 x 2 x 5 pin, pitch 2.00mm wafer Touch(BOM option for resistive/P-cap): JTP1: 5 x 1 header, pitch 2.54mm
<b>GPIO</b>	(Option By IET module only (DB-E)
<b>SATA</b>	1x SATA III connector
<b>SATA Power</b>	1x 2-Pin Wafer (2.0mm) for 5V Power SATA Power,1A

## ARC-10W37

<b>Buzzer</b>	With buzzer onboard
<b>Front Panel</b>	JFP1:5 x 2 wafer, pitch 2.00mm
<b>RTC Battery</b>	1 x 2-Pin Wafer (1.25mm) CR2032 for standard temperature
<b>AT/ATX Selector</b>	1 x 3-Pin Header (2.0mm), Default is AT
<b>Clear CMOS</b>	1 x 3-Pin Header (2.0mm)
<b>LVDS/eDP</b>	JLVDS1: DIN 40-pin wafer, pitch 1.25mm(1 x 2x20-pin Hirose connector for 2x24-bit LVDS) Co-layout eDP signal, BOM option, use the same connector
<b>LCD Backlight Brightness</b>	JBKL1: 5 x 1 wafer, pitch 2.00mm JBKLSL1: 3 x 1 header, pitch 2.00mm- jumper (DC or PWM mode)
<b>Touch</b>	BOM option for resistive/Pcap JTP1: 5 x 1 header, pitch 2.54mm (for resistive touch) JUSB1: 1 x 2 x 5 pin, pitch 2.00mm wafer(for P-cap touch)
<b>LPC</b>	N/A (eSPI to LPC by IT8882FN for JB2B1 IET Con.)
<b>BIOS SPI</b>	JSPI1: 4 x 2 header, pitch 2.00mm
<b>eSPI</b>	JESPI1: 1 x 2 x 6 pin, pitch 2.00mm connector for eSPI debug
<b>EC Debug</b>	JEC1: 2 x 1 header, pitch 2.00mm
<b>Audio</b>	Line in, Line out, Mic in thru IET module(DB-B)
<b>DC-Input</b>	Lockable Power connector
<b>Amp Connector</b>	JSPR1: 2 x 1 wafer, pitch 2.0mm JSPL1: 2 x 1 wafer, pitch 2.0mm
<b>Other</b>	JB2B1: 40 x 2 wafer, pitch 0.80mm (IET connector) NGFF1: 1 x M.2 (Key-B, 2242/3042/3052, SATAIII, PCIe1, USB3.2 Gen1x1 (5Gbp/s)), USB2.0, SIM Slot for LTE Cards NGFF2: 1 x M.2 (Key-E, 2230, PCIe1, USB2.0)
<b>Power Requirement</b>	
<b>DC Input Voltage</b>	+12~24V DC input, 10A
<b>Power Mode</b>	ATX/AT by jumper (Default ATX)
<b>Power Button</b>	1 x Power Switch on the side
<b>Wake on Mode</b>	Wake on LAN (specify condition, ex. S3/S4/S5) Wake on RTC, Wake on Ring
<b>Power Connector Type</b>	Lockable DC Jack (option for phoenix connector)
<b>Power Adapter</b>	AC/DC adapter 19V/3.78A Screw Type
<b>Mechanical</b>	
<b>Dimension</b>	282.4 x 201 x 50.9mm
<b>Weight</b>	2.3 Kgs
<b>Construction- Front</b>	Die casting with cover lens

<b>Construction- Rear</b>	Black die casting
<b>Thermal Solution</b>	Fanless
<b>Reliability</b>	
<b>Dust and Rain Test</b>	Front Panel IP65 Rear IP41 except I/O
<b>Vibration Test</b>	<p>Random Vibration Operation:</p> <ol style="list-style-type: none"> <li>1. PSD : 0.01818G<sup>2</sup>/Hz 3 Grms</li> <li>2. operation mode</li> <li>3. Test Frequency : 5-500Hz</li> <li>4. Test Axis : X,Y and Z axis</li> <li>5. 30 minutes per each axis</li> <li>6. IEC 60068-2-64 Test:Fh</li> <li>7. Storage : SSD or M.2 SSD</li> </ol> <p>Sine Vibration test (Non-operation)</p> <ol style="list-style-type: none"> <li>1 Test Acceleration : 2G</li> <li>2 Test frequency : 5~500 Hz</li> <li>3 Sweep : 1 Oct/ per one minute. (logarithmic)</li> <li>4 Test Axis : X,Y and Z axis</li> <li>5 Test time :30 min. each axis</li> <li>6 System condition : Non-Operating mode</li> <li>7. Reference IEC 60068-2-6 Testing procedures</li> </ol> <p>Package vibration test</p> <ol style="list-style-type: none"> <li>1. PSD: 0.026G<sup>2</sup>/Hz , 2.16 Grms</li> <li>2. Non-operation mode</li> <li>3. Test Frequency : 5-500Hz</li> <li>4. Test Axis : X,Y and Z axis</li> <li>5. 30 min. per each axis</li> <li>6. IEC 60068-2-64 Test:Fh</li> </ol>
<b>Mechanical Shock Test</b>	<ol style="list-style-type: none"> <li>1. Wave form : Half Sine wave</li> <li>2. Acceleration Rate : 20g for operation mode</li> <li>3. Duration Time : 11ms</li> <li>4. No. of Shock : +/- X,Y,Z axis 3 times</li> <li>5. Test Axis: +/- X,Y,Z axis</li> <li>6. Operation mode</li> <li>7. Reference IEC 60068-2-27 Testing procedures Test Eb : Shock Test</li> </ol>
<b>Drop Test</b>	<p>Package drop test</p> <p>Reference ISTA 2A, Method : IEC-60068-2-32 Test:Ed</p> <p>Test Ea : Drop Test</p>

## ARC-10W37



	<p>1 Test phase : One corner, three edges, six faces</p> <p>2 Test high : 96.5cm</p> <p>3 Package weight : 2.3Kg</p> <p>4 Test drawing</p> <p>4-foot drop resistance without package</p> <p>MIL-STD-810G</p>
<b>Operating Temperature</b>	0°C ~ 50°C (32°F ~ 122°F)
<b>Operating Humidity</b>	40°C @ 95% Relative Humidity, Non-condensing
<b>Storage Temperature</b>	-20°C ~ 60°C (-4°F ~ 140°F)
<b>Compliant with following Flexible Expansion Modules</b>	
<b>IET Module</b>	Optional IET Module list:
<b>ACC-ARC-USB-1R</b>	<b>IET DB-A 4 x USB3.0 kit for ARC Series</b>
<b>ACC-ARC-AUDIO-1R</b>	<b>IET DB-B HDMI + 5.1 CH Audio Kit for ARC Series</b>
<b>ACC-ARC-MPCIE-1R</b>	<b>IET DB-C HDMI + MPCIE w/SIM Kit for ARC Series</b>
<b>ACC-ARC-COM-1R</b>	<b>IET DB-D 2 x Isolated RS-232 Kit for ARC Series</b> (ARC-EHL is used eSPI EC, so need to add eSPI to LPC IC for UART)
<b>ACC-ARC-COM-2R</b>	<b>IET DB-G 3 x RS-232 Kit for ARC Series</b> (ARC-EHL is used eSPI EC, so need to add eSPI to LPC IC for UART)
<b>ACC-ARC-COM-3R</b>	<b>IET DB-H 2 x RS-232 + USB Kit for ARC Series</b> (ARC-EHL is used eSPI EC, so need to add eSPI to LPC IC for UART)
<b>ACC-ARC-COM-4R</b>	<b>IET DB-K 2 x RS-232 + LAN Kit for ARC Series</b> (ARC-EHL is used eSPI EC, so need to add eSPI to LPC IC for UART)
<b>ACC-ARC-GPIO-1R</b>	<b>IET DB-E 12-bit GPIO + 2-pin CAN Bus Kit for ARC Series</b>
<b>ACC-ARC-OBDII-1R</b>	<b>IET DB-F OBDII - CAN Bus Kit for ARC Series (OBDII/EOBD for Small Vehicle)</b> (ARC-EHL is used eSPI EC, so need to add eSPI to LPC IC for UART)
<b>ACC-ARC-OBDII-2R</b>	<b>IET DB-F OBDII - CAN Bus Kit for ARC Series (J1939J1708 for Large Vehicle)</b> (ARC-EHL is used eSPI EC, so need to add eSPI to LPC IC for UART)
<b>ACC-ARC-OBDII-3R</b>	<b>IET DB-F OBDII - CAN Bus Kit for ARC Series (ISO15765-4 for Special Large Vehicle)</b> (ARC-EHL is used eSPI EC, so need to add eSPI to LPC IC for UART)



**Note:** Specifications are subject to change without notice.

## 1.4 System Overview


### 1.4.1 I/O View



### Connectors

Label	Function	Note
DC-IN	DC Power-in connector	
COM1/2	Serial port 1/2 connector	DB-9 male connector
USB3.2	2 x USB 3.2 connector	
USB Type C	USB Type C connector	
LAN1/2	RJ-45 Ethernet 1/2	
LED	HDD/Power LED indicator	
Power Switch	Power on button	

## 1.5 System Dimensions



(Unit: mm)

# 2. Hardware Configuration

---

For advanced information, please refer to:

- 1- ARC-ADLN, ARC-BYT DB-A/B/C/D/E/F/G/H/K included in this manual.





**Note:** If you need more information, please visit our website:

[www.avalue.com](http://www.avalue.com)

## 2.1 ARC-10W37 connector mapping

### 2.1.1 Serial port 1 connector (COM1)



#### RS-232\*

Signal	PIN	PIN	Signal
NDCD#	1	6	NDSR#
NRXD	2	7	NRTS#
NTXD	3	8	NCTS#
NDTR#	4	9	NRI#
GND	5		

\* Default

**Note:**

supports RS232 (BOM option for RS422/485)



#### RS-422(BOM option)

Signal	PIN	PIN	Signal
TxD-	1	6	NC
TxD+	2	7	NC
RxD+	3	8	NC
RxD-	4	9	NC
GND	5		

#### RS-485(BOM option)

Signal	PIN	PIN	Signal
DATA-	1	6	NC
DATA+	2	7	NC
NC	3	8	NC
NC	4	9	NC
GND	5		

2.1.2 Serial port 2 connector (COM2)



**RS-232**

Signal	PIN	PIN	Signal
NDCD#	1	6	NDSR#
NRXD	2	7	NRTS#
NTXD	3	8	NCTS#
NDTR#	4	9	NRI#
GND	5		

## 2.2 Powering On the System



To power on the system, follow the steps below.

Step 1: Connect the power cord to the power adapter. Connect the other end of the power cord to a power source. Ensure to connect the power cord to a socket-outlet with earthing connection.


Step 2: Connect the power adapter to the power connector of the product.

Step 3: Locate the power button on the product.

Step 4: Switch on the power button can turn on the system. Keep holding the power button on can force shutdown the PC.




## 2.3 ARC-ADLN Overview



## 2.4 ARC-ADLN Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board’s jumpers and connectors.

### Jumpers

Label	Function	Note
JRI1/2	Serial port 1/2 pin9 signal select	3 x 2 header, pitch 2.00mm
JCOM_SEL1	Serial port 1 in RS-232/422/485 mode	4 x 3 header, pitch 2.00mm
JSBKL1	LVDS Back Light power selection	3 x 1 header, pitch 2.54mm
JSATX1	AT/ATX Input power select	3 x 1 header, pitch 2.54mm
JP1	M.2 KEY power select	3 x 1 header, pitch 2.00mm
JRTC1	Clear CMOS	3 x 1 wafer, pitch 2.00mm

### Connectors


Label	Function	Note
SO_DIMM1	1 x 262-Pin DDR5 4800MHz SO-DIMM	
JFP1	Front Panel connector	6 x 2 wafer, pitch 2.00mm
JPD1	PD JTAG connector	4 x 1 header, pitch 2.00mm

## Quick Reference Guide


<b>JBKL1</b>	LCD Inverter connector	5 x 1 wafer, pitch 2.00mm Matching Connector: JST PHR-5
<b>COM1/2</b>	Serial Port 1/2 connector	D-sub 9 pin, male
<b>JSPKR1</b>	AMPLIFIER_R	2 x 1 wafer, pitch 2.00mm
<b>JSPKL1</b>	AMPLIFIER_L	2 x 1 wafer, pitch 2.00mm
<b>JB2B1</b>	B2B connector	40 x 2 wafer, pitch 0.80mm
<b>SW1</b>	Power Button	
<b>LED1</b>	HDD/Power LED indicator	
<b>LVDS1</b>	LVDS connector	DIN 40-pin wafer, pitch 1.25mm Matching Connector: Hirose DF13-40DS-1.25C
<b>USB1</b>	USB connector	
<b>TYPEC1</b>	USB Type C connector	
<b>JUSB1</b>	On-board header for USB2.0	5 x 1 wafer, pitch 2.00mm
<b>JTP1</b>	Touch panel connector	5 x 1 header, pitch 2.54mm
<b>JUSB2</b>	On-board header for USB2.0	5 x 1 wafer, pitch 2.00mm
<b>LAN1/2</b>	RJ-45 Ethernet 1/2	
<b>BT1</b>	Battery connector	2 x 1 wafer, pitch 1.25mm
<b>DCIN1</b>	Power connector	
<b>JSPI1</b>	SPI connector	4 x 2 header, pitch 2.00mm
<b>JEC1</b>	EC Debug connector	3 x 1 header, pitch 2.00mm
<b>SATA1</b>	Serial ATA connector	
<b>SATAPW1</b>	SATA Power connector	2 x 1 wafer, pitch 2.00mm
<b>M2B1</b>	M.2 2242/3042/3052 Type B Slot	
<b>M2KE1</b>	M.2 2230 Type E Slot	
<b>USIM1</b>	USIM card slot	

## 2.5 ARC-ADLN Jumpers & Connectors settings


### 2.5.1 Clear CMOS (JRTC1)



Protect\*




Clear CMOS




\*Default


### 2.5.2 Serial port 1/2 pin9 signal select (JRI1/JRI2)




Ring\*



+5V




+12V




\* Default


2.5.3 Serial port 1 in RS-232/422/485 mode (JCOM\_SEL1)




RS232\*



RS422



RS485




PIN	Signal	PIN	Signal	PIN	Signal
1	NDCDA#	2	COM1-1	3	485_422TX1-
4	NTXDA	5	COM1-3	6	422RX1+
7	NRXDA	8	COM1-2	9	485_422TX1+
10	NDTRA#	11	COM1-4	12	422RX1-

Note:

This connector is available after modify the mode of COM1 in BIOS setting.

\* Default


2.5.4 LVDS Back Light power selection (JSBKL1)



PWM mode\*




DC mode




\* Default

# ARC-10W37


## 2.5.5 AT/ATX Input power select (JSATX1)



ATX\*




AT




\* Default


## 2.5.6 M.2 KEY power select (JP1)



+3.8V





+3.3V\*





\* Default

2.5.7 LCD Inverter connector (JBKL1)





Signal	PIN
+5V	5
LVDS_BKLADJ	4
LVDS_BKLT_EN	3
GND	2
+12V	1

2.5.8 Firmware Update connector (JPD1)




Signal	PIN
LDO_3V3	1
EEPROM_I2C_SCL	2
EEPROM_I2C_SDA	3
GND	4

2.5.9 Touch connector (JTP1) co-lay USB2.0 header (JUSB1)



JTP1\*

Signal	PIN
X+	1
X-	2
SENSE	3
Y+	4
Y-	5





JUSB1

Signal	PIN
+5VSB	1
USB_WFR_PN8	2
USB_WFR_PP8	3
GND	4
GND	5



\*Default

2.5.10 On-board header for USB2.0 (JUSB2)




Signal	PIN
GND	5
GND	4
USB2_R_DP8	3
USB2_R_DN8	2
+5VSB	1

2.5.11 LVDS connector (LVDS1)




Signal	PIN	PIN	Signal
LVDS_VDD12V	39	40	LVDS_VDD12V
GND	37	38	GND
LVDS_CLK2N	35	36	LVDS_CLK1N
LVDS_CLK2P	33	34	LVDS_CLK1P
GND	31	32	GND
LVDS_DATAN7	29	30	LVDS_DATAN6
LVDS_DATAP7	27	28	LVDS_DATAP6
GND	25	26	GND
LVDS_DATAN5	23	24	LVDS_DATAN4
LVDS_DATAP5	21	22	LVDS_DATAP4
GND	19	20	GND
LVDS_DATAN3	17	18	LVDS_DATAN2
LVDS_DATAP3	15	16	LVDS_DATAP2
GND	13	14	GND
LVDS_DATAN1	11	12	LVDS_DATAN0
LVDS_DATAP1	9	10	LVDS_DATAP0
GND	7	8	GND
LVDS_VDD33V	5	6	LVDS_VDD5V
LVDS_VDD33V	3	4	LVDS_VDD5V
LVDS_VDD33V	1	2	LVDS_VDD5V

2.5.12 AMPLIFIER\_R (JSPKR1)





Signal	PIN
SPK_R-	2
SPK_R+	1

2.5.13 AMPLIFIER\_L (JSPKL1)





Signal	PIN
SPK_L-	2
SPK_L+	1

2.5.14 SPI connector (JSPI1)





Signal	PIN	PIN	Signal
+3.3VSB	1	2	GND
ROM_CS#	3	4	ROM_SPI_CLK
ROM_SPI_MISO	5	6	ROM_SPI_MOSI
HOLD#	7	8	SPI_WP#

2.5.15 EC Debug connector (JEC1)



Signal	PIN
EC_SMDAT_DBG	1
EC_SMCLK_DBG	2
GND	3


2.5.16 B2B connector (JB2B1)



Signal	PIN	PIN	Signal
GND	1	41	GND
GND	2	42	GND
+12V	3	43	GND
+12V	4	44	GND
GND	5	45	GND
LPC_SERIRQ	6	46	+5VSB
LPC_LFRAME#	7	47	+5VSB
CLK_24M_CB	8	48	+5VSB
LPC_AD0	9	49	+5VSB
LPC_AD1	10	50	+5VSB



Signal	PIN	PIN	Signal
LPC_AD2	11	51	GND
LPC_AD3	12	52	USB2_DP4
PS_ON_B2B	13	53	USB2_DN4
PLT_BUF_RST#	14	54	GND
PCH_SLP_S3#	15	55	SMB_SCL_S0
HDMI1_HPD_CONN	16	56	SMB_SDA_S0
GND	17	57	GND
HDMI1_DDC_CLK	18	58	B2B_BOARD_ID
HDMI1_DDC_DAT	19	59	PCIEUSB3_PONRSTB
GND	20	60	PCIEUSB3_SMIB_INT#
HDMI1_TX_N2	21	61	B2BPCIE_WAKE#
HDMI1_TX_P2	22	62	RST_B2BPCIE#
GND	23	63	PCIE_CLKREQ#_3
HDMI1_TX_N1	24	64	GND
HDMI1_TX_P1	25	65	PCIE_TXN_9
GND	26	66	PCIE_TXP_9
HDMI1_TX_N0	27	67	GND
HDMI1_TX_P0	28	68	PCIE_RXN_9
GND	29	69	PCIE_RXP_9
HDMI1_CLKN	30	70	GND
HDMI1_CLKP	31	71	PCIE_CLK_N3
GND	32	72	PCIE_CLK_P3
GND	33	73	GND
MICIN_R	34	74	GND
MICIN_L	35	75	MIC1_JD
GND	36	76	GND
LINEOUT1_JD	37	77	LINE1-JD
LINEOUT_R	38	78	LINEIN_R
LINEOUT_L	39	79	LINEIN_L
GND	40	80	GND

2.5.17 SATA Power connector (SATAPW1)




Signal	PIN
GND	1
+5V	2

2.5.18 Front Panel connector (JFP1)



Signal	PIN
PWBT	1
	2
RST#	3
	4
PWR-LED-	5
PWR-LED+	6
HDD-LED-	7
HDD-LED+	8
LAN1-LED-	9
LAN1-LED+	10
LAN2-LED-	11
LAN2-LED+	12


### 2.5.19 Battery connector (BT1)




Signal	PIN
+RTCBATT	1
GND	2

## 2.6 ARC-BYT DB-A/B/C/D/E/F/G/H/K Overviews


### 2.6.1 ARC-BYT DB-A



### 2.6.2 ARC-BYT DB-B




### 2.6.3 ARC-BYT DB-C




## ARC-10W37


### 2.6.4 ARC-BYT DB-D




### 2.6.5 ARC-BYT DB-E




### 2.6.6 ARC-BYT DB-F




2.6.7 ARC-BYT DB-G



2.6.8 ARC-BYT DB-H



2.6.9 ARC-BYT DB-K



## 2.7 ARC-BYT DB-A/B/C/D/E/F/G/H/K Connector list

### 2.7.1 ARC-BYT DB-A

#### Connectors

Label	Function	Note
A_JUSB1~4	USB3.0 connector 1~4	
A_JB2B1	B2B connector	

### 2.7.2 ARC-BYT DB-B

#### Connectors

Label	Function	Note
B_LINE_OUT1	Line-out audio jack	
B_LINE_IN1	Line-in audio jack	
B_MIC_IN1	Mic-in audio jack	
B_JHDMI1	HDMI connector	
B_JB2B1	B2B connector	

### 2.7.3 ARC-BYT DB-C

#### Connectors

Label	Function	Note
C_JPCIE1	Mini PCI Express connector	
C_JSIM1	SIM card slot (Push-push)	
C_JHDMI1	HDMI connector	
C_JB2B1	B2B connector	

### 2.7.4 ARC-BYT DB-D

#### Connectors

Label	Function	Note
D_COM1/2	Serial Port 1/2 connector	DB-9 male connector
D_JB2B1	B2B connector	

### 2.7.5 ARC-BYT DB-E

#### Jumpers

Label	Function	Note
E_JCAN20	CAN2.0 Switch	3 x 1 header, pitch 2.00mm
E_JIAP1	For user update FW	3 x 1 header, pitch 2.00mm
E_JBOOT0	For user update FW	3 x 1 header, pitch 2.00mm

**Connectors**

Label	Function	Note
E_GPIO1	General purpose I/O connector	14 x 1 terminal, pitch 2.50mm
E_CN1	For user update FW	5 x 1 header, pitch 2.54mm
E_CAN1	CAN Bus connector	3 x 1 terminal, pitch 2.50mm
E_JB2B1	B2B connector	

**2.7.6 ARC-BYT DB-F****Connectors**

Label	Function	Note
F_CAN1	CAN Bus connector 1	7 x 2 header, pitch 2.00mm
F_CAN2	CAN Bus connector 2	
F_JB2B1	B2B connector	

**2.7.7 ARC-BYT DB-G****Connectors**

Label	Function	Note
G_COM1/2/3	Serial Port 1/2/3 connector	DB-9 male connector
G_JB2B1	B2B connector	

**2.7.8 ARC-BYT DB-H****Jumpers**

Label	Function	Note
H_USB_PWR_SEL1	USB Power selector	3 x 1 header, pitch 2.00mm

**Connectors**

Label	Function	Note
H_JUSB1	USB3.0 connector	
H_COM1/2	Serial Port 1/2 connector	DB-9 male connector
H_JB2B1	B2B connector	

**2.7.9 ARC-BYT DB-K****Connectors**

Label	Function	Note
I_JLAN1	RJ-45 Ethernet	

## ARC-10W37

---

<b>I_COM1/2</b>	Serial Port 1/2 connector	DB-9 male connector
-----------------	---------------------------	---------------------



---

<b>I_JB2B1</b>	B2B connector	
----------------	---------------	--

---



## 2.8 ARC-BYT DB-D Connectors settings

### 2.8.1 Serial Port 1 connector (D\_COM1)



Signal	PIN	PIN	Signal
NDCD#_3_D	1	6	NDSR#_3_D
NRXD_3_D	2	7	NRTS#_3_D
NTXD_3_D	3	8	NCTS#_3_D
NDTR#_3_D	4	9	NRI#_3_D
GND	5		


### 2.8.2 Serial Port 2 connector (D\_COM2)




Signal	PIN	PIN	Signal
NDCD#_2_D	1	6	NDSR#_2_D
NRXD_2_D	2	7	NRTS#_2_D
NTXD_2_D	3	8	NCTS#_2_D
NDTR#_2_D	4	9	NRI#_2_D
GND	5		

## 2.9 ARC-BYT DB-E Jumpers & Connectors settings


### 2.9.1 CAN2.0 Switch (E\_JCAN20)



CAN2.0A (11-bit)\*




CAN2.0B (29-bit)




\*Default


### 2.9.2 For user update FW (E\_JBOOT0)



Default\*




For user update FW




\*Default


2.9.3 For user update FW (E\_JIAP1)



Default\*





For user update FW




\*Default

2.9.4 For user update FW (E\_CN1)




Signal	PIN
+3.3V	1
SWDIO	2
SWCLK	3
CAN_BUS_RESET#	4
GND	5

2.9.5 General purpose I/O connector (E\_GPIO1)



Signal	PIN
GND	14
+3.3V	13
DO5	12
DO4	11
DO3	10
DO2	9
DO1	8
DO0	7
DI5	6
DI4	5
DI3	4
DI2	3
DI1	2
DI0	1



2.9.6 CAN Bus connector (E\_CAN1)



Signal	PIN
CANH	1
CANL	2
GND	3



## 2.10 ARC-BYT DB-F Connectors settings

### 2.10.1 CAN Bus connector 1 (F\_CAN1)



Signal	PIN	PIN	Signal
CAN_PWR	1	2	CAN_8
CAN_IND	3	4	CAN_9
GND	5	6	BAT_GND
CAN_WAKE	7	8	CAN_11
UART_RXD_1_F	9	10	CAN_12
UART_TXD_1_F	11	12	CAN_13
+5V	13	14	CAN_14



### 2.10.2 CAN Bus connector 2 (F\_CAN2)



Signal	PIN	PIN	Signal
BAT_PWR	1	6	CAN_12
CAN_8	2	7	CAN_13
CAN_9	3	8	CAN_14
BAT_GND	4	9	NC
CAN_11	5		



## 2.11 ARC-BYT DB-G Connectors settings

### 2.11.1 Serial Port 1 connector (G\_COM1)





Signal	PIN	PIN	Signal
NDCD#_3_G	1	6	NDSR#_3_G
NRXD_3_G	2	7	NRTS#_3_G
NTXD_3_G	3	8	NCTS#_3_G
NDTR#_3_G	4	9	NRI#_3_G
GND	5		

### 2.11.2 Serial Port 2 connector (G\_COM2)



Signal	PIN	PIN	Signal
NDCD#_2_G	1	6	NDSR#_2_G
NRXD_2_G	2	7	NRTS#_2_G
NTXD_2_G	3	8	NCTS#_2_G
NDTR#_2_G	4	9	NRI#_2_G
GND	5		


### 2.11.3 Serial Port 3 connector (G\_COM3)




Signal	PIN	PIN	Signal
NDCD#_1_G	1	6	NDSR#_1_G
NRXD_1_G	2	7	NRTS#_1_G
NTXD_1_G	3	8	NCTS#_1_G
NDTR#_1_G	4	9	NRI#_1_G
GND	5		

## 2.12 ARC-BYT DB-H Jumpers settings


### 2.12.1 USB Power selector (H\_USB\_PWR\_SEL1)



+5VSB\*





+5V



\*Default



## 2.13 ARC-BYT DB-H Connectors settings

### 2.13.1 Serial Port 1 connector (H\_COM1)



Signal	PIN	PIN	Signal
NDCD#_1_H	1	6	NDSR#_1_H
NRXD_1_H	2	7	NRTS#_1_H
NTXD_1_H	3	8	NCTS#_1_H
NDTR#_1_H	4	9	NRI#_1_H
GND	5		



### 2.13.2 Serial Port 2 connector (H\_COM2)



Signal	PIN	PIN	Signal
NDCD#_2_H	1	6	NDSR#_2_H
NRXD_2_H	2	7	NRTS#_2_H
NTXD_2_H	3	8	NCTS#_2_H
NDTR#_2_H	4	9	NRI#_2_H
GND	5		



## 2.14 ARC-BYT DB-K Connectors settings

### 2.14.1 Serial Port 1 connector (I\_COM1)



Signal	PIN	PIN	Signal
NDCD#_1_I	1	6	NDSR#_1_I
NRXD_1_I	2	7	NRTS#_1_I
NTXD_1_I	3	8	NCTS#_1_I
NDTR#_1_I	4	9	NRI#_1_I
GND	5		

### 2.14.2 Serial Port 2 connector (I\_COM2)



Signal	PIN	PIN	Signal
NDCD#_2_I	1	6	NDSR#_2_I
NRXD_2_I	2	7	NRTS#_2_I
NTXD_2_I	3	8	NCTS#_2_I
NDTR#_2_I	4	9	NRI#_2_I
GND	5		

# 3. Installation



## Removing the Top Cover Warning

To prevent electric shock or system damage, before removing the chassis cover, must turn off power and disconnect the unit from power source.

Electrostatic discharge (ESD) can cause serious damage to electronic components. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the product is accessed internally, or any other electrical component is handled, the following anti-static precautions are strictly adhered to:



- Wear an anti-static wristband: Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- Self-grounding: Before handling the board, touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- Use an anti-static pad: When configuring the product, place it on an anti-static pad. This reduces the possibility of ESD damaging the product.
- Only handle the edges of the PCB: When handling the PCB, hold the PCB by the edges.

## Installation Precautions


When installing the flat bezel panel PC, please follow the precautions listed below:

- Power turned off: When installing the flat bezel panel PC, make sure the power is off. Failing to turn off the power may cause severe injury to the body and/or damage to the system.
- Certified Engineers: Never open the equipment. For safety reasons, the equipment should be opened only by qualified skilled person.
- Anti-static Discharge: If a user open the rear panel of the flat bezel panel PC, to configure the jumpers or plug in added peripheral devices, ground themselves first and wear an anti-static wristband.

### 3.1 Installing Hard Disk & Memory




**Step 1. Memory Installation:** Remove 3 screws to release the chassis cover, and remove it.




**Step 2.1** Insert the SODIMM into the memory socket.

**Step 2.2** Re-assemble your system back through previous steps to complete the installation.




**Step 3. HDD Installation:** Insert the HDD into the Drive Bay and fasten 2 screws.


## 3.2 Installing ARC-BYT DB



**Step 1.** Unfasten 2 screws of the HDD bracket and take it off.



**Step 2.** Remove 4 screws to release the chassis cover, and remove it.



**Step 3.1** Insert the ARC-BYT DB into the socket and fasten 3 screws.

**Step 3.2** Re-assemble your system back through previous steps to complete the installation.

### 3.3 System Mounting

**Warning!** *More than one person should participate in mounting the panel PC to prevent accidental damage to the panel or personal injury.*



#### Safety Precautions

Observe the following common safety precautions before installing any electronic device:


- Use separate, non-intersecting paths to route power and networking wires. If power wiring and device wiring paths must be crossed make sure the wires are perpendicular at the intersection point.
- Keep the wires separated according to the interface. Wires that share similar electrical characteristics must be bundled together.
- Do not bundle input wiring with output wiring. Keep them separate.
- When necessary, it is strongly advised that you label wiring to all devices in the system.

The panel PC supports various mounting options, as listed below.


- Wall mounting (ACC-RITYVESA-B075R, Demonstration only)
- Arm/ Stand mounting (ACC-ARM-D41R, Demonstration only)
- Panel mounting (Use LPC-10 WMB version for demonstration)
- VESA mounting (Screws in the package)

### 3.3.1 Wall Mounting

To mount the panel PC onto wall, follow the instruction below (see Figure for addition reference).




**Step 1.** Insert four M4 screws into the VESA holes on the panel PC and tighten them to secure the bracket to the rear panel, ensure that the thread depth of the screws on the rear panel does not exceed 4mm.



**Step 2.** Select the location on the wall for the wall mount plate, secure the mount plate to the wall by inserting four M5 screws into pilot holes and tightening them.

# ARC-10W37



### MAIN PARTS

ITEM	1	2	3
PARTS			
QTY	1	1	2

### PARTS FOR TV BRACKETS

ITEM	4
PARTS	
QTY	4


### PARTS FOR WALL BRACKETS

ITEM	5	6
PARTS		
QTY	4	4

**Step 3.** To mount the panel PC on the wall, align the wall mount bracket attached to the panel PC with the wall mount plate on the wall and slide the panel PC downwards to hang the bracket on the mount plate. Secure the panel PC in place by tightening screws in the wall mount bracket.

### 3.3.2 ARM/ Stand Mounting

This Panel PC can be mounted on a VESA-compliant arm mount with a 100mm interface pad. To affix the panel PC to an arm mount, follow the steps below.




**Step 1.** Refer to the installation instruction of mounting arm/ stand to correctly assembly the arm/ stand onto the surface as a base.

**Step 2.** Align the retention screw holes on the mounting arm interface with VESA holes in the panel PC and secure the panel PC with four M4 retention screws. Ensure that the thread depth of the screws on the rear panel does not exceed 4mm.


**3.3.3 Panel Mounting**

To mount the flat bezel panel PC into a panel, follow the steps below.


1. Prepare a panel cutout according to the panel PC dimensions. For the panel cutout dimension, please refer to “System Dimensions” section in this manual.




2. Install the panel PC in the cabinet and retrieve hook brackets from the accessory box.



3. Insert the hook brackets into the holes following the direction of the arrows shown in below figure and hang the panel PC.




4. Tighten the screws to affix the panel PC in place, fasten all the hook bracket to ensure panel PC well fix at cabinet.  
(Different size panel PC come with different quantities mounting brackets and screws.)



### 3.3.4 VESA Mounting

The following picture indicates VESA mounting hole pattern (75x75 / 100x100 mm) on this Panel PC. VESA mount is a widely used mounting solution suitable for all kinds of industrial applications.



# 4. Drivers Installation

All the drivers are available on Avalue Downloads Area (<https://www.avaluetech.com/en/support/download>). Type the model name and press Enter to find all the relevant software, utilities, and documentation.

## Note:

The panel PC with projected capacitive type touchscreen and Windows 7 (or later) OS does not require touch driver installation. This is because there is a HID touch digitizer built-in driver in Windows 7 or later.

Chipset <sup>1</sup> Audio <sup>1</sup> Graphics <sup>1</sup> LAN <sup>1</sup> Other <sup>1</sup>

### Chipset

Total 1 Files

No.	Release Date	Title	Description	Download
01	2023-09-20	Intel Chipset Driver for Win10 x64	Windows 10 64bit	

### Audio

Total 1 Files

No.	Release Date	Title	Description	Download
01	2023-09-20	Realtek Audio Driver for Win10 x64	Windows 10 64bit	



**Note:** Installation procedures and screen shots in this section are for your reference and may not be exactly the same as shown on your screen.

## 4.1 Install Chipset Driver

All drivers can be found on the Avalue Official Website:

[www.avalue.com](http://www.avalue.com).



**Note:** The installation procedures and screen shots in this section are based on Windows 11 operation system. If the warning message appears while the installation process, click Continue to go on.



**Step 3. Click Install.**



**Step1. Click Next.**



**Step 4. Click Finish to complete setup.**



**Step 2. Click Accept.**


## 4.2 Install VGA Driver

All drivers can be found on the Avalue Official Website:

[www.avalue.com](http://www.avalue.com).




**Note:** The installation procedures and screen shots in this section are based on Windows 11 operation system. If the warning message appears while the installation process, click Continue to go on.




**Step 3. Click Start.**



**Step 1. Click Begin installation.**



**Step 4. Click Finish to complete setup.**




**Step 2.**  
Click **I agree** to accept license agreement.

## 4.3 Install ME Driver


All drivers can be found on the Avalue Official Website:  
[www.avalue.com](http://www.avalue.com).




**Note:** The installation procedures and screen shots in this section are based on Windows 11 operation system. If the warning message appears while the installation process, click Continue to go on.




**Step 1. Click Next** to continue setup.



**Step 2. Click Next.**



**Step 3. Click Next.**



**Step 4. Click Finish** to complete setup.

## 4.4 Install Serial IO Driver


All drivers can be found on the Avalue Official Website:  
[www.avalue.com](http://www.avalue.com).



**Note:** The installation procedures and screen shots in this section are based on Windows 11 operation system. If the warning message appears while the installation process, click Continue to go on.



**Step 3. Click Next.**



**Step 1. Click Next.**



**Step 4. Click Next.**



**Step 2. Click Next.**



**Step 5. Click Finish to complete setup.**

## 4.5 Install Audio Driver (For Realtek ALC888S)


All drivers can be found on the Avalue Official Website:

[www.avalue.com](http://www.avalue.com).




**Note:** The installation procedures and screen shots in this section are based on Windows 11 operation system.

### Realtek Audio Driver 6.0.9497.1



**Step 3. Installing.**




**Step 1. Installing Drivers.**

### Realtek Audio Driver 6.0.9497.1



**Step 4. Click Finish to complete setup.**

### Realtek Audio Driver 6.0.9497.1



**Step 2. Click Next.**

## 4.6 Install LAN Driver


All drivers can be found on the Avalue Official Website:  
[www.avalue.com](http://www.avalue.com).



**Note:** The installation procedures and screen shots in this section are based on Windows 11 operation system. If the warning message appears while the installation process, click Continue to go on.




**Step 3.** Installing Drivers.



**Step 1.** Installing Drivers.



**Step 4.** Complete setup.



**Step 2.** Click **OK**.

# 5. BIOS Setup

---

## 5.1 Introduction

The BIOS setup program allows users to modify the basic system configuration. In this following chapter will describe how to access the BIOS setup program and the configuration options that may be changed.

## 5.2 Starting Setup

The AMI BIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the NVRAM and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing <Del> or <F2> immediately after switching the system on, or

By pressing the <Del> or <F2> key when the following message appears briefly at the left-top of the screen during the POST (Power On Self Test).

**Press <Del> or <F2> to enter SETUP**

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to.

**Press F1 to Continue, DEL to enter SETUP**

## 5.3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Button	Description
↑↓→←	Move
Enter	Select
+/-	Value
Esc	Exit
F1	General Help
F2	Previous Values
F3	Optimized Defaults
F4	Save & Exit Setup
<K>	Scroll help area upwards
<M>	Scroll help area downwards

- **Navigating Through The Menu Bar**

Use the left and right arrow keys to choose the menu you want to be in.



**Note:** Some of the navigation keys differ from one screen to another.

- **To Display a Sub Menu**

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “>” pointer marks all sub menus.

## 5.4 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or <Enter> key.

## 5.5 In Case of Problems

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AMI BIOS supports an override to the NVRAM settings which resets your system to its defaults.


The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both BIOS Vendor and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

## 5.6 BIOS setup

Once you enter the Aptio Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

### 5.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.



### 5.6.1.1 System Language

This option allows choosing the system default language.

### 5.6.1.2 System Date

Use the system date option to set the system date. Manually enter the month, day and year.

### 5.6.1.3 System Time

Use the system time option to set the system time. Manually enter the hours, minutes and seconds.




**Note:** The BIOS setup screens shown in this chapter are for reference purposes only, and may not exactly match what you see on your screen.

Visit the Avalue website ([www.avalu.com](http://www.avalu.com)) to download the latest product and BIOS information.


## 5.6.2 Advanced Menu

This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.




### 5.6.2.1 CPU Configuration

Use the CPU configuration menu to view detailed CPU specification and configure the CPU.



Item	Options	Description
<b>Intel (VMX) Virtualization Technology</b>	Disabled Enabled[Default]	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.
<b>Active Processor Cores</b>	All[Default] 1 2 3	Number of cores to enable in each processor package.


### 5.6.2.1.1 Efficient-core Information



### 5.6.2.2 Power & Performance




5.6.2.2.1 CPU – Power Management Control




Item	Option	Description
Intel® SpeedStep™	Enabled[Default], Disabled	Allows more than two frequency ranges to be supported.
Intel® Speed Shift Technology	Enabled[Default], Disabled	Enable/Disable Intel® Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.
Turbo Mode	Enabled[Default], Disabled	Enable/Disable processor Turbo Mode (requires EMTTM enabled too). AUTO means enabled.
C States	Enabled[Default], Disabled	Enable/Disable CPU Power Management.

5.6.2.2.1.1 View/Configure Turbo Options



### 5.6.2.3 PCH-FW Configuration



Item	Option	Description
ME State	Disabled Enabled[Default]	When Disabled ME will be put into ME Temporarily Disabled Mode.

#### 5.6.2.3.1 Firmware Update Configuration



Item	Option	Description
ME FW Image Re-Flash	Disabled[Default], Enabled	Enable/Disable Me FW Image Re-Flash function.

5.6.2.3.2 PTT Configuration




Item	Option	Description
<b>TPM Device Selection</b>	dTPM[Default], PTT	Selects TPM device: PTT or dTPM. PTT-Enables PTT in SkuMgr dTPM 1.2-Disables PTT in SkuMgr Warning! PTT/dTPM will be disabled and all data saved on it will be lost.

5.6.2.4 Trusted Computing



Item	Options	Description
<b>Security Device Support</b>	Disable, Enable[Default]	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.


### 5.6.2.5 APCI Settings



Item	Options	Description
<b>Enable Hibernation</b>	Disabled Enabled <b>[Default]</b> ,	Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may not be effective with some OS.
<b>ACPI Sleep State</b>	Suspend Disabled, S3 (Suspend to RAM) <b>[Default]</b>	Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed.

### 5.6.2.6 IT5782 Super IO Configuration

You can use this item to set up or change the IT5782 Super IO configuration for serial ports. Please refer to 5.6.2.6.1 ~ 5.6.2.6.5 for more information.



Item	Description
<b>Serial Port 1 Configuration</b>	Set Parameters of Serial Port 1 (COMA).
<b>Serial Port 2 Configuration</b>	Set Parameters of Serial Port 2 (COMB).
<b>Serial Port 3 Configuration</b>	Set Parameters of Serial Port 3 (COMC).
<b>Serial Port 4 Configuration</b>	Set Parameters of Serial Port 4 (COMD).
<b>Serial Port 5 Configuration</b>	Set Parameters of Serial Port 5 (COME).

### 5.6.2.6.1 Serial Port 1 Configuration




Item	Option	Description
<b>Serial Port</b>	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
<b>UART 232 422 485</b>	UART 232[Default] UART 422 UART 485	Change the Serial Port as RS232/422/485.

### 5.6.2.6.2 Serial Port 2 Configuration




Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).


### 5.6.2.6.3 Serial Port 3 Configuration




### 5.6.2.6.4 Serial Port 4 Configuration



### 5.6.2.6.5 Serial Port 5 Configuration



5.6.2.7 HW Monitor



5.6.2.8 S5 RTC Wake Settings



Item	Options	Description
Wake system from S5	Disabled[Default], Fixed Time Dynamic Time	Enable or disable System wake on alarm event. Select Fixed Time, system will wake on the hr::min::sec specified. Select Dynamic Time, System will wake on the current time + Increase minute(s).


### 5.6.2.9 Serial Port Console Redirection



Item	Options	Description
Console Redirection	Disabled[Default], Enabled	Console Redirection Enable or Disable.
Console Redirection EMS	Disabled[Default], Enabled	Console Redirection Enable or Disable.

### 5.6.2.10 USB Configuration


The USB Configuration menu helps read USB information and configures USB settings.



## Quick Reference Guide

Item	Options	Description
<b>XHCI Hand-off</b>	Enabled[Default] Disabled	This is a workaround for OSES without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
<b>USB Mass Storage Driver Support</b>	Enabled[Default] Disabled	Enable/Disable USB Mass Storage Driver Support.
<b>USB transfer time-out</b>	1 sec 5 sec 10 sec 20 sec[Default]	The time-out value for Control, Bulk, and Interrupt transfers.
<b>Device reset time-out</b>	10 sec 20 sec[Default] 30 sec 40 sec	USB mass storage device Start Unit command time-out.
<b>Device power-up delay</b>	Auto[Default] Manual	Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100ms, for a Hub port the delay is taken from Hub descriptor.
<b>Mass Storage Devices</b>	Auto[Default] Floppy Forced FDD Hard Disk CD-ROM	Mass storage device emulation type. 'AUTO' enumerates devices according to their media format. Optical drives are emulated as 'CDROM', drives with no media will be emulated according to a drive type.

### 5.6.2.11 Network Stack Configuration




Item	Options	Description
<b>Network Stack</b>	Enabled Disabled[Default]	Enable/Disable UEFI Network Stack.


### 5.6.2.12 NVMe Configuration



### 5.6.3 Chipset




### 5.6.3.1 System Agent (SA) Configuration




Item	Option	Description
VT-d	Enabled[Default] Disabled	VT-d capability.

#### 5.6.3.1.1 Memory Configuration



5.6.3.1.2 Graphics Configuration




Item	Option	Description
GTT Size	2MB	Select the GTT Size.
	4MB	
	8MB[Default]	
Aperture Size	128MB	Select the Aperture Size. Note: Above 4GB MMIO BIOS assignment is automatically enabled when selecting > 2048MB aperture. To use this feature, please disable CSM Support.
	256MB[Default]	
	512MB	
	1024MB	

5.6.3.2 PCH-IO Configuration



### 5.6.3.2.1 PCI Express Configuration




#### 5.6.3.2.1.1 PCI Express Root Port 4 (M.2 KeyE)



Item	Option	Description
<b>PCI Express Root Port 4 (M.2 KeyE)</b>	Enabled[Default], Disabled	Control the PCI Express Root Port.
<b>ASPM</b>	Disabled[Default], L1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
<b>L1 Substates</b>	Disabled[Default] L1.1	PCI Express L1 Substates settings.


	L1.1 & L1.2	
<b>PTM</b>	Disabled <b>[Default]</b> , Enabled	Enable/Disable Precision Time Measurement.
<b>PCIe Speed</b>	Auto <b>[Default]</b> Gen1 Gen2 Gen3	Configure PCIe Speed.

5.6.3.2.1.2 PCI Express Root Port 7 (LAN1-I226)




Item	Option	Description
<b>PCI Express Root Port 7 (LAN1-I226)</b>	Enabled <b>[Default]</b> , Disabled	Control the PCI Express Root Port.
<b>ASPM</b>	Disabled <b>[Default]</b> , L1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
<b>L1 Substates</b>	Disabled <b>[Default]</b> L1.1 L1.1 & L1.2	PCI Express L1 Substates settings.
<b>PTM</b>	Disabled <b>[Default]</b> , Enabled	Enable/Disable Precision Time Measurement.
<b>PCIe Speed</b>	Auto <b>[Default]</b> Gen1 Gen2 Gen3	Configure PCIe Speed.

### 5.6.3.2.1.3 PCI Express Root Port 9 (B2B)




Item	Option	Description
<b>PCI Express Root Port 9 (B2B)</b>	Enabled[Default], Disabled	Control the PCI Express Root Port.
<b>ASPM</b>	Disabled[Default], L1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
<b>L1 Substates</b>	Disabled[Default] L1.1 L1.1 & L1.2	PCI Express L1 Substates settings.
<b>PTM</b>	Disabled[Default], Enabled	Enable/Disable Precision Time Measurement.
<b>PCIe Speed</b>	Auto[Default] Gen1 Gen2 Gen3	Configure PCIe Speed.

5.6.3.2.1.4 PCI Express Root Port 10 (LAN2-I226)



Item	Option	Description
<b>PCI Express Root Port 10 (LAN2-I226)</b>	Enabled[Default], Disabled	Control the PCI Express Root Port.
<b>ASPM</b>	Disabled[Default], L1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
<b>L1 Substates</b>	Disabled[Default] L1.1 L1.1 & L1.2	PCI Express L1 Substates settings.
<b>PTM</b>	Disabled[Default], Enabled	Enable/Disable Precision Time Measurement.
<b>PCIe Speed</b>	Auto[Default] Gen1 Gen2 Gen3	Configure PCIe Speed.

### 5.6.3.2.2 SATA Configuration




Item	Options	Description
SATA Controller(s)	Enabled[Default] Disabled,	Enable/Disable SATA Device.
Port 0/1	Disabled Enabled[Default]	Enable or Disable SATA Port.

### 5.6.3.2.3 HD Audio Configuration



Item	Option	Description
HD Audio	Disabled Enabled[Default]	Control Detection of the HD-Audio device. Disable = HDA will be unconditionally disabled Enabled = HDA will be unconditionally enabled.


5.6.3.3 Board & Panel Configuration



Item	Option	Description
<b>CH7513 EDID Panel Option</b>	1024x768 24/1 800x600 18/1 1024x768 18/1 1366x768 18/1 1024x600 18/1 <b>1280x800 24/1 [Default]</b> 1920x1200 24/2 1920x1080 18/2 1280x1024 24/2 1440x900 18/2 1600x1200 24/2 1366x768 24/1 1920x1080 24/2 7513-eDP	Port-EDP to LVDS(Chrotel 7513) Panel EDID Option.
<b>ErP Function</b>	Disabled <b>[Default]</b> Enabled	ErP Function (Deep S5).
<b>PWR-On After PWR-Fail</b>	Off <b>[Default]</b> On Last state	AC loss resume.
<b>Wake Up by Ring</b>	Disabled Enabled <b>[Default]</b>	Wake Up by Ring from S3/S4/S5.
<b>Watch Dog</b>	Disabled <b>[Default]</b> 30 sec 40 sec 50 sec 1 min 2 min 10 min 30 min	Select WatchDog.

<b>USB Standby Power</b>	Disabled Enabled[ <b>Default</b> ]	Enables/Disabled USB Standby Power during S3/S4/S5.
<b>Onboard USB Touch(Penmount6000)</b>	Disabled[ <b>Default</b> ] Enabled	Onboard USB Touch(Penmount6000) Enabled/Disabled.
<b>M.2 KeyB P38 Setting</b>	Low[ <b>Default</b> ] High	Set M.2 KeyB Pin38(DEVSLP) as Low/High.
<b>SHOW DMI INFO</b>	Disabled[ <b>Default</b> ] Enabled	SHOW DMI INFO.

### 5.6.4 Security



- **Administrator Password**


Set setup Administrator Password

- **User Password**


Set User Password

# ARC-10W37

## 5.6.4.1 Secure Boot





## 5.6.5 Boot



Item	Option	Description
Setup Prompt Timeout	1~ 65535	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
Bootup NumLock State	On[Default] Off	Select the keyboard NumLock state
Quiet Boot	Disabled[Default] Enabled	Enables or disables Quiet Boot option
Boot Option #1/2	Set the system boot order.	

## 5.6.6 Save and exit



### 5.6.6.1 Save Changes and Reset

Reset the system after saving the changes.

### 5.6.6.2 Discard Changes and Reset

Reset system setup without saving the changes.

## **ARC-10W37**

### **5.6.6.3 *Restore Defaults***

Restore/Load Default values for all the setup options.

### **5.6.6.4 *Launch EFI Shell from filesystem device***

Attempts to Launch EFI Shell application (Shellx64.efi) from one of the available filesystem devices.

# 6. Maintenance & Troubleshooting

---

## System Maintenance Introduction

If the components of the product fail they must be replaced.

Please contact the system reseller or vendor to purchase the replacement parts. Please follow the safety precautions outlined in the sections that follow:

## General Safety Precautions

Please ensure the following safety precautions are adhered to at all times.

1. Follow the electrostatic precautions outlined below whenever the device is opened.
2. Make sure the power is turned off and the power cord is disconnected whenever the product is being installed, moved or modified.
3. To prevent the risk of electric shock, make sure power cord is unplugged from wall socket. To fully disengage the power to the unit, please disconnect the power cord from the AC outlet. Refer servicing to qualified service personnel. The AC outlet shall be readily available and accessible.
4. Do not apply voltage levels that exceed the specified voltage range. Doing so may cause fire and/or an electrical shock. Use a power cord that matches the voltage of the power outlet, which has been approved and complies with the safety standard of your particular country.
5. Electric shocks can occur if the product chassis is opened when it is running. To avoid risk of electric shock, this device must only be connected to a supply mains with protective earth.
6. Do not drop or insert any objects into the ventilation openings of the product.
7. If considerable amounts of dust, water, or fluids enter the device, turn off the power supply immediately, unplug the power cord, and contact your dealer or the nearest service center.
8. This equipment is not suitable for use in locations where children are likely to be present.
9. DO NOT:
  - Drop the device against a hard surface.
  - Strike or exert excessive force onto the LCD panel.
  - Touch any of the LCD panels with a sharp object.
  - In a site where the ambient temperature exceeds the rated temperature.

## Anti-Static Precautions

### **WARNING:**

Failure to take ESD precautions during the installation of the product may result in permanent damage to the product and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the product. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the product is opened and any of the electrical components are handled, the following anti-static precautions are strictly adhered to.

- Wear an anti-static wristband: Wearing a simple anti-static wristband can help to prevent ESD from damaging any electrical component.
  - Self-grounding: Before handling any electrical component, touch any grounded conducting material. During the time the electrical component is handled, frequently touch any conducting materials that are connected to the ground.
  - Use an anti-static pad: When configuring or working with an electrical component, place it on an anti-static pad. This reduces the possibility of ESD damage.
  - Only handle the edges of the electrical component. When handling the electrical component, hold the electrical component by its edges. Please ensure the following safety precautions are adhered to at all times.
1. Follow the electrostatic precautions outlined below whenever the device is opened.
  2. Make sure the power is turned off and the power cord is disconnected

## Maintenance and Cleaning

When maintaining or cleaning the product, please follow the guidelines below.

### **WARNING:**

- For safety reasons, turn-off the power and unplug the panel PC before cleaning.
- If you dropped any material or liquid such as water onto the panel PC when cleaning, unplug the power cable immediately and contact your dealer or the nearest service center. Always make sure your hands are dry when unplugging the power cable.

### Maintenance and Cleaning

Prior to cleaning any part or component of the product, please read the details below.

- Except for the LCD panel, never spray or squirt liquids directly onto any other components. To clean the LCD panel, gently wipe it with a piece of soft dry cloth or a slightly moistened cloth.
- The interior of the device does not require cleaning. Keep fluids away from the device interior.
- Be cautious of all small removable components when vacuuming the device.
- Never drop any objects or liquids through the openings of the device.
- Be cautious of any possible allergic reactions to solvents or chemicals used when cleaning the device.
- Avoid eating, drinking and smoking within vicinity of the device.

## Cleaning Tools

Some components in the panel PC may only be cleaned using a product specifically designed for the purpose. In such case, the product will be explicitly mentioned in the cleaning tips. Below is a list of items to use when cleaning the panel PC.

- Cloth: Although paper towels or tissues can be used, a soft, clean piece of cloth is recommended when cleaning the device.
- Water or rubbing alcohol: A cloth moistened with water or rubbing alcohol can be used to clean the device.
- Using solvents: The use of solvents is not recommended when cleaning the device as they may damage the plastic parts.
- Vacuum cleaner: Using a vacuum specifically designed for computers is one of the best methods of cleaning the device. Dust and dirt can restrict the airflow in the device and cause its circuitry to corrode.
- Cotton swabs: Cotton swabs moistened with rubbing alcohol or water are excellent tools for wiping hard to reach areas.
- Foam swabs: Whenever possible, it is best to use lint free swabs such as foam swabs for cleaning.

## Basic Troubleshooting

### PEI Beep Codes

# of Beeps	Description
1	Memory not Installed
2	Recovery started
3	Typically for development use. The beep code is generated when DXE IPL PPI or DXE Core is not found.
4	Recovery failed
4	S3 Resume failed
7	Typically for development use. The beep code is generated when platform cannot be reset because reset PPI is not available.

### DXE Beep Codes

# of Beeps	Description
1	Invalid password
4	Typically for development use. The beep code is generated when some of the Architectural Protocols are not available.
5	No Console Input or Output Devices are found
5	No Console Input Devices are found
6	Flash update is failed
7	Typically for development use. The beep code is generated when platform cannot be reset because reset protocol is not available.
8	Platform PCI resource requirements cannot be met

# 7. Product Application

---

For detailed instructions on the operation of the Watchdog Timer and Digital I/O (DIO) features of this Panel PC, please refer to the comprehensive guide available in the "AvalueIOAPI" manual. Please reaching out to your respective distributors, Avalue technical support team, or Avalue customer service representatives for further information. Feel free to inquire about this supplementary resource to enhance your understanding of the Watchdog Timer and Digital I/O (DIO) Application for optimal utilization of your Panel PC.

# 8. Operating the Device

---

The Multi-Touch mode was pre-installed on the Panel PC and need tools for any customizations. Should you have specific requirements or encounter scenarios where a customized touch mode is necessary, we recommend reaching out to your local distributors, Avalue technical support team, or Avalue customer service representatives. These professionals can provide tailored guidance and assistance to address any unique needs related to Multi-Touch mode adjustments.