

# **MI1002AF**

**Intel® 14th Gen Core™ Ultra 7/5/3  
Mini-ITX Motherboard**

## **User's Manual**

Version 1.0  
(October 2024)

## **Copyright**

© 2024 IBASE Technology, Inc. All rights reserved.

No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of IBASE Technology, Inc. (hereinafter referred to as "IBASE").

## **Disclaimer**

IBASE reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, IBASE does not guarantee this document is error-free.

IBASE assumes no liability for incidental or consequential damages arising from misapplication or inability to use the product or the information contained herein, nor for any infringements of rights of third parties, which may result from its use.

## **Trademarks**

All the trademarks, registrations and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

## Compliance



This product complies with **CE and FCC Class B requirements**. In residential areas, additional measures may be required if radio interference is detected. This product has been tested for environmental specifications and limits and complies with the directives of the European Union (EU). Users should also follow local regulations to prevent any interference or disruptions caused by the product's operation.



This product has been tested and found to comply with the limits for a Class B device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications.

### WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive of for waste electrical and electronic equipment (WEEE - 2012/19/EU). Instead, it should be disposed of by returning it to a municipal recycling collection point. Check local regulations for disposal of electronic products.

### Green IBASE



This product complies with RoHS 2 restrictions, restricting the use of hazardous substances in electrical and electronic equipment. The following substances must not exceed the specified concentrations:

- Hexavalent chromium: 1,000 ppm
- Poly-brominated biphenyls (PBBs): 1,000 ppm
- Poly-brominated diphenyl ethers (PBDEs): 1,000 ppm
- Cadmium: 100 ppm
- Mercury: 1,000 ppm
- Lead: 1,000 ppm
- Bis(2-ethylhexyl) phthalate (DEHP): 1,000 ppm
- Butyl benzyl phthalate (BBP): 1,000 ppm
- Dibutyl phthalate (DBP): 1,000 ppm
- Diisobutyl phthalate (DIBP): 1,000 ppm

## Important Safety Information

Carefully read the precautions before using the board.

### Environmental conditions:

- Use this product in environments where the ambient temperature ranges as between 0°C and 60°C.

### Care for your iBASE products:

- Before cleaning the PCB, unplug all cables and remove the battery.
- Clean the PCB with a circuit board cleaner or degreaser, or use cotton swabs and alcohol.
- Use a computer vacuum cleaner to remove dust and prevent the fan from being clogged.



### WARNING

### Attention during use:

- Do not use this product near water.
- Do not spill water or any other liquids on this product.
- Do not place heavy objects on the top of this product.

### Anti-static precautions

- Wear an anti-static wrist strap to avoid electrostatic discharge.
- Place the PCB on an anti-static kit or mat.
- Hold the edges of PCB when handling.
- Touch the edges of non-metallic components of the product instead of the surface of the PCB.
- Touch a grounded metal surface, such as an unpainted metal part of your computer case, to discharge static electricity.



### CAUTION

Danger of explosion if the internal lithium-ion battery is replaced by an incorrect type. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to local recycling laws and the manufacturer's instructions.

## Warranty Policy

- **IBASE standard products:**

24-month (2-year) warranty from the date of shipment. If the date of shipment cannot be ascertained, the product serial numbers can be used to determine the approximate shipping date.

- **3<sup>rd</sup>-party parts:**

12-month (1-year) warranty from delivery for the 3<sup>rd</sup>-party parts that are not manufactured by IBASE, such as CPU, CPU cooler, memory, storage devices, power adapter, panel and touchscreen.

- \* PRODUCTS, HOWEVER, THAT FAIL DUE TO MISUSE, ACCIDENT, IMPROPER INSTALLATION OR UNAUTHORIZED REPAIR SHALL BE TREATED AS OUT OF WARRANTY AND CUSTOMERS SHALL BE BILLED FOR REPAIR AND SHIPPING CHARGES.

## Technical Support & Services

1. Visit the IBASE website at [www.ibase.com.tw](http://www.ibase.com.tw) to find the latest information about the product.
2. If you need any further assistance from your distributor or sales representative, prepare the following information of your product and elaborate upon the problem.
  - Product model name
  - Product serial number
  - Detailed description of the problem
  - The error messages in text or in screenshots if there is any
  - The arrangement of the peripherals
  - Software in use (such as OS and application software, including the version numbers)
3. To apply for an RMA number, please visit the IBASE website to complete a request form.

# Table of Contents

---

|                  |   |           |
|------------------|---|-----------|
| <b>Chapter 1</b> | <b>General Information .....</b>                        | <b>1</b>  |
| 1.1              | Introduction .....                                      | 2         |
| 1.2              | Features.....   | 2         |
| 1.3              | Packing List .....                                      | 3         |
| 1.4              | Optional Accessories .....                              | 3         |
| 1.5              | Specifications.....                                     | 4         |
| 1.6              | Block Diagram .....                                     | 6         |
| 1.7              | Product View.....                                       | 7         |
| 1.8              | Board Dimensions .....                                  | 10        |
| <b>Chapter 2</b> | <b>Hardware Configuration .....</b>                     | <b>11</b> |
| 2.1              | Essential Installations .....                           | 12        |
| 2.2              | Setting the Jumpers.....                                | 13        |
| 2.3              | Jumper & Connector Locations .....                      | 14        |
| 2.4              | Jumpers Quick Reference .....                           | 15        |
| 2.4.1            | Clear CMOS Contents (JBAT1) .....                       | 15        |
| 2.4.2            | Clear ME Contents (JME1) .....                          | 16        |
| 2.4.3            | ATX & AT Power Mode Selection (JP1).....                | 16        |
| 2.4.4            | Sierra EM9191 5G Card USB/PCIe Select (JP3).....        | 17        |
| 2.5              | Connectors Quick Reference.....                         | 18        |
| 2.5.1            | COM1 & COM2 RS-232/422/485 Ports (CN1) .....            | 19        |
| 2.5.2            | DisplayPort & HDMI Port (CN2) .....                     | 20        |
| 2.5.3            | USB Type-C Connector (CN3, CN5).....                    | 20        |
| 2.5.4            | 2.5 Gigabit LAN (Intel I226-V) + USB3.2 (CN4, CN6)..... | 21        |
| 2.5.5            | 2.5 Gigabit LAN (Intel I226-LM) + USB3.2 (CN7) .....    | 21        |
| 2.5.6            | HD Audio Connector (CN8).....                           | 21        |
| 2.5.7            | Front Panel Settings Connector (J3).....                | 22        |
| 2.5.8            | COM3 (J2) & COM4 (J5) RS-232 Ports .....                | 23        |
| 2.5.9            | DDR5 SO-DIMM Slot (J6 / J10) .....                      | 24        |
| 2.5.10           | SPI Flash Connector (J7) .....                          | 24        |
| 2.5.11           | 80 Port Debug (J8).....                                 | 25        |
| 2.5.12           | Digital I/O Connector (J11).....                        | 25        |
| 2.5.13           | M.2 M2280 Slot (J12).....                               | 26        |
| 2.5.14           | M.2 E2230 Slot (J13) .....                              | 26        |
| 2.5.15           | USB 2.0 Connector (J14, J15) .....                      | 27        |
| 2.5.16           | SIM Slot (J18) .....                                    | 28        |

|                  |  |           |
|------------------|--|-----------|
| 2.5.17           | M.2 B-key 3052 Slot (J19) .....                      | 28        |
| 2.5.18           | SATA Power Connector (J16) .....                     | 29        |
| 2.5.19           | Audio Pin Header for Chassis Front Panel (J22) ..... | 30        |
| 2.5.20           | DC-In Power Connector (J23) .....                    | 31        |
| 2.5.21           | SATA III Connector (SATA1, SATA2) .....              | 31        |
| 2.5.22           | Fan Power Connectors (CPU_FAN1, SYS_FAN1) .....      | 32        |
| 2.5.23           | PCIe (x4) Slot (PCIE1) .....                         | 32        |
| <b>Chapter 3</b> | <b>Drivers Installation .....</b>                    | <b>33</b> |
| 3.1              | Introduction .....                                   | 34        |
| 3.2              | Intel® Chipset Software Installation Utility .....   | 34        |
| 3.3              | VGA Driver Installation .....                        | 36        |
| 3.4              | Intel(R) Smartsound Drivers Installation .....       | 37        |
| 3.5              | HD Audio Driver Installation .....                   | 38        |
| 3.6              | LAN Driver Installation .....                        | 39        |
| 3.7              | Intel® ME Drivers Installation .....                 | 40        |
| 3.8              | Intel® Serial IO Drivers Installation .....          | 41        |
| 3.9              | Intel® PMT Drivers Installation .....                | 42        |
| 3.10             | Intel® NPU IO Drivers Installation .....             | 43        |
| <b>Chapter 4</b> | <b>BIOS Setup .....</b>                              | <b>45</b> |
| 4.1              | Introduction .....                                   | 46        |
| 4.2              | BIOS Setup .....                                     | 46        |
| 4.3              | Main Settings .....                                  | 47        |
| 4.4              | Advanced Settings .....                              | 48        |
| 4.5              | Security Settings .....                              | 61        |
| 4.6              | Boot Settings .....                                  | 62        |
| 4.7              | Save & Exit Settings .....                           | 63        |
| 4.8              | MEBx .....   | 64        |
| <b>Appendix</b>  | <b>.....</b>   | <b>65</b> |
| A.               | I/O Port Address Map .....                           | 66        |
| B.               | Interrupt Request Lines (IRQ) .....                  | 68        |
| C.               | Watchdog Timer Configuration .....                   | 69        |
| D.               | Onboard Connector Types .....                        | 73        |
| E.               | MI1002AF USB Power Control Bit Mapping. ....         | 74        |

This page is intentionally left blank.



# Chapter 1

## General Information

The information provided in this chapter includes:

- Features
- Packing List
- Optional Accessories
- Specifications
- Block Diagram
- Product View
- Board Dimensions

## 1.1 Introduction

The MI1002AF Mini ITX motherboard is based on Intel® Core Ultra 7/5/3 processors. With support for two DDR5 slots accommodating up to 64GB memory, it supports independent displays with HDMI (2.0a) and 1x DisplayPort(1.4a) (DP++) interface. This high-performance platform meets demands in next-generation applications in imaging, AI, and edge computing. Connectivity and expansion are provided by 3x Intel 2.5G LAN, 6x USB 3.x, 4x COM, 2x SATA III, 1x PCI-E (x4) [Gen. 4.0]; 3x M.2 (B-key, E-key and M-Key) .



## 1.2 Features

- Intel® Core Ultra 7/5/3 Processors
- 2x DDR5 SO-DIMM sockets, Max. 64GB
- Intel® processor integrated graphics supports HDMI (2.0a) and 1x DisplayPort (1.4a) (DP++)
- 3x Intel® 2.5G LAN
- 6x USB 3.x, 4x USB 2.0, 4x COM, 2x SATA III
- 1x PCI-E (x4) [Gen.4.0]; 3x M.2 (B-key, E-key and M-Key)
- Watchdog timer, Digital I/O, iAMT(18.0) , fTPM
- 12V~24V DC input

## 1.3 Packing List

Your MI1002AF package should include the items listed below. If any of the items below is missing, contact the distributor or dealer from whom you purchased the product.

- MI1002 x 1
- IO Shield x 1
- SATA cable x 1
- COM cable x 1
- USB 2.0 cable x 1

## 1.4 Optional Accessories

- Audio Cable
- Cooler
- 330W Power Adaptor  
(This is suitable for 45W TDP and 15W TDP CPU skus)
- 150W Power Adaptor (This is recommended to pair with 15W TDP CPU skus only)
- Power Cable

## 1.5 Specifications

| Model             |  |
|-------------------|--|
| MI1002AF          | LGA1851 Mini-ITX Motherboard w /HDMI, DisplayPort, 3 x 2.5GbE, 2 x SATA, iAMT (18.0), fTPM   |
| Specifications    |  |
| CPU Socket        | LGA1851  |
| CPU               | Gen Intel® Core™ Ultra 7/5/3 CPU   |
| Memory            | 2x DDR5 SO-DIMM sockets<br>Supports DDR5-5600 module, Max. 64GB  |
| BIOS              | AMI  |
| Watchdog Timer    | 256 levels   |
| Hardware Monitor  | Yes  |
| Storage Interface | SATA III & NVMe  |
| Expansion Slots   | 1x PCI-E (x4) [Gen.4.0]  |
| Mini Type Slots   | <ul style="list-style-type: none"> <li>• 1x M.2 (M-key, type:2280, PCI-E(4x) Gen.4)</li> <li>• 1x M.2 (E-Key, type:2230, USB 2.0 + PCI-E(1x))</li> <li>• 1x M.2 (B-Key, type:3052, USB 3.2 + PCI-E(1x))</li> </ul> |
| Graphics          | 14th Gen Intel Core Ultra 7/5/3 processor integrated   |
| Video Output      | 1x HDMI (2.0a) + 1x DisplayPort (1.4a) (DP++) + 2x USB Type-C (DP)   |
| Ethernet          | <ul style="list-style-type: none"> <li>• LAN 1: Intel® I226LM, supports 2.5G and iAMT</li> <li>• LAN 2: Intel® I226V, supports 2.5G only</li> <li>• LAN 3: Intel® I226V, supports 2.5G only</li> </ul>             |
| I/O Chipset       | Fintek F81964D-I   |
| Serial Port       | 4x COM ports : 2x RS232/422/485 + 2x RS232   |
| USB 2.0           | 4x USB 2.0 via pin header  |
| USB 3.X           | 4x USB 3.2 @ edge connector<br>2x USB Type-C @ edge connector  |
| Serial ATA        | 2x SATA III  |
| Audio             | Built-in HDA controller+Realtek ALC888S (7.1 ch.)  |
| TPM               | Supports fTPM  |
| Others            | 12V~24V DC-in, Digital I/O (4-in/4-out), SIM socket  |


| Physical                         |                            |
|----------------------------------|----------------------------|
| <b>Dimensions<br/>(L x W)</b>    | 170mm x 170mm (6.7"x 6.7") |
| Environmental                    |                            |
| <b>Operating<br/>Temperature</b> | 0 ~ 60 °C (32 ~ 140 °F)    |
| <b>Storage<br/>Temperature</b>   | -20 ~ 80 °C (-4 ~ 176 °F)  |


All specifications are subject to change without prior notice.



## 1.7 Product View


### Top View








## Rear View



| No.         | Function                                  |
|-------------|---|
| 1. CN1      | COM1 & COM2 RS-232/422/485 Ports          |
| 2. CN2      | DisplayPort & HDMI Port                   |
| 3. CN3, CN5 | USB Type-C Connector                      |
| 4. CN4, CN6 | 2.5 Gigabit LAN (Intel I226-V) + USB 3.2  |
| 5. CN7      | 2.5 Gigabit LAN (Intel I226-LM) + USB 3.2 |
| 6. CN8      | HD Audio Connector                        |

## 1.8 Board Dimensions



## Chapter 2

# Hardware Configuration

This section provides information on jumper settings and connectors on the MI1002A and other installation information in order to set up a workable system. The topics covered are:

- Essential installations
- Jumper and connector locations
- Jumper settings and information of connectors


## 2.1 Essential Installations

Follow the instructions below to install the memory modules.


### 2.1.1 Installing the Memory

To install the modules, locate the memory slot on the board and perform the following steps:

1. Align the key of the memory module with that on the memory slot and insert the module slantwise.



2. Gently push the module in an upright position until the clips of the slot close to hold the module in place when the module touches the bottom of the slot.




To remove the module, press the ejector tabs at both ends outwards.

## 2.2 Setting the Jumpers


Set up and configure your MI1002AF by using jumpers for various settings and features according to your needs and applications. Contact your supplier if you have doubts about the best configuration for your use.

### 2.2.1 How to Set Jumpers

Jumpers are short-length conductors consisting of several metal pins with a non-conductive base mounted on the circuit board. Jumper caps are used to have the functions and features enabled or disabled. If a jumper has 3 pins, you can connect either PIN1 to PIN2 or PIN2 to PIN3 by shorting.



A 3-pin jumper



A jumper cap


Refer to the illustration below to set jumpers.

| Pin closed | Oblique view | Illustration |
|------------|--------------|--------------|
| Open       |              | <br>1 2 3    |
| 1-2        |              | <br>1 2 3    |
| 2-3        |              | <br>1 2 3    |

When two pins of a jumper are encased in a jumper cap, this jumper is **closed**, i.e., turned **On**.

When a jumper cap is removed from two jumper pins, this jumper is **open**, i.e., turned **Off**.


## 2.3 Jumper & Connector Locations



## 2.4 Jumpers Quick Reference



| Jumper | Function                              |
|--------|---------------------------------------|
| JBAT1  | Clear CMOS                            |
| JME1   | Clear ME                              |
| JP1    | AT/ATX Select                         |
| JP3    | Sierra EM919x 5G card USB/PCIe Select |



### 2.4.1 Clear CMOS Contents (JBAT1)





| Function   | Pin closed | Illustration |
|------------|------------|--------------|
| Normal     | 1-2        | 1            |
| Clear CMOS | 2-3        | 1            |



2.4.2 Clear ME Contents (JME1)



| Function | Pin closed | Illustration  |
|----------|------------|---|
| Normal   | 1-2        |  |
| Clear ME | 2-3        |  |


2.4.3 ATX & AT Power Mode Selection (JP1)



| Function      | Pin closed | Illustration  |
|---------------|------------|---|
| ATX (default) | 1-2        |  |
| AT            | 2-3        |  |



### 2.4.4 Sierra EM9191 5G Card USB/PCIe Select (JP3)




| Function       | Pin closed | Illustration |
|----------------|------------|--------------|
| USB            | 1-2        | 1            |
| PCIe (default) | 2-3        | 1            |

## 2.5 Connectors Quick Reference

| Connector             | Function                                  |
|-----------------------|---|
| CN1                   | COM1 & COM2 RS-232/422/485 Ports          |
| CN2                   | DisplayPort & HDMI Port                   |
| CN3, CN5              | USB Type-C Connector                      |
| CN4                   | 2.5 Gigabit LAN (Intel I226-V) + USB 3.2  |
| CN6                   | 2.5 Gigabit LAN (Intel I226-LM) + USB 3.2 |
| CN7                   | 2.5 Gigabit LAN (Intel I226-V) + USB 3.2  |
| CN8                   | HD Audio Connector                        |
| J2, J5                | COM3 & COM4 RS-232 Ports                  |
| J3                    | Front Panel Settings Connector            |
| J6, J10               | DDR5 SO-DIMM Slots                        |
| J7                    | SPI Flash Connector (Factory use only)    |
| J8                    | 80 Port Debug (Factory use only)          |
| J11                   | Digital I/O Connector                     |
| J12                   | M.2 M2280 Slot                            |
| J13                   | M.2 E2230 Slot                            |
| J19                   | M.2 B-key 3052 Slot                       |
| J14, J15              | USB 2.0 Connector (DF11-8S-PA66H)         |
| J18                   | SIM Slot                                  |
| J16                   | SATA Power Connector                      |
| J22                   | Audio Pin Header for Chassis Front Panel  |
| J23                   | DC-In Power Connector                     |
| SATA1, SATA2          | SATA III Connectors                       |
| CPU_FAN1,<br>SYS_FAN1 | Fan Power Connectors                      |
| PCIE1                 | PCIe (x4) Slot                            |

## 2.5.1 COM1 &amp; COM2 RS-232/422/485 Ports (CN1)




| Pin | Signal Name              | Pin | Signal Name          |
|-----|--------------------------|-----|----------------------|
| 1   | DCD, Data carrier detect | 6   | DSR, Data set ready  |
| 2   | RXD, Receive data        | 7   | RTS, Request to send |
| 3   | TXD, Transmit data       | 8   | CTS, Clear to send   |
| 4   | DTR, Data terminal ready | 9   | RI, Ring indicator   |
| 5   | Ground                   |     |                      |


**COM1/COM2** RS-232/422/485 are jumperless, configurable in BIOS.

| Pin | Signal Name |        |        |
|-----|-------------|--------|--------|
|     | RS-232      | RS-422 | RS-485 |
| 1   | DCD         | TX-    | DATA-  |
| 2   | RX          | TX+    | DATA+  |
| 3   | TX          | RX+    | NC     |
| 4   | DTR         | RX-    | NC     |
| 5   | Ground      | Ground | Ground |
| 6   | DSR         | NC     | NC     |
| 7   | RTS         | NC     | NC     |
| 8   | CTS         | NC     | NC     |
| 9   | RI          | NC     | NC     |


**2.5.2 DisplayPort & HDMI Port (CN2)**




**2.5.3 USB Type-C Connector (CN3, CN5)**




## 2.5.4 2.5 Gigabit LAN (Intel I226-V) + USB3.2 (CN4, CN6)




## 2.5.5 2.5 Gigabit LAN (Intel I226-LM) + USB3.2 (CN7)



## 2.5.6 HD Audio Connector (CN8)



### 2.5.7 Front Panel Settings Connector (J3)



| Pin | Signal     | Pin | Signal     |
|-----|------------|-----|------------|
| 1   | Power BTN- | 2   | Power BTN+ |
| 3   | HDD LED+   | 4   | HDD LED-   |
| 5   | Reset BTN- | 6   | Reset BTN+ |
| 7   | Power LED+ | 8   | Power LED- |

J3 is utilized for system indicators to provide light indication of the computer activities and switches to change the computer status. It provides interfaces for the following functions:

**ATX Power ON Switch (Pins 1 and 2)**

The 2 pins make an “ATX Power Supply On/Off Switch” for the system that connects to the power switch on the case. When pressed, the power switch will force the system to power on. When pressed again, it will power off the system.

**Hard Disk Drive LED Connector (Pins 3 and 4)**

This connector connects to the hard drive activity LED on control panel. This LED will flash when the HDD is being accessed.


**Reset Switch (Pins 5 and 6)**

The reset switch allows you to reset the system without turning the main power switch off and then on again. Orientation is not required when making a connection to this header.

**Power LED (Pins 7 and 8)**


This connector connects to the system power LED on control panel. This LED will light when the system turns on.

## 2.5.8 COM3 (J2) &amp; COM4 (J5) RS-232 Ports




| Pin | Signal Name              | Pin | Signal Name              |
|-----|--------------------------|-----|--------------------------|
| 1   | DCD, Data carrier detect | 2   | RXD, Receive data        |
| 3   | TXD, Transmit data       | 4   | DTR, Data terminal ready |
| 5   | Ground                   | 6   | DSR, Data set ready      |
| 7   | RTS, Request to send     | 8   | CTS, Clear to send       |
| 9   | RI, Ring indicator       | 10  | Not Used                 |

## 2.5.9 DDR5 SO-DIMM Slot (J6 / J10)




## 2.5.10 SPI Flash Connector (J7)



Note: J7 is for factory use only.




### 2.5.11 80 Port Debug (J8)




Note: J8 is for factory use only.

### 2.5.12 Digital I/O Connector (J11)




| Pin | Signal | Pin | Signal    |
|-----|--------|-----|-----------|
| 1   | Ground | 2   | +5V(0.5A) |
| 3   | OUT3   | 4   | OUT1      |
| 5   | OUT2   | 6   | OUT0      |
| 7   | IN3    | 8   | IN1       |
| 9   | IN2    | 10  | IN0       |

**2.5.13 M.2 M2280 Slot (J12)**




\*J12 supports NVME

**2.5.14 M.2 E2230 Slot (J13)**



\*J13 supports USB2.0 & PCIE x1


### 2.5.15 USB 2.0 Connector (J14, J15)




\* Connector type: DF11-8S-PA66H

| Pin | Signal    | Pin | Signal    |
|-----|-----------|-----|-----------|
| 1   | VCC(0.5A) | 2   | Ground    |
| 3   | D0-       | 4   | D1+       |
| 5   | D0+       | 6   | D1-       |
| 7   | Ground    | 8   | VCC(0.5A) |

## 2.5.16 SIM Slot (J18)




## 2.5.17 M.2 B-key 3052 Slot (J19)




\*J19 supports Sierra EM9191 5G modules.

2.5.18 SATA Power Connector (J16)




| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1   | +5V         | 3   | Ground      |
| 2   | Ground      | 4   | +12V        |

**2.5.19 Audio Pin Header for Chassis Front Panel (J22)**




| Pin | Signal Name | Pin | Signal Name  |
|-----|-------------|-----|--------------|
| 1   | MIC IN_L    | 2   | Ground       |
| 3   | MIC IN_R    | 4   | DET          |
| 5   | LINE_R      | 6   | Sense Ground |
| 7   | Sense       | 8   | KEY          |
| 9   | LINE_L      | 10  | Sense Ground |

## 2.5.20 DC-In Power Connector (J23)




| Pin | Signal Name | Pin | Signal Name |
|-----|-------------|-----|-------------|
| 1   | Ground      | 2   | Ground      |
| 3   | +12 ~ +24V  | 4   | +12 ~ +24V  |

## 2.5.21 SATA III Connector (SATA1, SATA2)




2.5.22 Fan Power Connectors (CPU\_FAN1, SYS\_FAN1)



| Pin | Signal Name        |
|-----|--------------------|
| 1   | Ground             |
| 2   | +12V               |
| 3   | Rotation detection |
| 4   | Control            |

2.5.23 PCIe (x4) Slot (PCI1)





## Chapter 3

# Drivers Installation

This chapter introduces installation of the following drivers:

- Intel® Chipset Software Installation Utility
- HD Graphics Drivers
- Smartsound Drivers
- HD Audio Drivers
- LAN Drivers
- Intel® ME Drivers
- Intel® Serial I/O Drivers
- Intel® PMT Drivers
- Intel® NPU IO Drivers

### 3.1 Introduction

This section describes the installation procedures for software and drivers.

---

**Note:** After installing your Windows operating system, you must install the Intel® Chipset Software Installation Utility first before proceeding with the drivers installation.

---

### 3.2 Intel® Chipset Software Installation Utility

The Intel® Chipset drivers should be installed first before the software drivers to install INF files for Plug & Play function for Intel chipset components. Follow the instructions below to complete the installation.


1. The software drivers are available on the IBASE website. Go to the download page of the product. Copy the compressed drivers file to your computer. Double click the file to decompress it. Run “CDGuide” to go to the main drivers page. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane.



- Click **Intel(R) Chipset Software Installation Utility**.



- When the *Welcome* screen to the Intel® Chipset Device Software appears, click **Next** to continue.
- Accept the terms in the software license agreement.
- On the *Readme File Information* screen, click **Install**.




- After completing the installation, click **Finish** to complete the setup process.

### 3.3 VGA Driver Installation


1. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane.



2. Click **Intel(R) HD Graphics Driver**.



3. Click **Begin installation**.
4. Click **I agree** in the INTEL SOFTWARE LICENSE AGREEMENT screen.
5. Click **Start** for the installer to install the following components:
  - Intel Graphics Driver
  - Intel Graphics Command Center
6. When installation has been completed, click **Finish**.



### 3.4 Intel(R) Smartsound Drivers Installation

1. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane. Click **Intel(R) Smartsound Drivers** on the right page.



2. Run the file in the path shown below for the InstallShield Wizard to start and complete the installation of the Intel Smartsound drivers. When installation has been completed, press any key to continue.



### 3.5 HD Audio Driver Installation

1. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane. Click **Realtek Audio Drivers**.



2. Click **Realtek Audio DCH Drivers**.



3. Click **Next** when the Welcome to the InstallShield Wizard for Realtek Audio Driver screen appears. After the Installshield Wizard has completed the installation, restart the computer.

### 3.6 LAN Driver Installation


1. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane.



2. Click **Intel(R) PRO LAN Network Drivers**.



3. On the *Intel® Network Connections* screen, click **Install Drivers and Software**.
4. When the Welcome to the install wizard for Intel(R) Network Connections screen appears, click **Next**.
5. Accept the terms in the software license agreement and click **Next**.
6. On the *Setup Options* screen, click the checkbox to select the desired driver(s) for installation. Then click **Next** to continue.



7. On the *Ready to Install the Program* screen, click **Install** to begin the installation. When the Install wizard has completed the installation, click **Finish**.



### 3.7 Intel® ME Drivers Installation

1. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane.



2. Click **Intel(R) ME Drivers**.



3. When the Welcome screen appears, click **Next**.
4. Accept the terms in the license agreement and click **Next**.
5. In the Destination Folder screen, click **Next** to install to the default folder, or click Change to choose another destination folder.
6. After Intel Management Engine Components have been successfully installed, click **Finish**.

You have successfully installed the following components:

- Intel® Management Engine Interface
- Serial Over LAN
- Intel® Wireless Manageability Driver
- Local Management Service
- Intel® Trusted Connect Service



### 3.8 Intel® Serial IO Drivers Installation

1. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane.



2. Click **Intel(R) Serial IO Drivers**.



3. When the Welcome screen appears, click **Next**.
4. Accept the terms in the license agreement and click **Next**.
5. In both the Readme File Information and Confirmation screens, click **Next**. When you successfully finished the installation, click **Finish**.



### 3.9 Intel® PMT Drivers Installation

1. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane.



2. Click **Intel(R) PMT Drivers**.



3. Run the file in the path shown below for the InstallShield Wizard to start and complete the installation of the Intel PMT drivers. When installation has been completed, press any key to continue.



### 3.10 Intel® NPU IO Drivers Installation

1. Click **Intel** on the left pane and then **Intel(R) Meteor Lake-P/PS/U Chipset Drivers** on the right pane.



2. Click **Intel(R) NPU IO Drivers**.



3. Run the file in the path shown below for the InstallShield Wizard to start and complete the installation of the drivers. When installation has been completed, press any key to continue.



This page is intentionally left blank.

## Chapter 4

# BIOS Setup

This chapter describes the different settings available in the AMI BIOS that comes with the board. The topics covered in this chapter are as follows:

- Main Settings
- Advanced Settings
- Security Settings
- Boot Settings
- Save & Exit
- MEBx

## 4.1 Introduction

The BIOS (Basic Input/Output System) installed in the ROM of your computer system supports Intel® processors. The BIOS provides critical low-level support for standard devices such as disk drives, serial ports and parallel ports. It also provides password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

## 4.2 BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Press the <Del> key immediately allows you to enter the Setup utility. If you are a little bit late pressing the <Del> key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup.

If you still need to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again.

The following message will appear on the screen:

```
Press <DEL> to Enter Setup
```

In general, press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help, and <Esc> to quit.

When you enter the BIOS Setup utility, the *Main Menu* screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.


---

**Warning:** It is strongly recommended that you avoid making any changes to the chipset defaults.

These defaults have been carefully chosen by both AMI and your system manufacturer to provide the absolute maximum performance and reliability. Changing the defaults could make the system unstable and crash in some cases.

---

## 4.3 Main Settings



| BIOS Setting | Description   |
|--------------|---|
| System Date  | Sets the date. Use the <Tab> key to switch between the Date elements. |
| System Time  | Set the time. Use the <Tab> key to switch between the Time elements.  |

## 4.4 Advanced Settings

This section allows you to configure system features according to your preference.






## 4.4.1 CPU Configuration



| BIOS Setting                           | Description  |
|--|--|
| Efficient/Performance-core Information | Displays the E-core / P-core Information   |
| Intel (VMX) Virtualization Technology  | When enabled, a VMX can utilize the additional hardware capabilities provided by Vanderpool Technology.  |
| Active Performance Cores               | Number of P-cores to enable in each processor package. Note: Number of cores and E-cores are looked at together. When both are (0,0), Pcode will enable all cores. |
| Active Efficient Cores                 | Number of E-cores to enable in each processor package. Note: Number of cores and E-cores are looked at together. When both are (0,0), Pcode will enable all cores. |
| Active SOC-North Efficient-cores       | Number of SOC-North Efficient-cores to enable in SOC North   |
| Hyper-Threading                        | Enable/Disable Hyper-Threading   |

## 4.4.2 Power &amp; Performance




| BIOS Setting                   | Description  |
|--------------------------------|--|
| CPU - Power Management Control | CPU - Power Management Control Options   |
| Intel Speedstep                | Allows more than two frequency ranges to be supported  |
| Intel Speed Shift Technology   | Enable/Disable Intel Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.             |
| Turbo Mode                     | Options: Enabled, Disabled   |
| Config TDP Configurations      | cTDP (Assured Power) Configurations  |
| Configurable TDP Boot Mode     | cTDP (Assured Power) Mode as Nominal/Level1/Level12/Deactivate TDP (Base Power) selection. Deactivate option will set MSR to Nominal and MMIO to zero. |



### 4.4.3 System Agent (SA) Configuration

| Aptio Setup - AMI   |          |          |      |   |      |
|---|----------|----------|------|---|------|
| Main  | Advanced | Security | Boot | Save & Exit   | MEMX |
| <ul style="list-style-type: none"><li>▶ CPU Configuration</li><li>▶ Power &amp; Performance</li><li>▶ System Agent (SA) Configuration</li><li>▶ PCH-I/O Configuration</li><li>▶ PCH-FW Configuration</li><li>▶ Trusted Computing</li><li>▶ ACPI Settings</li><li>▶ F81964 Super I/O Configuration</li><li>▶ Hardware Monitor</li><li>▶ USB Configuration</li><li>▶ Network Stack Configuration</li><li>▶ NVMe Configuration</li></ul> |          |          |      | <div>System Agent (SA) Parameters</div> <div>++: Select Screen<br/>T1: Select Item<br/>Enter: Select<br/>+/-: Change Opt.<br/>F1: General Help<br/>F2: Previous Values<br/>F3: Optimized Defaults<br/>F4: Save &amp; Exit<br/>ESC: Exit</div> |      |
| Version 2.22.1293 Copyright (C) 2024 AMI  |          |          |      |   |      |
| <div>System Agent (SA) Configuration</div> <div>▶ VMD setup menu</div>  |          |          |      | <div>VMD Configuration settings</div>   |      |
| <div>VMD Configuration</div> <div>Enable VMD controller [Disable]</div>   |          |          |      | <div>Enable/Disable to VMD controller</div>   |      |

### 4.4.4 PCH-IO Configuration



## 4.4.5 PCH-FW Configuration




## 4.4.6 Trusted Computing

| Aptio Setup - AMI              |               |  |
|--------------------------------|---------------|--|
| Advanced                       |               |  |
| TPM 2.0 Device Found           | 15,23         | Enables or Disables BIOS support for security device. O.S. will not show Security Device, TCG EFI protocol and INT1A interface will not be available.                          |
| Firmware Version:              | IFX           |  |
| Vendor:                        |               |  |
| Security Device Support        | [Enable]      |  |
| Active PCR banks               | SHA256        |  |
| Available PCR banks            | SHA256,SHA384 |  |
| SHA256 PCR Bank                | [Enabled]     |  |
| SHA384 PCR Bank                | [Disabled]    |  |
| Pending operation              | [None]        | ++: Select Screen<br>F1: Select Item<br>Enter: Select<br>+/-: Change Opt.<br>F1: General Help<br>F2: Previous Values<br>F3: Optimized Defaults<br>F4: Save & Exit<br>ESC: Exit |
| Platform Hierarchy             | [Enabled]     |  |
| Storage Hierarchy              | [Enabled]     |  |
| Endorsement Hierarchy          | [Enabled]     |  |
| Physical Presence Spec Version | [1.3]         |  |
| TPM 2.0 InterfaceType          | [TIS]         |  |
| Device Select                  | [Auto]        |  |




| BIOS Setting                   | Description  |
|--------------------------------|--|
| Security Device Support        | Enables / Disables BIOS support for security device. OS will not show security device. TCG EFI protocol and INT1A interface will not be available.   |
| SHA256/384, SM3_256 PCR Bank   | Enables / Disables PCR Bank.   |
| Pending operation              | Schedule an operation for the security device. Note: Your computer will reboot during restart in order to change state of security device.   |
| Platform Hierarchy             | Enables / Disables platform hierarchy.   |
| Storage Hierarchy              | Enables / Disables storage hierarchy.  |
| Endorsement Hierarchy          | Enables / Disables endorsement hierarchy.  |
| Physical Presence Spec Version | Select to tell O.S. to support PPI Spec Version 1.2 or 1.3. Note some HCK tests might not support 1.3.   |
| Device Select                  | TPM 1.2 will restrict support to TPM 1.2 devices. TPM 2.0 will restrict support to TPM 2.0 devices. Auto will support both with the default set to TPM 2.0 devices if not found, TPM 1.2 devices will be enumerated. |

### 4.4.7 ACPI Settings





| BIOS Setting       | Description  |
|--------------------|--|
| Enable Hibernation | Enables / Disables the system ability to hibernate (OS/S4 Sleep State). This option may be not effective with some OS. |

## 4.4.8 F81964 Super IO Configuration






## 4.4.9 Hardware Monitor




| BIOS Setting            | Description   |
|-------------------------|---|
| CPU Smart Fan Control   | Enables / Disables smart fan control.   |
| Temperatures / Voltages | These fields are the parameters of the hardware monitoring function feature of the motherboard. The values are read-only values as monitored by the system and show the PC health status. |

4.4.10 USB Configuration




| BIOS Setting                    | Description  |
|---------------------------------|--|
| XHCI Hand-off                   | This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.   |
| USB Mass Storage Driver Support | Enables / Disables the support for USB mass storage driver.  |
| USB Transfer time-out           | The time-out value (1 / 5 10 / 20 secs) for Control, Bulk, and Interrupt transfers.  |
| Device reset time-out           | Gives seconds (10 / 20 / 30 / 40 secs) to delay execution of Start Unit command to USB mass storage device.  |
| Device power-up delay           | Max.time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100ms, for a Hub port the delay is taken from Hub descriptor. |

### 4.4.11 Network Stack Configuration




| BIOS Setting       | Description  |
|--------------------|--|
| Network Stack      | Enable/Disable UEFI Network Stack  |
| IPv4 PXE Support   | If disabled, IPv4 PXE boot support will not be available.  |
| IPv4 HTTP Support  | If disabled, IPv4 HTTP boot support will not be available.   |
| IPv6 PXE Support   | If disabled, IPv6 PXE boot support will not be available.  |
| IPv6 HTTP Support  | If disabled, IPv6 HTTP boot support will not be available.   |
| PXE boot wait time | Wait time in seconds to press ESC key to abort the PXE boot. Use either +/- or numeric keys to set the value |
| Media detect count | Number of times the presence of media will be checked. Use either +/- numeric keys to set the value.         |

4.4.12 NVMe Configuration




## 4.5 Security Settings




| BIOS Setting                 | Description  |
|------------------------------|--|
| Setup Administrator Password | Sets an administrator password for the setup utility.  |
| User Password                | Sets a user password.  |
| Secure Boot                  | Secure Boot feature is Active if Secure Boot is enabled. Platform Key(PK) is enrolled and the system is in user mode. The mode change requires platform reset.         |
| Secure Boot Mode             | Secure Boot mode options: Standard or Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication. |
| Restore Factory Keys         | Forces system to user mode. Install factory default Secure Boot key databases.   |
| Reset to Setup Mode          | Delete all Secure Boot key databases from NVRAM  |
| Expert Key Management        | Enables expert users to modify Secure Boot Policy variables without full authentication.   |

## 4.6 Boot Settings





| BIOS Setting                | Description  |
|-----------------------------|--|
| Setup Prompt Timeout        | Number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting. |
| Bootup NumLock State        | Selects the keyboard NumLock state.  |
| Quiet Boot                  | Enables / Disables Quiet Boot option.  |
| FIXED BOOT ORDER Priorities | Sets the system boot order.  |

## 4.7 Save & Exit Settings



| BIOS Setting                            | Description  |
|---|--|
| Save Changes and Exit                   | Exits system setup after saving the changes.   |
| Discard Changes and Exit                | Exits system setup without saving any changes.   |
| Save Changes and Reset                  | Resets the system after saving the changes.  |
| Discard Changes and Reset               | Resets system setup without saving any changes.  |
| Save Changes                            | Saves changes done so far to any of the setup options.   |
| Discard Changes                         | Discards changes done so far to any of the setup options.  |
| Restore Defaults                        | Restores / Loads defaults values for all the setup options.  |
| Save as User Defaults                   | Saves the changes done so far as User Defaults.  |
| Restore User Defaults                   | Restores the user defaults to all the setup options.   |
| Launch EFI Shell from filesystem device | Attempts to launch EFI shell application (Shell.efi) from one of the available filesystem devices. |

## 4.8 MEBx





# Appendix

This section provides the mapping addresses of peripheral devices and the sample code of watchdog timer configuration.

## A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. The following table lists the I/O port addresses used.

| Address               | Device Description                |
|-----------------------|-----------------------------------|
| 0x0000EFA0-0x0000EFBF | Intel(R) SMBus - 7E22             |
| 0x00000A00-0x00000A0F | Motherboard resources             |
| 0x00000A10-0x00000A1F | Motherboard resources             |
| 0x00000A10-0x00000A1F | Motherboard resources             |
| 0x0000002E-0x0000002F | Motherboard resources             |
| 0x0000004E-0x0000004F | Motherboard resources             |
| 0x00000061-0x00000061 | Motherboard resources             |
| 0x00000063-0x00000063 | Motherboard resources             |
| 0x00000065-0x00000065 | Motherboard resources             |
| 0x00000067-0x00000067 | Motherboard resources             |
| 0x00000070-0x00000070 | Motherboard resources             |
| 0x00000080-0x00000080 | Motherboard resources             |
| 0x00000092-0x00000092 | Motherboard resources             |
| 0x000000B2-0x000000B3 | Motherboard resources             |
| 0x00000680-0x0000069F | Motherboard resources             |
| 0x0000164E-0x0000164F | Motherboard resources             |
| 0x00003050-0x00003057 | Standard SATA AHCI Controller     |
| 0x00003040-0x00003043 | Standard SATA AHCI Controller     |
| 0x00003020-0x0000303F | Standard SATA AHCI Controller     |
| 0x000003F8-0x000003FF | Communications Port (COM1)        |
| 0x000002F8-0x000002FF | Communications Port (COM2)        |
| 0x000003E8-0x000003EF | Communications Port (COM3)        |
| 0x000002E8-0x000002EF | Communications Port (COM4)        |
| 0x00000020-0x00000021 | Programmable interrupt controller |
| 0x00000024-0x00000025 | Programmable interrupt controller |

| Address               | Device Description                                 |
|-----------------------|--|
| 0x00000028-0x00000029 | Programmable interrupt controller                  |
| 0x0000002C-0x0000002D | Programmable interrupt controller                  |
| 0x00000030-0x00000031 | Programmable interrupt controller                  |
| 0x00000034-0x00000035 | Programmable interrupt controller                  |
| 0x00000038-0x00000039 | Programmable interrupt controller                  |
| 0x0000003C-0x0000003D | Programmable interrupt controller                  |
| 0x000000A0-0x000000A1 | Programmable interrupt controller                  |
| 0x000000A4-0x000000A5 | Programmable interrupt controller                  |
| 0x000000A8-0x000000A9 | Programmable interrupt controller                  |
| 0x000000AC-0x000000AD | Programmable interrupt controller                  |
| 0x000000B0-0x000000B1 | Programmable interrupt controller                  |
| 0x000000B4-0x000000B5 | Programmable interrupt controller                  |
| 0x000000B8-0x000000B9 | Programmable interrupt controller                  |
| 0x000000BC-0x000000BD | Programmable interrupt controller                  |
| 0x000004D0-0x000004D1 | Programmable interrupt controller                  |
| 0x00000000-0x00000CF7 | PCI Express Root Complex                           |
| 0x00000D00-0x0000FFFF | PCI Express Root Complex                           |
| 0x00000040-0x00000043 | System timer                                       |
| 0x00000050-0x00000053 | System timer                                       |
| 0x0000FFF8-0x0000FFFF | Intel(R) Active Management Technology - SOL (COM5) |
| 0x00002000-0x000020FE | Motherboard resources                              |
| 0x00000060-0x00000060 | Standard PS/2 Keyboard                             |
| 0x00000064-0x00000064 | Standard PS/2 Keyboard                             |
| 0x00001854-0x00001857 | Motherboard resources                              |

## B. Interrupt Request Lines (IRQ)

The following table shows the IRQ used by the devices on board.

| Level             | Function  |
|-------------------|---|
| IRQ 4294967286~84 | Intel(R) Ethernet Controller I226-LM                            |
| IRQ 4294967292    | PCI Express Root Port   |
| IRQ 4294967289    | Standard SATA AHCI Controller                                   |
| IRQ 4             | Communications Port (COM1)                                      |
| IRQ 3             | Communications Port (COM2)                                      |
| IRQ 5             | Communications Port (COM3)                                      |
| IRQ 6             | Communications Port (COM4)                                      |
| IRQ 4294967290    | PCI Express Root Port   |
| IRQ 4294967286    | Intel(R) USB 3.20 eXtensible Host Controller - 1.20 (Microsoft) |
| IRQ 4294967293    | PCI Express Root Port   |
| IRQ 4294967232    | Intel(R) Reserved Device  |
| IRQ 55~204        | Microsoft ACPI-Compliant System                                 |
| IRQ 256~511       | Microsoft ACPI-Compliant System                                 |
| IRQ 4294967288    | Intel(R) Arc(TM) Graphics                                       |
| IRQ 0             | System timer  |
| IRQ 19            | Intel(R) Active Management Technology - SOL (COM5)              |
| IRQ 4294967291    | PCI Express Root Port   |
| IRQ 1             | Microsoft PS/2 Keyboard   |
| IRQ 4294967287    | Intel(R) USB 3.20 eXtensible Host Controller - 1.20 (Microsoft) |
| IRQ 4294967251~67 | Intel(R) Ethernet Controller I226-V                             |
| IRQ 4294967234~50 | Intel(R) Ethernet Controller I226-V #2                          |
| IRQ 12            | Microsoft PS/2 Mouse  |
| IRQ 4294967233    | Intel(R) Management Engine Interface #1                         |
| IRQ 4294967285    | Intel® Smart Sound Technology BUS                               |
| IRQ 14            | Intel(R) Serial IO GPIO Host Controller - INT1083               |
| IRQ 4294967294    | PCI Express Root Port   |

## C. Watchdog Timer Configuration

The Watchdog Timer (WDT) is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven.

Under normal circumstance, you will need to restart the WDT at regular intervals before the timer counts to zero.

### Sample Code:

```
//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include <dos.h>
#include <conio.h>
#include <stdio.h>
#include <stdlib.h>
#include "F81964.H"
//-----
int main (int argc, char *argv[]);
void EnableWDT(int);
void DisableWDT(void);
//-----
int main (int argc, char *argv[])
{
    unsigned char bBuf;
    unsigned char bTime;
    char **endptr;

    char SIO;

    printf("Fintek 81964 watch dog program\n");
    SIO = Init_F81964();
    if (SIO == 0)
    {
        printf("Can not detect Fintek 81964, program abort.\n");
        return(1);
    }
    if (SIO == 0)

    if (argc != 2)
    {
        printf("Parameter incorrect!!\n");
        return (1);
    }
}
```

```

bTime = strtol(argv[1], endptr, 10);
printf("System will reset after %d seconds\n", bTime);

if (bTime)
{
    EnableWDT(bTime); }
else
{
    DisableWDT(); }
return 0;
}
//-----
void EnableWDT(int interval)
{
    unsigned char bBuf;

    bBuf = Get_F81964_Reg(0x2B);
    bBuf &= (~0x20);
    Set_F81964_Reg(0x2B, bBuf);           //Enable WDTO

    Set_F81964_LD(0x07);                 //switch to logic device 7
    Set_F81964_Reg(0x30, 0x01);          //enable timer

    bBuf = Get_F81964_Reg(0xF5);
    bBuf &= (~0x0F);
    bBuf |= 0x52;
    Set_F81964_Reg(0xF5, bBuf);           //count mode is second

    Set_F81964_Reg(0xF6, interval);       //set timer

    bBuf = Get_F81964_Reg(0xFA);
    bBuf |= 0x01;
    Set_F81964_Reg(0xFA, bBuf);           //enable WDTO output

    bBuf = Get_F81964_Reg(0xF5);
    bBuf |= 0x20;
    Set_F81964_Reg(0xF5, bBuf);           //start counting
}
//-----
void DisableWDT(void)
{
    unsigned char bBuf;

    Set_F81964_LD(0x07);                 //switch to logic device 7

    bBuf = Get_F81964_Reg(0xFA);
    bBuf &= ~0x01;
    Set_F81964_Reg(0xFA, bBuf);           //disable WDTO output

    bBuf = Get_F81964_Reg(0xF5);
    bBuf &= ~0x20;
    bBuf |= 0x40;
    Set_F81964_Reg(0xF5, bBuf);           //disable WDT
}
//-----
//

```

```

// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include "F81964.H"
#include <dos.h>
//-----
unsigned int F81964_BASE;
void Unlock_F81964 (void);
void Lock_F81964 (void);
//-----
unsigned int Init_F81964(void)
{
    unsigned int result;
    unsigned char ucDid;

    F81964_BASE = 0x4E;
    result = F81964_BASE;

    ucDid = Get_F81964_Reg(0x20);
    if (ucDid == 0x07) //Fintek 81964
    {
        goto Init_Finish;
    }

    F81964_BASE = 0x2E;
    result = F81964_BASE;

    ucDid = Get_F81964_Reg(0x20);
    if (ucDid == 0x07) //Fintek 81964
    {
        goto Init_Finish;
    }

    F81964_BASE = 0x00;
    result = F81964_BASE;

Init_Finish:
    return (result);
}
//-----
void Unlock_F81964 (void)
{
    outputb(F81964_INDEX_PORT, F81964_UNLOCK);
    outputb(F81964_INDEX_PORT, F81964_UNLOCK);
}
//-----
void Lock_F81964 (void)
{
    outputb(F81964_INDEX_PORT, F81964_LOCK);
}
//-----
void Set_F81964_LD( unsigned char LD)
{
    Unlock_F81964();
    outputb(F81964_INDEX_PORT, F81964_REG_LD);
    outputb(F81964_DATA_PORT, LD);
    Lock_F81964();
}

```

```
//-----
void Set_F81964_Reg( unsigned char REG, unsigned char DATA)
{
    Unlock_F81964();
    outportb(F81964_INDEX_PORT, REG);
    outportb(F81964_DATA_PORT, DATA);
    Lock_F81964();
}
//-----

unsigned char Get_F81964_Reg(unsigned char REG)
{
    unsigned char Result;
    Unlock_F81964();
    outportb(F81964_INDEX_PORT, REG);
    Result = inportb(F81964_DATA_PORT);
    Lock_F81964();
    return Result;
}
//-----

//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#ifndef F81964_H
#define F81964_H 1
//-----
#define F81964_INDEX_PORT (F81964_BASE)
#define F81964_DATA_PORT (F81964_BASE+1)
//-----
#define F81964_REG_LD 0x07
//-----
#define F81964_UNLOCK 0x87
#define F81964_LOCK 0xAA
//-----
unsigned int Init_F81964(void);
void Set_F81964_LD( unsigned char);
void Set_F81964_Reg( unsigned char,
unsigned char); unsigned char
Get_F81964_Reg( unsigned char);
//-----
#endif // F81964_H
```



## D. Onboard Connector Types

| Function                       | Connector            | Onboard Type                            | Compatible Mating Type for Reference    |
|--------------------------------|----------------------|---|---|
| DC-In Power Connector          | J23                  | Hao Guo Xing Ye<br>ATX4PT-NY46          | Molex<br>39-01-2040                     |
| USB 2.0 Connector              | J14, J15             | Hao Guo Xing Ye<br>DF11-8S-PA66H        | Hirose<br>DF11-8DS-2C                   |
| SATA Power Connector           | J16                  | Hao Guo Xing Ye<br>WAFER25-104S-2442-ST | AMP<br>171822-4                         |
| Digital I/O Connector          | J11                  | E-CALL<br>E-CALL_0196-01-200-100        | Dupont<br>10P 2.0 mm-pitch<br>(female)  |
| Front Panel Settings Connector | J3                   | E-CALL<br>0126-01-203-080               | Dupont<br>8P 2.54 mm-pitch<br>(female)  |
| COM3 & COM4 RS-232 Port        | J2, J5               | Hao Guo Xing Ye<br>DF11-10S-PA66H       | HRS<br>DF11-10DS-2C                     |
| Audio Connector                | J22                  | E-CALL<br>0126-01-2821009               | Dupont<br>10P 2.54 mm-pitch<br>(female) |
| Fan Power Connectors           | CPU_FAN1<br>SYS_FAN1 | TechBest<br>W2-03I104132S1WT(A)-L       | Molex<br>47054-1000                     |

**E. MI1002AF USB Power Control Bit Mapping.**

| Function   | Connector  | Software Mapping |
|------------|------------|------------------|
| M.2 –E Key | J13        | bit_3            |
| USB3       | CN7 (A, B) | bit_4            |