

MS-CF16

Industrial Computer Board

User Guide

Contents

Safe	ety Information	4
Regu	ulatory Notices	5
Spec	cifications	8
Moth	herboard Overview	10
Rear	r I/O Panel	11
	HDMI™ Connector	11
	USB 10Gbps Ports	11
	USB 5 Gbps Ports	11
	GbE RJ-45 LAN Jack	11
ME C	Overview	12
	Board Dimension	12
	Suggested Chassis I/O Gap Dimension	13
Stora	rage	15
Ехра	ansion Slots	16
Coni	nectors	18
	Power Connectors	18
	Cooling Connectors	19
	Audio Connectors	20
	Graphics Connectors	21
	USB Connectors	24
	Other Connectors	25
Jum	npers	29
Bios	s Setup	30
	Entering Setup	30
	Control Keys	31
	Getting Help	31
	Main Menu	31

Revision

V1.1, 2025/05

Sub-Menu	31
General Help <f1></f1>	31
The Menu Bar	32
Main	33
Advanced	34
Boot	42
Security	43
Chipset	51
Power	52
Save & Exit	53
Audio Driver Setup	54
Installing the Intel® SST Audio Driver	54
GPIO WDT Programming	56
Abstract	56
General Purpose IO	57
Watchdog Timer	58

Safety Information

- The components included in this package are prone to damage from electrostatic discharge (ESD). Please adhere to the following instructions to ensure successful computer assembly.
- Ensure that all components are securely connected. Loose connections may cause the computer to not recognize a component or fail to start.
- Hold the motherboard by the edges to avoid touching sensitive components.
- It is recommended to wear an electrostatic discharge (ESD) wrist strap when handling the motherboard to prevent electrostatic damage. If an ESD wrist strap is not available, discharge yourself of static electricity by touching another metal object before handling the motherboard.
- Store the motherboard in an electrostatic shielding container or on an anti-static pad whenever the motherboard is not installed.
- Before turning on the computer, ensure that there are no loose screws or metal components on the motherboard or anywhere within the computer case.
- Do not boot the computer before installation is completed. This could cause permanent damage to the components as well as injury to the user.
- If you need help during any installation step, please consult a certified computer technician.
- Always turn off the power supply and unplug the power cord from the power outlet before installing or removing any computer component.
- Keep this user guide for future reference.
- Keep this motherboard away from humidity.
- Make sure that your electrical outlet provides the same voltage as is indicated on the PSU, before connecting the PSU to the electrical outlet.
- Place the power cord such a way that people can not step on it. Do not place anything over the power cord.
- All cautions and warnings on the motherboard should be noted.
- If any of the following situations arises, get the motherboard checked by service personnel:
 - Liquid has penetrated into the computer.
 - The motherboard has been exposed to moisture.
 - The motherboard does not work well or you can not get it work according to user guide.
 - The motherboard has been dropped and damaged.
 - The motherboard has obvious sign of breakage.
- Do not leave this motherboard in an environment above 60°C (140°F), it may damage the motherboard.

Regulatory Notices

CE Conformity

Hereby, Micro-Star International CO., LTD declares that this device is in compliance with the essential safety requirements and other relevant provisions set out in the European Directive.



FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

WEEE Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at:

https://csr.msi.com/global/index

Battery Information

Please take special precautions if this product comes with a battery.

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.
- Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting
 of a battery, which can result in an explosion.
- Avoid leaving a battery in an extremely high temperature or extremely low air pressure environment that can result in an explosion or the leakage of flammable liquid or gas.
- Do not ingest battery. If the coin/button cell battery is swallowed, it can cause severe internal burns and can lead to death. Keep new and used batteries away from children.

European Union:



Batteries, battery packs, and accumulators should not be disposed of as unsorted household waste. Please use the public collection system to return, recycle, or treat them in compliance with the local regulations.

BSMI:



廢電池請回收

For better environmental protection, waste batteries should be collected separately for recycling or special disposal.

California, USA:



The button cell battery may contain perchlorate material and requires special handling when recycled or disposed of in California.

For further information please visit:

http://www.dtsc.ca.gov/hazardouswaste/perchlorate/

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.



- Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.

Copyright and Trademarks Notice

msi MSI 微星





Copyright © Micro-Star Int' I Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int' I Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI™, HDMI™ High-Definition Multimedia Interface, HDMI™ Trade dress and the HDMI[™] Logos are trademarks or registered trademarks of HDMI[™] Licensing Administrator, Inc.

Technical Support

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.


Specifications

Model	Alder Lake-N SKUs	Amston Lake SKUs				
Dimensions	101(L)mm x 73(W)mm, PICO-ITX					
Processor	 Intel® IoTG Alder Lake-N, Processor N97, 4 cores, 12W Atom® x7425E, 4 cores, 12W 	Intel® IoTG Amston Lake, Atom® x7433RE, 4 cores, 9W				
Chipset	Within processor					
ТРМ	Infineon® SLB 9672VU2.0	Infineon® SLB 9672XU2.0				
Material	• 1 x Realtek® RTL8125BG-CG 2.5GbE LAN	• 1 x Realtek® RTL8125BI-CG 2.5GbE LAN				
Network	• 1 x Realtek® RTL8111K-CG 1GbE PHY LAN	• 1 x Realtek® RTL8111KI-CG 1GbE LAN				
Memory	 LPDDR5 on board Single channel, Non-ECC Up to 4800 MT/s Up to 16GB 					
Storage	1 x SATA 3.0 6Gb/s ports					
	• 1 x M.2 E Key slot (2230) - Supports PCle 3.0 x1, USB 2.0 (480 Mbps) signal					
Expansion Slots	5 1 X W.2 D NCy Stot (2242/ 3042)					
Audio	Realtek® ALC897 High Definition Audio Codec					
Graphics	1 x HDMI™ 1.4b up to 3840x2160 @30Hz 1 x eDP up to 1920×1080 @60Hz Supports auto switch between eDP & LVDS Connector shared with LVDS 1 x LVDS up to 1920×1080 @60Hz Supports 18/24-bit dual channel Supports auto switch between eDP & LVDS Connector shared with eDP					
	2 Independent display supported HDMI™ + LVDS/ eDP					
	• 1 x HDMI™ connector (1.4b)					
	• 1 x 2.5 GbE RJ-45 LAN port					
Rear Panel Connectors	• 1 x 1 GbE RJ-45 LAN port					
	• 1 x USB 10Gbps Type-A ports					
	• 1 x USB 5Gbps Type-A ports					


Continued on next column

Model	Alder Lake-N SKUs	Amston Lake SKUs					
Internal USB Connectors	1 x USB 2.0 header (480 Mbps, for 2 USB ports)						
Power	• 1 x 2-Pin DC-In 12V Power Connector						
Connectors	• 1 x 2-Pin SATA 5V Power Connector						
Fan Connectors	1 x 3-pin DC system fan connector						
	• 1 x Front panel header						
	• 2 x LAN LED connector						
	• 1 x Front audio header (Line-out & Mic-in)						
	• 1 x LVDS inverter header (5V/ 12V)						
System	• 1 x LVDS +eDP wafer connector						
Connectors	 1 x GPIO + COM header COM (serial): Supports RS-232/422/485, with 0V/5V/12V (default 5V) GPIO: 8-bit, 4 x GPI, 4 x GPO 						
	• 1 x SMBus header						
	• 1 x CMOS battery header						
	1 x COM voltage select jumper						
	• 1 x LVDS/ eDP power select jumper (3V/ 5V)						
Jumpers	• 1 x AT/ ATX mode select jumper						
	• 1 x Clear CMOS jumper						
	• 1 x ME jumper						
	Windows 10 IoT Enterprise 21H2 LTSC (64-Bit)						
OS Driver Support	Windows 11 IoT Enterprise 24H2 LTSC (64-Bit)						
- при	Linux (support by request)						
Certification	CE, FCC Class B, BSMI, RCM, VCCI, UKCA, IC, II	EC 62368: CE (LVD) Compliant					
Environment	 Operating Temperature: -10 ~ 60°C Thermal w/ Airflow: 0.7m/s The standard thermal solution only supports TDP up to 12W. Storage Temperature: -20 ~ 80°C 	Operating Temperature: -40 ~ 70°C Thermal w/ Airflow: 0.7m/s The standard thermal solution only supports TDP up to 9W. (-40 ~ 85°C by request)					
		• Storage Temperature: -40 ~ 85°C					
	Operating Humidity: 10 ~ 90%, non-conder	S					
	• Relative Humidity: 10 ~ 90%, non-condensing						

Motherboard Overview



Rear I/O Panel



HDMI™ Connector HDMI™

HDMI™ is an all-digital interface for uncompressed audio/video streams, supporting standard, enhanced, or high-definition video, and multi-channel digital audio on a single cable.

USB 10Gbps Ports


This connector delivers high-speed data transfer for various devices, such as storage devices, hard drives, video cameras, etc. It supports data transfer rates up to 10 Gbps.

USB 5 Gbps Ports

The USB (Universal Serial Bus) port is for attaching USB devices such as keyboards, mouse, or other USB-compatible devices. It supports data transfer rates up to **5 Gbps**.

GbE RJ-45 LAN Jack


The standard single RJ45 LAN jack is provided for connection to the Local Area Network (LAN). You can connect a network cable to it.




ME Overview


Board Dimension

Unit of measurement: mm





Suggested Chassis I/O Gap Dimension




Component Contents

Component	Page		
Storage	15		
SATA1: SATA 3.0 6Gb/s Port	15		
Expansion Slots	16		
M2_B1: M.2 Slot (B Key, 2242, 3042)	16		
M2_E1: M.2 Slot (E Key, 2230)	17		
Connectors	18		
Power Connectors	18		
JPWR1: 2-Pin DC-In 12V Power Connector	18		
JSATAPWR1: 2-Pin SATA 5V Power Connector	18		
Cooling Connectors	19		
SYSFAN1: System Fan Connector	19		
Audio Connectors	20		
JAUD1: Front Audio Header	20		
Graphics Connectors	21		
JINV1: LVDS Inverter Header	21		
JLVDS_EDP1: LVDS+eDP Wafer Connector	22		
USB Connectors	24		
JUSB1: USB 2.0 Header	24		
Other Connectors	25		
JFP1: Front Panel Connector	25		
LAN_LED1~2: LAN LED Connector	25		
JSMB1: SMBus Header			
JGPIO_COM1: GPIO + COM Connector	26		
JRTC1: CMOS Battery Header	28		
Jumpers	29		

Storage

SATA1: SATA 3.0 6Gb/s Port

This connector is SATA 6Gb/s interface port, it can connect to one SATA device.








Important


- This SATA port supports hot plug.
- Please do not fold the SATA cable at a 90-degree angle. Data loss may result during transmission otherwise.
- SATA cables have identical plugs on either sides of the cable. However, it is recommended that the flat connector be connected to the motherboard for space saving purposes.

Expansion Slots



M2_B1: M.2 Slot (B Key, 2242, 3042)

Please install the WWAN Card/ solid-state drive (SSD) into the M.2 slot as shown below.




Feature

- Supports SATA 3.0/ PCIe 3.0 x1, USB 10Gbps & USB 2.0 (480 Mbps) signals.
- Supports B+M key PCIe x1 module.
- Supports Quectel EM05-G Wi-Fi module with E-SIM.

M2_E1: M.2 Slot (E Key, 2230)

Please install the Wi-Fi/ Bluetooth card into the M.2 slot as shown below.



Feature

- Supports PCIe 3.0 x1, USB 2.0 (480 Mbps) signal.
- Supports Intel® Wi-Fi 6E AX210 + BT 5.2 wireless card.




Important

When adding or removing expansion cards, make sure that you unplug the power supply first. Meanwhile, read the documentation for the expansion card to configure any necessary hardware or software settings for the expansion card, such as jumpers, switches or BIOS configuration.


Connectors

Power Connectors




JPWR1: 2-Pin DC-In 12V Power Connector

This connector allows you to connect an power supply.



JSATAPWR1: 2-Pin SATA 5V Power Connector

This connector is used to provide power to SATA devices.






Important

Make sure that all the power cables are securely connected to a proper power supply to ensure stable operation of the system.

Cooling Connectors



SYSFAN1: System Fan Connector

The fan connector supports CPU/ system cooling fans with +12V. When connecting the wire to the connectors, always note that the red wire is the positive and should be connected to the +12V; the black wire is Ground and should be connected to GND.


	1	FAN SENSE
SYSFAN1	2	FAN_PWM
ا النَّالَ	3	GND



Important

Please refer to the recommended CPU fans at processor's official website or consult the vendors for proper CPU cooling fan.

Audio Connectors




JAUD1: Front Audio Header

This connector allows you to connect front panel audio.


		1	LINE_OUT_R_F_J	2	MIC1_RA
JAUD1 2 9 1	3	LINE_OUT_L_F_J	4	MIC1_LA	
	5	FRONT_JD	6	MIC1_JD	
	7	GND	8	GND	
	9	NC	10	NC	

Graphics Connectors



JINV1: LVDS Inverter Header

The connector is provided for LCD backlight options.



JLVDS_EDP1: LVDS+eDP Wafer Connector

This connector is intended for use with LVDS/eDP interface flat panels. When connecting your flat panel to this connector, please refer to the panel datasheet to ensure that you set the JVDD1 (eDP/ LVDS power select jumper) to the correct power voltage.

eDP Panel (P1)	CF16 M	eDP Panel (P1)			
	40 J				
Lane3_P	EDP_LINE3_DP	1	2	EDP_LINE2_DP	Lane2_P
Lane3_N	EDP_LINE3_DN	3	4	EDP_LINE2_DN	Lane2_N
	DDC0_CLK	5	6	DDC0_DATA	
LCD_VCC	LCD_VDD	7	8	LCD_VDD	LCD_VCC
LCD_VCC	LCD_VDD	9	10	VCC3	
	BKLT_EN	11	12	LVDS_DETECT#	LCD_GND
Lane1_P	LVDSA_DATA1+	13	14	EHPDET/ LVDSA_DATA0+	HPD
Lane1_N	LVDSA_DATA1-	15	16	LVDSA_DATA0-	
H_GND	GND	17	18	GND	H_GND
	LVDSA_DATA3+	19	20	LVDSA_DATA2+	Lane0_P
	LVDSA_DATA3-	21	22	LVDSA_DATA2-	Lane0_N
H_GND	GND	23	24	GND	H_GND
	LVDSB_DATA1+	25	26	LVDSB_DATA0+	
	LVDSB_DATA1-	27	28	LVDSB_DATA0-	
H_GND	GND	29	30	GND	GND
	LVDSB_DATA3+	31	32	LVDSB_DATA2+	
	LVDSB_DATA3-	33	34	LVDSB_DATA2-	
	NA	35	36	GND	GND
	LVDSB_CLK+	37	38	LVDSA_CLK+	AUX_CH_P
	LVDSB_CLK-	39	40	LVDSA_CLK-	AUX_CH_N


LVDS Panel (P1)	CF16 Motherboard (P2)				LVDS Panel (P1)
	40 JLVDS1_EDP1 2 39 1				
	EDP_LINE3_DP	1	2	EDP_LINE2_DP	
	EDP_LINE3_DN	3	4	EDP_LINE2_DN	
	DDC0_CLK	5	6	DDC0_DATA	
VCC	LCD_VDD	7	8	LCD_VDD	VCC
VCC	LCD_VDD	9	10	VCC3	
	BKLT_EN	11	12	LVDS_DETECT#	GND
RXO1+	LVDSA_DATA1+	13	14	EHPDET/ LVDSA_DATA0+	RXO0+
RXO1-	LVDSA_DATA1-	15	16	LVDSA_DATA0-	RXO0-
GND	GND	17	18	GND	GND
RXO3+	LVDSA_DATA3+	19	20	LVDSA_DATA2+	RXO2+
RXO3-	LVDSA_DATA3-	21	22	LVDSA_DATA2-	RXO2-
GND	GND	23	24	GND	GND
RXE1+	LVDSB_DATA1+	25	26	LVDSB_DATA0+	RXE0+
RXE1-	LVDSB_DATA1-	27	28	LVDSB_DATA0-	RXE0-
GND	GND	29	30	GND	GND
RXE3+	LVDSB_DATA3+	31	32	LVDSB_DATA2+	RXE2+
RXE3-	LVDSB_DATA3-	33	34	LVDSB_DATA2-	RXE2-
	NA	35	36	GND	GND
RXEC+	LVDSB_CLK+	37	38	LVDSA_CLK+	RXOC+
RXEC-	LVDSB_CLK-	39	40	LVDSA_CLK-	RXOC-



1 Important

Pin 12 is a detect pin. When using a customized LVDS cable, pin 12 should be a signal ground with a low impedance. Otherwise, LVDS will not function.

USB Connectors



JUSB1: USB 2.0 Header


This header is ideal for connecting USB devices such as keyboard, mouse, or other USB-compatible devices. It supports data transfer rate up to **480 Mbps**.

	7 1	1	SVCC2	2	GND
		3	JUSB_4-	4	JUSB_3+
JUSB1	<u> </u>	5	JUSB_4+	6	JUSB_3-
	8 2	7	GND	8	SVCC2

Other Connectors


JFP1: Front Panel Connector

This front-panel connector is provided for electrical connection to the front panel switches & LEDs.




LAN_LED1~2: LAN LED Connector


The LAN LED connector provides status indication for network connections via LEDs.



JSMB1: SMBus Header

This header enables users to connect to the System Management Bus (SMBus) interface.






JGPIO_COM1: GPIO + COM Connector

This connector is designed to provide a flexible combination of General Purpose Input/ Output (GPIO) signals and serial communication capabilities.

	-			
	1	GND	2	VCC5_F
	3	NGPO_0	4	NGPI_0
	5	NGPO_1	6	NGPI_1
ICDIO COMI	7	NGPO_2	8	NGPI_2
JGPIO_COM1	9	NGPO_3	10	NGPI_3
19 20 2	11	NDCT1#	12	NSIN1
	13	NSOUT1	14	NDTR1#
	15	GND	16	NDSR1#
	17	NRTS1	18	NCTS1#
	19	VCC_COM1	20	NC



Feature

- Supports RS-232/422/485, with 0V/5V/12V.
- RS-232/422/485, selection by BIOS control.
- Supports True RS-232/ TTL RS-232
- Supports Auto flow control.
- Supports 1000m cable.



Important

After connect COM header to printer, garbage can't be printed when power on/off.

	RS232						
PIN	SIGNAL	DESCRIPTION					
1	NDCD	Data Carrier Detect					
2	NSIN	Signal In					
3	NSOUT	Signal Out					
4	NDTR	Data Terminal Ready					
5	GND	Signal Ground					
6	NDSR	Data Set Ready					
7	NRTS	Request To Send					
8	NCTS	Clear To Send					
9	VCC_COM	VCC_COM					

RS422				
PIN	SIGNAL	DESCRIPTION		
1	422 TXD-	Transmit Data, Negative		
2	422 TXD+	Receive Data, Positive		
3	422 RXD+	Transmit Data, Positive		
4	422 RXD-	Receive Data, Negative		
5	GND	Signal Ground		
6	NC	No Connection		
7	NC	No Connection		
8	NC	No Connection		
9	NC	No Connection		

RS485				
PIN	SIGNAL	DESCRIPTION		
1	TXD-	Transmit Data, Negative		
2	NC	No Connection		
3	TXD+	Transmit Data, Positive		
4	NC	No Connection		
5	GND	Signal Ground		
6	NC	No Connection		
7	NC	No Connection		
8	NC	No Connection		
9	NC	No Connection		


JRTC1: CMOS Battery Header

If the CMOS battery is out of charge, the time in the BIOS will be reset and the data of system configuration will be lost. In this case, you need to replace the CMOS battery.



Replacing CMOS battery

- 1. Unplug the battery wire from the JRTC1 connector and remove the battery.
- 2. Connect the new CR2032 battery with wire to the JRTC1 connector.





WARNING

KEEP OUT OF REACH OF CHILDREN




- Swallowing can lead to chemical burns, perforation of soft tissue, and even death.
- Severe burns can occur within 2 hours of ingestion.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Jumpers



1mportant

Avoid adjusting jumpers when the system is on; it will damage the motherboard.



Jumper Name	Default Setting	Description
	1	COM Power Select Jumper
JCOMP1		1-2: 5V (Default)
		2-3: 12V
	1	Clear CMOS Jumper
JCMOS1		1-2: Normal (Default)
		2-3: Clear CMOS
	1	CSE Jumper
JCSE_DIS1		1-2: Normal (Default)
		2-3: ME disable
	1	AT/ ATX Mode Select Jumper
JATX1		1-2: ATX (Default)
		2-3: AT
		eDP/ LVDS Power Select Jumper
JVDD1		1-2: 3V (Default)
		2-3: 5V

Bios Setup

This chapter provides information on the BIOS Setup program and allows users to configure the system for optimal use.

Users may need to run the Setup program when:

- An error message appears on the screen at system startup and requests users to run SETUP.
- Users want to change the default settings for customized features.



// Important

- Please note that BIOS update assumes technician-level experience.
- As the system BIOS is under continuous update for better system performance, the illustrations in this chapter should be held for reference only.

Entering Setup

Power on the computer and the system will start POST (Power On Self Test) process. When the message below appears on the screen, press or <F2> key to enter Setup.

Press < DEL > or < F2 > to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system by turning it **OFF** and **On** or pressing the **RESET** button. You may also restart the system by simultaneously pressing **<Ctrl>, <Alt>, and <Delete>** keys.



Important

The items under each BIOS category described in this chapter are under continuous update for better system performance. Therefore, the description may be slightly different from the latest BIOS and should be held for reference only.

Control Keys

←→	Select Screen	
↑ ↓	Select Item	
Enter	Select	
+-	Change Value	
Esc	Exit	
F1	General Help	
F7	Previous Values	
F9	Optimized Defaults	
F10	Save & Reset*	
F12	Screenshot capture	
<k></k>	Scroll help area upwards	
<m></m>	Scroll help area downwards	

^{*} When you press **F10**, a confirmation window appears and it provides the modification information. Select between Yes or No to confirm your choice.

Getting Help

Upon entering setup, you will see the Main Menu.

Main Menu

The main menu lists the setup functions you can make changes to. You can use the arrow keys (↑↓) to select the item. The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Sub-Menu

If you find a right pointer symbol appears to the left of certain fields that means a sub-menu can be launched from this field. A sub-menu contains additional options for a field parameter. You can use **arrow keys** ($\uparrow \downarrow$) to highlight the field and press <Enter> to call up the sub-menu. Then you can use the control keys to enter values and move from field to field within a sub-menu. If you want to return to the main menu, just press the < Esc>.

General Help <F1>

The BIOS setup program provides a General Help screen. You can call up this screen from any menu by simply pressing <F1>. The Help screen lists the appropriate keys to use and the possible selections for the highlighted item. Press **<Esc>** to exit the Help screen.

The Menu Bar



Main

Use this menu for basic system configurations, such as time, date, etc.

Advanced

Use this menu to set up the items of special enhanced features.

► Boot

Use this menu to specify the priority of boot devices.

Security

Use this menu to set supervisor and user passwords.

► Chipset

This menu controls the advanced features of the onboard chipsets.

▶ Power

Use this menu to specify your settings for power management.

➤ Save & Exit

This menu allows you to load the BIOS default values or factory default settings into the BIOS and exit the BIOS setup utility with or without changes.

Main



► System Date

This setting allows you to set the system date.

Format: <Day> <Month> <Date> <Year>.

System Time

This setting allows you to set the system time.

Format: <Hour> <Minute> <Second>.

Advanced



► Full Screen Logo Display

This BIOS feature determines if the BIOS should hide the normal POST messages with the motherboard or system manufacturer's full-screen logo.

[Enabled] BIOS will display the full-screen logo during the boot-up sequence,

hiding normal POST messages.

[Disabled] BIOS will display the normal POST messages, instead of the full-

screen logo.

Please note that enabling this BIOS feature often adds 2-3 seconds of delay to the booting sequence. This delay ensures that the logo is displayed for a sufficient amount of time. Therefore, it is recommended that you disable this BIOS feature for a faster boot-up time.


Bootup NumLock State

This setting is to set the Num Lock status when the system is powered on.

Turn on the Num Lock key when the system is powered on. [On]

[Off] Allow users to use the arrow keys on the numeric keypad.

CPU Configuration



► Intel (VMX) Virtualization Technology

Virtualization enhanced by Intel Virtualization Technology will allow a platform to run multiple operating systems and applications in independent partitions. With Virtualization, one computer system can function as multiple "virtual" systems.

Active Efficient-cores

Select the number of active Efficient-cores (E-cores).

Intel(R) SpeedStep(TM)

EIST (Enhanced Intel SpeedStep Technology) allows the system to dynamically adjust processor voltage and core frequency, which can result in decreased average power consumption and decreased average heat production. When disabled, the processor will return the actual maximum CPUID (CPU Identification) input value of the processor when gueried.

▶ Intel (R) Speed Shift Technology

Intel® Speed Shift Technology is an energy-efficient method that allows frequency control by hardware rather than the OS.

[Enabled] When enabled, Intel® Speed Shift Technology is activated.

> The technology enables the management of processor power consumption via hardware performance state (P-State) transitions.

[Disabled] Disable this function.


► C States

This setting controls the C-States (CPU Power states).

Detects the idle state of system and reduce CPU power consumption accordingly. [Enabled]

[Disabled] Disable this function.

Memory Configuration



► In-Band ECC Support

Enables or disables In-Band ECC(Error-Correcting Code) Support.

When enabled this function, a portion(1/32) of memory space will [Enabled]

be reserved to store ECC data.

Disables this function. [Disabled]

► In-Band ECC Error Operation Mode

Select an operation mode from 0-2. This feature only display when In-Band ECC Support is enabled.

► In-Band ECC Error Injection Control

Enables or disables In-Band ECC Error Injection. This feature only display when In-Band ECC Support is enabled.

Super IO Configuration



► Serial Port 1

This setting enables/disables the specified serial port.

» Change Settings

This setting is used to change the address & IRQ settings of the specified serial port.

» Mode Select

Select an operation mode for Serial Port 1.

► FIFO Mode


This setting controls the FIFO data transfer mode.

▶ Watch Dog Timer

You can enable the system watchdog timer, a hardware timer that generates a reset when the software that it monitors does not respond as expected each time the watchdog polls it.

► H/W Monitor (PC Health Status)

These items display the current status of all monitored hardware devices/ components such as voltages, temperatures and all fans' speeds.



Smart Fan Configuration



► SYSFAN

This setting enables/ disables the Smart Fan function. Smart Fan is an excellent feature which will adjust the System fan speed automatically depending on the current system temperature, avoiding the overheating to damage your system.

» Min. Speed (%)

The beginning speed of the System fan.

PCI/ PCIE Device Configuration




Audio Controller

This setting enables/disables the onboard audio controller.

Network Stack Configuration

This menu provides Network Stack settings for users to enable network boot (PXE) from BIOS.



► Network Stack

This menu provides Network Stack settings for users to enable network boot (PXE) from BIOS. The following items will display when **Network Stak** is enabled.

» IPV4 PXE Support

Enables or disables IPv4 PXE boot support.

» IPV4 HTTP Support

Enables or disables Ipv4 HTTP Support.

» IPV6 PXE Support

Enables or disables Ipv6 PXE Support.

» IPV6 HTTP Support

Enables or disables Ipv6 HTTP Support.


» PXE boot wait time

Use this option to specify the wait time to press the ESC key to abort the PXE boot. Press "+" or "-" on your keyboard to change the value. The default setting is 0.

» Media detect count

Use this option to specify the number of times media will be checked. Press "+" or "-" on your keyboard to change the value. The default setting is 1.

GPIO Group Configuration




► GPO0 ~ GPO3

These settings control the operation mode of the specified GPIO.

► PCIE ASPM settings

This menu provide settings for PCIe ASPM (Active State Power Management) level for different installed devices.



► M2 B1/M2 E1

Sets PCI Express ASPM (Active State Power Management) state for power saving.

Lanes form PCH:

[Disabled] Disable this function.

Higher latency, lower power "standby" state. [L1] [Auto] Set the best state supported by the system.

Lanes form SA:

[Disabled] Disable this function.

Higher latency, lower power "standby" state. [L1]

[L0sL1] Activate both L0s and L1 support.

[L0s] Initiate an automatic shutdown of the system to protect from

potential damage due to overheating.


Boot



► Boot Option #1~2

This setting allows users to set the sequence of boot devices where BIOS attempts to load the disk operating system.

Security




► Administrator Password

Administrator Password controls access to the BIOS Setup utility.

User Password

User Password controls access to the system at boot and to the BIOS Setup utility.

PCH-FW Configuration



▶ ME State

This setting specifies the Intel Management Engine state.

► Comms Hub Support

This setting enables/disables Communications Hub Support.

▶ JHI Support

This setting enables/disables support for Intel Dynamic Application Loader Host Interface (JHI).

► Core BIOS Done Message

This setting enables/disables Core BIOS Done Message sent to ME.

► Firmware Update Configuration



» ME FW Image Re-Flash

This setting enables/ disables the ME FW (Firmware) image re-flash.

» FW Update

This setting enables/ disables the FW (Firmware) update.

► PTT Configuration

Intel Platform Trust Technology (PTT) is a platform functionality for credential storage and key management used by Microsoft Windows.



» TPM Device Selection


Select TPM (Trusted Platform Module) devices from PTT or dTPM (Discrete TPM).

[PTT] Enables PTT in SkuMgr.

[dTPM] Disables PTT in SkuMgr. Warning! PTT/ Discrete TPM will be

disabled and all data saved on it will be lost.

► ME Debug Configuration



This setting enables/ disables the HECI (Host Embedded Controller Interface) send/ receive timeouts.

» Force ME DID Init Status

Forces the DID initialization status value.

» CPU Replaced Polling Disable

Setting this option disables the CPU replacement polling loop.

» HECI Message Check Disable

This setting disables message check for BIOS boot path when sending messages.

» MBP HOB Skip

Setting this option will skip MBP HOB.

» HECI2 Interface Communication

This setting Adds/ Removes HECI2 device from PCI space.

» KT Device

This setting enables/ disables KT Device.

» End of Post Message

This setting enables/ disables End of Post Message sent to ME.

» DOI3 Setting for HECI Disable

Setting this option disables setting DOI3 bit for all HECI devices.

» MCTP Broadcast Cycle

This setting enables/ disables Management Component Transport Protocol (MCTP) Broadcast Cycle.

► Anti-Rollback SVN Configuration



» Automatic HW-Enforced Anti-Rollback SVN

Setting this option enables will automatically activate the hardware-enforced Anti-Rollback security version (HW ERB SVN). Once ME FW was successfully run on a platform, FW with lower ARB-VN will be blocked from execution.

» Set HW-Enforced Anti-Rollback for Current SVN

Enable HW ERB mechanism for current ARB SVN value. FW with lower ARB-SVN will be blocked from execution. The value will be restored to disable after the command is sent.

Trusted Computing



► Security Device Support

This item enables or disables BIOS support for security device. When set to [Disable], the OS will not show security device.

► SHA256/ SHA384 PCR Bank

These settings enable/disable the SHA256 PCR Bank and SHA384 PCR Bank.

► Pending Operation

When **Security Device Support** is set to [Enable], **Pending Operation** will appear. It is advised that users should routinely back up their TPM secured data.

Clear all data secured by TPM. [TPM Clear]

Discard the selection. [None]

▶ Platform Hierarchy, Storage Hierarchy, Endorsement Hierarchy

These settings enable/disable the Platform Hierarchy, Storage Hierarchy and Endorsement Hierarchy.

Physical Presence Spec Version

This settings show the Physical Presence Spec Version.

► TPM 2.0 Interface Type

This setting shows the TPM 2.0 Interface Type.

► PH Randomization

This setting enables/disables PH Randomization.

▶ Device Select

Select your TPM device throgh this setting.


Serial Port Console Redirection



► Console Redirection

Console Redirection operates in host systems that do not have a monitor and keyboard attached. This setting enables/disables the operation of console redirection. When set to [Enabled], BIOS redirects and sends all contents that should be displayed on the screen to the serial COM port for display on the terminal screen. Besides, all data received from the serial port is interpreted as keystrokes from a local keyboard.

► Console Redirection Settings (COM1)



» Terminal Type

To operate the system's console redirection, you need a terminal supporting ANSI terminal protocol and a RS-232 null modem cable connected between the host system and terminal(s). You can select emulation for the terminal from this setting.

Extended ASCII character set. [ANSI]

[VT100] ASCII character set.

Extends VT100 to support color, function keys, etc. [VT100Plus]

[VT-UTF8] Uses UTF8 encoding to map Unicode characters onto one or

more bytes.

» Bits per second, Data Bits, Parity, Stop Bits

These setting specifies the transfer rate (bits per second, data bits, parity, stop bits) of Console Redirection.

» Flow Control

Flow control is the process of managing the rate of data transmission between two nodes. It's the process of adjusting the flow of data from one device to another to ensure that the receiving device can handle all of the incoming data. This is particularly important where the sending device is capable of sending data much faster than the receiving device can receive it.

» VT-UTF8 Combo Key Support

This setting enables/disables the VT-UTF8 combination key support for ANSI/VT100 terminals.

» Recorder Mode, Resolution 100x31

These settings enable/disable the recorder mode and the resolution 100x31.

» Putty Keypad

PuTTY is a terminal emulator for Windows. This setting controls the numeric keypad for use in PuTTY.

Secure Boot



► Secure Boot

Secure Boot function can be enabled only when the Platform Key (PK) is enrolled and running accordingly.

► Secure Boot Mode

Selects the secure boot mode. This item appears when **Secure Boot** is enabled.

[Standard] The system will automatically load the secure keys from BIOS.

Allows user to configure the secure boot settings and manually [Custom]

load the secure keys.

► Restore Factory Keys

Allows you to restore all factory default keys. The settings will be applied after reboot or at the next reboot. This item appears when "Secure Boot Mode" sets to [Custom].


Reset to setup Mode

Allows you to delete all the Secure Boot keys (PK,KEK,db,dbt,dbx). The settings will be applied after reboot or at the next reboot. This item appears when "Secure Boot Mode" sets to [Custom].

► Key Management

Press Enter key to enter the sub-menu. Manage the secure boot keys. This item appears when "Secure Boot Mode" sets to [Custom].

Chipset



► DVMT Total Gfx Mem

This setting specifies the memory size for DVMT.

DVMT Pre-Allocated

This setting defines the DVMT pre-allocated memory. Pre-allocated memory is the small amount of system memory made available at boot time by the system BIOS for video. Pre-allocated memory is also known as locked memory. This is because it is "locked" for video use only and as such, is invisible and unable to be used by the operating system.

► Type Select

Set your video signal interface as LVDs or eDP.

» LVDS Panel Type

This setting specifies the LCD Panel's resolution and distribution formats. The item will display when Panel 1 Type is set to LVDs.

Power



Restore AC Power Loss

This setting specifies whether your system will reboot after a power failure or interrupt occurs. Available settings are:

[Power Off] Leaves the computer in the power off state.

[Power On] Leaves the computer in the power on state.

[Last State] Restores the system to the previous status before power failure or

interrupt occurred.

► Deep Sleep Mode

The setting enables/disables the S4 + S5 power saving mode.

OnChip USB

The item allows the activity of the OnChip USB device to wake up the system from S4/S5 sleep state.


► LAN/ PCIE PME

Enables or disables the system to be awakened from the power saving modes when activity or input signal of Intel LAN device and onboard PCIE PME is detected.

► RTC

When [Enabled], your can set the date and time at which the RTC (real-time clock) alarm awakens the system from suspend mode.

Save & Exit



Save Changes and Reset

Save changes to CMOS and reset the system.

Discard Changes and Exit

Abandon all changes and exit the Setup Utility.

Discard Changes

Abandon all changes.

Load Optimized Defaults

Use this menu to load the default values set by the motherboard manufacturer specifically for optimal performance of the motherboard.

Save as User Defaults

Save changes as the user's default profile.

Restore User Defaults

Restore the user's default profile.

Launch EFI Shell from filesystem device

This setting helps to launch the EFI Shell application from one of the available file system devices.

Audio Driver Setup

Installing the Intel® SST Audio Driver

The Intel® Smart Sound Technology (Intel® SST) driver enables high-quality audio processing, voice interactions, and microphone functionality on your device. This section guides you through installing the Intel® SST driver and the associated audio codec driver on a Windows operating system.



Important

To enable the Realtek audio codec to function under the Intel® Smart Sound Technology (Intel® SST) framework on your PC, the Intel® SST driver **must be installed** before the Realtek audio driver.

Prerequisites

- Operating System: Windows 10 or Windows 11 (64-bit).
- Administrative Privileges: Administrator access to the PC.
- Internet Connection: Required for driver downloads.

Key Reminder

Install the Intel® SST driver before the Realtek audio driver. The Intel® SST driver provides the necessary framework to prevent errors.

Installation Steps

- 1. Download the Intel® SST Driver:
 - Visit the MSI Support Page for your IPC model.
 - Download the Intel® SST driver (.zip) and save it to a known location.
- 2. Locate and Extract the Driver File:
 - Right-click and select Extract All to a folder.
- 3. Sort and Identify the .inf File:
 - Open the extracted folder and sort contents by **Type** to group .inf files.
 - Locate the Intel[®] SST .inf file.
- 4. Install the Driver:
 - Right-click all the .inf file and select Install.
 - If prompted by User Account Control (UAC) window, click "Yes" to allow changes.
 - On Windows 10, click "OK" when "The operation completed successfully" appears.
- 5. Restart your PC to apply the driver.
- 6. Verify Intel® SST Installation:
 - Open **Device Manager** (Windows + X > Device Manager).
 - Expand Sound, Video, and Game Controllers and confirm that Intel® Smart Sound Technology (Intel® SST) Audio Controller is listed without a yellow exclamation mark.



• Note: After completing Intel® SST installation, the "Intel High Definition Audio" item will be shown at "Other devices" of Device Manager. Please install the audio codec driver for this.

GPIO WDT Programming

This chapter provides GPIO (General Purpose Input/ Output) and WDT (Watch Dog Timer) programming guide.

Abstract

In this section, code examples based on C programming language provided for customer interest. Inportb, Outportb, Inportl and Outportl are basic functions used for access IO ports and defined as following.

Inportb: Read a single 8-bit I/O port.

Outportb: Write a single byte to an 8-bit port.

Inportl: Reads a single 32-bit I/O port.

Outportl: Write a single long to a 32-bit port.

General Purpose IO

1. General Purposed IO - GPIO/DIO

The GPIO port configuration addresses are listed in the following table:

Name	IO Port	IO address	Name	IO Port	IO address
N_GPI0	0xA0A	Bit 0	N_GPO0	0xA0A	Bit 4
N_GPI1	0xA0A	Bit 1	N_GPO1	0xA0A	Bit 5
N_GPI2	0xA0A	Bit 2	N_GPO2	0xA0A	Bit 6
N_GPI3	0xA0A	Bit 3	N_GPO3	0xA0A	Bit 7

1.1 Set output value of GPO

- 1. Read the value from GPO port.
- 2. Set the value of GPO address.
- 3. Write the value back to GPO port.

```
Example: Set N_GPO0 output "high"
    val = Inportb (OxAOA);
                                     // Read value from N_GPO0 port.
    val = val | (1<<4);
                                     // Set N GPOO address (bit 4) to 1 (output "high").
    Outportb (0xA0A, val);
                                       // Write back to N_GPO0 port.
Example: Set N GPO1 output "low"
    val = Inportb (0xA0A);
                                     // Read value from N_GPO1 port.
    val = val & (~(1<<5));
                                     // Set N_GPO1 address (bit 5) to 0 (output "low").
    Outportb (0xA0A, val);
                                     // Write back to N GPO1 port.
```

1.2 Read input value from GPI

- 1. Read the value from GPI port.
- 2. Get the value of GPI address.

```
Example: Get N_GPI2 input value.
```

```
val = Inportb (0xA0A);
                                  // Read value from N_GPI2 port.
                                   // Read N_GPI2 address (bit 2).
val = val & (1 << 2);
if (val)
          printf ("Input of N_GPI2 is High");
           printf ("Input of N_GPI2 is Low");
else
```

Watchdog Timer

2. Watchdog Timer - WDT

The base address (WDT BASE) of WDT configuration registers is 0xA10.

2.1 Set WDT Time Unit

```
val = Inportb (WDT BASE + 0x05);
                                      // Read current WDT setting
val = val | 0x08:
                                        // minute mode. val = val & 0xF7 if second mode
Outportb (WDT BASE + 0x05, val);
                                        // Write back WDT setting
```

Set WDT Time 2.2

```
Outportb (WDT BASE + 0x06, Time);
                                  // Write WDT time, value 1 to 255.
```

2.3 **Enable WDT**

```
val = Inportb (WDT_BASE + 0x0A);
                                       // Read current WDT_PME setting
val = val | 0x01;
                                       // Enable WDT OUT: WDOUT_EN (bit 0) set to 1.
Outportb (WDT_BASE + 0x0A, val);
                                       // Write back WDT setting.
val = Inportb (WDT BASE + 0x05);
                                       // Read current WDT setting
val = val | 0x20;
                                       // Enable WDT by set WD EN (bit 5) to 1.
Outportb (WDT BASE + 0x05, val);
                                       // Write back WDT setting.
```

2.4 Disable WDT

```
val = Inportb (WDT BASE + 0x05);
                                       // Read current WDT setting
val = val & 0xDF;
                                        // Disable WDT by set WD_EN (bit 5) to 0.
Outportb (WDT BASE + 0x05, val);
                                        // Write back WDT setting.
```

2.5 **Check WDT Reset Flag**

If the system has been reset by WDT function, this flag will set to 1.

```
val = Inportb (WDT BASE + 0x05);
                                         // Read current WDT setting.
val = val & 0x40;
                                         // Check WDTMOUT STS (bit 6).
if (val)
       printf ("timeout event occurred");
else
         printf ("timeout event not occurred");
```

2.6 **Clear WDT Reset Flag**

```
val = Inportb (WDT BASE + 0x05);
                                      // Read current WDT setting
val = val | 0x40;
                                       // Set 1 to WDTMOUT_STS (bit 6);
Outportb (WDT_BASE + 0x05, val);
                                       // Write back WDT setting
```