

EMX-MTLP

Onboard Meteor LakeU & H series Intel® BGA Processor
(TDP: 15~28W) Thin Mini ITX motherboard

User's Manual

1st Ed – 19 May 2025

Copyright Notice

Copyright © 2025 Avalue Technology Inc., ALL RIGHTS RESERVED.

Document Amendment History

Revision	Date	By	Comment
1 st	May 2025	Avalue	Initial Release

Declaration of Conformity



This device complies with part 15 FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class "a" digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CE statement

The product(s) described in this manual complies with all application European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

Copyright Notice

© 2025 by Avalue Technology Inc. All rights are reserved. No parts of this manual may be copied, modified, or reproduced in any form or by any means for commercial use without the prior written permission of Avalue Technology Inc. All information and specification provided in this manual are for reference only and remain subject to change without prior notice.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows is registered trademark of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Disclaimer

This manual is intended to be used as a practical and informative guide only and is subject

EMX-MTLP User's Manual

to change without notice. It does not represent a commitment on the part of Avalue. This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

A Message to the Customer

Avalue Customer Services

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support and Assistance

1. Visit the Avalue website at <https://www.avalue.com/> where you can find the latest information about the product.
2. Contact your distributor or our technical support team or sales representative for technical support if you need additional assistance. Please have following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

To receive the latest version of the user's manual; please visit our Web site at:

www.avalue.com

Product Warranty (Returns & Warranties policy)

1. Purpose

Avalue establishes the following maintenance specifications and operation procedures for providing the best quality of service and shortened repair time to our customers.

2. Warranty

2.1 Warranty Period

Avalue endeavors to offer customers the most comprehensive post-sales services and protection; besides offering a 2-year warranty for standard Avalue products, an extended warranty service can also be provided based on additional request from the customer. Within the warranty period, customers are entitled to receive comprehensive and prompt repair and warranty.

Standard products manufactured by Avalue are offered a 2-year warranty, from the date of delivery from Avalue. For ODM/OEM products manufactured by Avalue or PCBA with conformal coating, will follow up the define warranty of the agreement, otherwise will be offered 1-year warranty for ODM/OEM products but non-warranty for PCBA with conformal coating. For outsourcing parts kit by Avalue (ex: Motherboard, LCD touch panel, CPU, RAM, HDD) are offered a 6-month warranty, and Mobile/Tablet PC battery are offered a warranty of the half year, from the date of delivery by Avalue. Products before the mass production stage, i.e. engineering samples are not applied in this warranty or service policy. For extended warranty and cross-territory services, product defects resulting from design, production process or material are covered by the pre-set warranty period after the date of delivery from Avalue. For non-Avalue products, the product warranty and repair time shall be based on the service standards provided by the original manufacturer; in principle Avalue will provide these products a warranty service for no more than one year.

2.2 Maintenance services within the warranty period

In the case of Avalue product DOA (Defect-on-Arrival) when the customer finds any defect within 1 month after the delivery, Avalue will replace it with a new product in a soonest way. Except for custom products, once the customer is approved of a Cross-Shipment Agreement, which allows for delivery a new product to the customer before receiving the defective one, Avalue will immediately proceed with new product replacement for the said DOA case. On validation of the confirmed defect, Avalue is entitled to reserve the right whether to provide a new product for replacement. For the returned defective new product, it is necessary to verify that there shall be no bruise, alteration, scratch or marking to the appearance, and that none of the delivered accessories missing; otherwise, the customer will be requested to pay a processing fee. On the other hand, if the new product defect is resulting from incorrect configuration or erroneous use by the user instead of any problem of the hardware itself, the customer will also be requested to pay for relevant handling fees.

EMX-MTLP User's Manual

As for other conditions, Avalue will handle defects by way of repair. The customer will be requested to send the defective product to an Avalue authorized service center, and Avalue will return the repaired product back to the customer as soon as possible.

2.3 Ruling of an out-of-warranty defect

The following situations are not included in the warranty:

- The warranty period has expired.
- Product has been altered or its label of the serial number has been torn off.
- Product functionality issues resulting from improper use by the user, unauthorized dismantle or alteration, unfit operation environment, improper maintenance, accident or other causes. Avalue reserves the right for the ruling of the aforementioned situations.
- Product damage resulting from lightning, flood, earthquake or other calamities.
- The warranty rules of non-Avalue products and accessories shall be in accordance with standards set up by the original manufacturer. These products and accessories include RAM, HDD, FDD, CD-ROM, CPU, FAN, etc.
- Product upgrade request or test request submitted by the customer after expiration of the warranty.
- PCBA with conformal coating.
- Avalue semi-product and outsourced products without Avalue serial number.
- Products before the mass production stage, i.e. engineering samples.

3. Procedure for sending for repair

3.1 Attain a RMA number

A customer's rejected product returned for repair shall have a RMA (Return Merchandise Authorization) number. Without a RMA number, Avalue will not provide any repair service for the rejected product, and the product will be returned to the customer at customer's cost. Avalue will not issue any notice for the return of the product.

Each returned product for repair shall have a RMA number, which is simply the authorization of the return for repair; it is not a guarantee that the returned goods can be repaired or replaced. For applying for a RMA number, the customer may enter the eRMA webpage of Avalue <https://www.avalue.com/en/member> and log-in with an account number and a password authorized by Avalue. The system will then automatically issue a RMA number.

When applying for the RMA number, it is essential to fill in basic information of the customer and the product, together with detailed description of the problem encountered. If possible, avoid using ambiguous words such as "does not work" or "problematic". Without a substantial description of the problem, it is hard to start the repair and will cause prolonged repair time. Lacking detailed statement of fault steps also makes the problem hard to be identified, sometimes resulting in second-time repairs.

In case the customer can't define the cause of problem, please contact Avalue application engineers. Sometimes when the problem can be resolved even before the customer sends back the product.

On the other hand, if the customer only returns the key parts to Avalue for repair, it is necessary that the serial number of the entire unit is given in the "Problem Description" field, so that warranty period can be ruled accordingly; or Avalue will handle the case as an Out-of- warranty case.

3.2 Return of faulty product for repair

It is recommended that the customer not to return the accessories (manual, connection cables, etc.) with the products for repair, devices such as CPU, DRAM, CF memory card, etc., shall also be removed from the faulty goods before return for repair. If these devices are relevant to described repair problems and necessary to be returned with the goods; please clearly indicate the items included in the eRMA application form. Avalue shall not be responsible for any item that is not itemized. Moreover, make sure the problem(s) are detailed in the "Problem Description" field.

In the list of delivery, the customer may fill-in a value which is lower than the actual value, to prevent customs levying a higher tax over the excessive value of the return goods. The customer shall be held responsible for extra fees caused by this. We strongly recommend that "Invoice for customs purpose only with no commercial value" be indicated on the delivery note. Also for the purpose of expedited handling, please printout the RMA number and put it in the carton, also indicate the number outside of the carton, with the recipient addressing to Avalue RMA Department.

When returning the defective product, please use an anti-static bag or ESD material to pack it properly. In case of improper packing resulting in damages in the transportation process, Avalue reserves the right to reject the un-repaired faulty good at the customer's costs. Furthermore, it is suggested that the faulty goods shall be sent via a door-to-door courier service. The customer shall be held responsible for any customs clearance fee or extra expenses if Air-Cargo is used for the delivery.

In case of a DOA situation of a new product, Avalue will be responsible for the product and the freight. If the faulty goods are within the warranty period, the sender will take responsibility for the freight. For an out-of-warranty case, the customer shall be responsible for the freight of both trips.

3.3 Maintenance Charge

Avalue will charge a moderate repair fee for the following conditions:

- The warranty period has expired.
- Product has been altered or its label of the serial number has been torn off.
- Product functionality issues resulting from improper use by the user, unauthorized dismantle or alteration, unfit operation environment, improper maintenance, accident

EMX-MTLP User's Manual

or other causes. Avalue reserves the right for the ruling of the aforementioned situations.

- Product damage resulting from lightning, flood, earthquake or other calamities.
- The warranty rules for non-Avalue products and accessories shall be in accordance with standards set up by the original supplier. These products and accessories include RAM, HDD, FDD, CD-ROM, CPU, FAN, etc.
- Product upgrade request or test request submitted by the customer after expiry of the warranty.
- PCBA with conformal coating.
- Avalue semi-product and outsourced products without Avalue serial number
- Products before the mass production stage, i.e. engineering samples.
- In case the products received are examined as NPF (No Problem Found) within the warranty period, the customer shall be responsible for the freight of both trips.
- Please contact your local distributor to examine in advance to prevent unnecessary freight cost.

For system failure of out-of-warranty products, Avalue will provide a quotation prior to repair service. When the customer applies for the cost, please refer to the Quotation number. In case the customer does not return the DOA product that has already been replaced by a new one, or the customer does not sign back the quotation of the out-of-warranty maintenance, Avalue reserves the right of whether or not to provide the repair service. In case the customer does not reply in 3 months, Avalue shall directly scrap or return the product back to customer at customer's cost without further notice to the customer.

3.4 Maintenance service of phased-out products

For servicing phased-out products, Avalue provides an extended period, starting the date of phase-out, as a guaranteed maintenance period of such products, for continuance of the maintenance service to meet customer's requirements. In case of unexpected factors causing Avalue to be unable to repair/replace a warranted but phased-out product, Avalue will, depending on the availability, upgrade the product (free of charge with continued warranty period as of the original product), or, give partial refund (based on the length of the remaining warranty period) to solve this kind of problem.

3.5 Maintenance Report

On completion of repair of a defective product, a Maintenance Report indicating the maintenance result and part(s) replaced (if any) will be sent to the customer together with the product. If the customer demands an additional maintenance analysis report, a service fee of various level will be charged depending on the warranty status. In case the analysis result shows that the defect attributes to Avalue's faulty design or process, the analysis fee will be exempted.

4. Service Products

Avalue provides service products to manage with different customer needs. Should you have any need, please consult to Avalue Sales Department.

Defect Analysis Report (DAR)

Avalue provides DAR (Defect Analysis Report) services aiming to elevating customer satisfaction. A DAR includes defect cause identification/verification/suggestion and improvement precautions, with instructions on correct usage for the avoidance of any reoccurrence.

Upgrade Service

Avalue is capable to provide system upgrade service for customization requirements. This upgrade service is applicable for main parts, such as CPU, memory, HDD, SSD, storage devices; also replacements motherboards of systems. Please contact Avalue sales for details to evaluate the possibility of system upgrade service and obtain information of lead time and price.

Safety Instructions

Safety Precautions

Before installing and using this device, please note the following precautions.

1. Read these safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Disconnected this equipment from any AC outlet before cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
8. Use a power cord that has been approved for using with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to

EMX-MTLP User's Manual

avoid damage by transient overvoltage.

12. Never pour any liquid into an opening. This may cause fire or electrical shock.












13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel. If one of the following situations arises, get the equipment checked by service personnel:

- The power cord or plug is damaged.
- Liquid has penetrated into the equipment.
- The equipment has been exposed to moisture.
- The equipment does not work well, or you cannot get it work according to the user's manual.
- The equipment has been dropped and damaged.
- The equipment has obvious signs of breakage.






14. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

15. Equipment intended only for use in a RESTRICTED ACCESS AREA.

Explanation of Graphical Symbols

	Warning	A WARNING statement provides important information about a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Caution	A CAUTION statement provides important information about a potentially hazardous situation which, if not avoided, may result in minor or moderate injury to the user or patient or in damage to the equipment or other property.
	Note	A NOTE provides additional information intended to avoid inconveniences during operation.
		Direct current.
		Alternating current
		Stand-by, Power on
		FCC Certification
		CE Certification
		Follow the national requirements for disposal of equipment.
		Stacking layer limit
		This side up

EMX-MTLP User's Manual

		Fragile Packaging
		Beware of water damage, moisture-proof
		Carton recyclable
		Handle with care
		Follow operating instructions of consult instructions for use.

Disposing of your old product

WARNING:

There is danger of explosion if the battery is mishandled or incorrectly replaced. Replace only with the same type of battery. Do not disassemble it or attempt to recharge it outside the system. Do not crush, puncture, dispose of in fire, short the external contacts, or expose to water or other liquids. Dispose of the battery in accordance with local regulations and instructions from your service provider.

CAUTION:

- Lithium Battery Caution: Danger of explosion if battery is incorrectly replaced. Replace only with same or equivalent type. Dispose batteries according to manufacturer's instructions.
- Disposal of a BATTERY into fire or a hot oven, or mechanically crushing or cutting of a BATTERY, that can result in an EXPLOSION
- Leaving a BATTERY in an extremely high temperature surrounding environment that can result in an EXPLOSION or the leakage of flammable liquid or gas.
- A BATTERY subjected to extremely low air pressure that may result in an EXPLOSION or the leakage of flammable liquid or gas.

Mise en garde!

AVERTISSEMENT : Il existe un risque d'explosion si la batterie est mal manipulée ou remplacée de manière incorrecte. Remplacez uniquement par le même type de batterie. Ne le démontez pas et ne tentez pas de le recharger en dehors du système. Ne pas écraser, percer, jeter au feu, court-circuiter les contacts externes ou exposer à l'eau ou à d'autres liquides. Jetez la batterie conformément aux réglementations locales et aux instructions de votre fournisseur de services.

MISE EN GARDE:

- Pile au lithium Attention : Danger d'explosion si la pile n'est pas remplacée correctement. Remplacer uniquement par un type identique ou équivalent. Jetez les piles conformément aux instructions du fabricant.
- L'élimination d'une BATTERIE dans le feu ou dans un four chaud, ou l'écrasement ou le découpage mécanique d'une BATTERIE, pouvant entraîner une EXPLOSION
- Laisser une BATTERIE dans un environnement à température extrêmement élevée pouvant entraîner une EXPLOSION ou une fuite de liquide ou de gaz inflammable.
- UNE BATTERIE soumise à une pression d'air extrêmement basse pouvant entraîner une EXPLOSION ou une fuite de liquide ou de gaz inflammable.

Content

1. Getting Started	17
1.1 Safety Precautions	17
1.2 Packing List	17
1.3 Manual Objectives	18
1.4 System Specifications	19
1.5 Architecture Overview—Block Diagram	24
2. Hardware Configuration	25
2.1 Product Overview	26
2.2 Jumper and Connector List	27
2.3 Setting Jumpers & Connectors	30
2.3.1 Clear CMOS (JCMOS1)	30
2.3.2 AT/ATX Power Mode Select (JAT1)	30
2.3.3 M.2 KeyB power selector (JM2BP1)	31
2.3.4 COM1 pin9 signal selector (JCOM1_PW1)	31
2.3.5 LVDS Backlight Power Select (JBLS1)	32
2.3.6 LVDS Backlight connector (JBL1)	32
2.3.7 eDP Backlight connector (JBL2)	33
2.3.8 CPU fan connector (JFAN1)	33
2.3.9 System fan connector (JFAN2)	34
2.3.10 SATA Power connector (JSPWR1)	34
2.3.11 Amplifier Wafer (SPK1)	35
2.3.12 ESPI Debug Header (JESPI1)	35
2.3.13 Serial port 1 connector (JCOM1)	36
2.3.14 Serial port 2 connector (JCOM2)	36
2.3.15 Serial port 3~6 connector (JCOM3_1)	37
2.3.16 RTC Battery connector (BT1)	37
2.3.17 4pin ATX Power connector (JPWR2)	38
2.3.18 Serial Port 1 RS485/422 Mode connector (J485-1)	38
2.3.19 USB2.0 connector (JUSB1)	39
2.3.20 USB2.0 connector (JUSB2)	39
2.3.21 USB2.0 connector (JUSB3)	40
2.3.22 Front Audio connector (JFAUD1)	40
2.3.23 JPD connector (JPD1)	41
2.3.24 LAN Active Indicator LED connector (JLAN_LED1)	41
2.3.25 Front Panel connector (JFP1)	42
2.3.26 eDP connector (JEDP1)	42
2.3.27 LVDS connector (JLVDS1)	43

2.3.28	EC_Program (JEC_1).....	43
2.3.29	General purpose I/O connector (JDIO1)	44
2.3.30	BIOS SPI connector (JBIOS1).....	44
3.	Drivers Installation.....	45
3.1	Install Chipset Driver	46
3.2	Install VGA Driver.....	47
3.3	Install ME Driver	48
3.4	Install Audio Driver	49
3.5	Install Serial IO Driver	50
3.6	Install Ethernet Driver.....	52
3.7	Install Smart Sound Technology (ISST) Driver.....	53
3.8	Install Intel@NPU Driver	55
4.	BIOS Setup	57
4.1	Introduction	58
4.2	Starting Setup	58
4.3	Using Setup	59
4.4	Getting Help	60
4.5	In Case of Problems.....	60
4.6	BIOS setup.....	61
4.6.1	Main Menu	61
4.6.1.1	System Date	61
4.6.1.2	System Time.....	62
4.6.2	Advanced Menu	62
4.6.2.1	Connectivity Configuration.....	63
4.6.2.2	CPU Configuration.....	63
4.6.2.2.1	Efficient-core Information.....	64
4.6.2.2.2	Performance-core Information.....	65
4.6.2.3	Power & Performance	65
4.6.2.3.1	CPU - Power Management Control.....	66
4.6.2.4	System Agent (SA) Configuration.....	67
4.6.2.4.1	Memory Configuration	67
4.6.2.4.2	Graphics Configuration	68
4.6.2.4.3	VMD setup menu	68
4.6.2.5	PCIE Configuration	69
4.6.2.5.1	PCI Express Root Port PXPA3(M.2 KeyE).....	69
4.6.2.5.2	PCI Express Root Port PXPB1(M.2 KeyB).....	70
4.6.2.5.3	PCI Express Root Port PXPB3(LAN1-I226)	71
4.6.2.5.4	PCI Express Root Port PXPB4(LAN2-I226)	72
4.6.2.5.5	PCI Express Root Port PXPC(PCIE slot)	73
4.6.2.5.6	PCI Express Root Port PXPD(M.2 KeyM1).....	74

EMX-MTLP User's Manual

4.6.2.5.7	PCI Express Root Port PXPE(M.2 KeyM2)	75
4.6.2.6	PCH-IO Configuration	76
4.6.2.6.1	SATA Configuration	76
4.6.2.6.2	HD Audio Configuration	77
4.6.2.7	PCH-FW Configuration	77
4.6.2.7.1	Firmware Update Configuration	78
4.6.2.8	Trusted Computing	78
4.6.2.9	ACPI Settings	79
4.6.2.10	Board & Panel Configuration	79
4.6.2.10.1	SHOW DMI INFO	81
4.6.2.11	Super IO Configuration	81
4.6.2.11.1	Serial Port 1 Configuration	82
4.6.2.11.2	Serial Port 2 Configuration	82
4.6.2.11.3	Serial Port 3 Configuration	83
4.6.2.11.4	Serial Port 4 Configuration	83
4.6.2.11.5	Serial Port 5 Configuration	84
4.6.2.11.6	Serial Port 6 Configuration	84
4.6.2.12	EC 5782 HW monitor	85
4.6.2.13	S5 RTC Wake Settings	85
4.6.2.14	Serial Port Console Redirection	86
4.6.2.15	USB Configuration	87
4.6.2.16	Network Stack Configuration	88
4.6.2.17	NVMe Configuration	88
4.6.3	Security	89
4.6.4.1	Security Boot	89
4.6.4.1.1	Expert Key Management	90
4.6.4	Boot	90
4.6.5	Save and Exit	91
4.6.5.1	<i>Save Changes and Reset</i>	91
4.6.5.2	<i>Discard Changes and Reset</i>	91
4.6.5.3	<i>Restore Defaults</i>	92
4.6.5.4	<i>UEFI: Innostor\Innostor 1.00, Partition 1 (Innostor Innostor 1.00)</i>	92
4.6.6	MEBx	92
5.	Mechanical Drawing	93

1. Getting Started

1.1 Safety Precautions

Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

1.2 Packing List

Before installation, please ensure all the items listed in the following table are included in the package.

Item	Description	Q'ty
1	EMX-MTLP motherboard	1
2	SATA cable	1
3	SATA power cable	1
4	I/O shield	1
5	Heatsink (only for 125U/15W SKU)	1
6	Graphite Radiator Film (only for 125U/15W SKU)	2

Note:

Before using the motherboard power, ensure the power pinout, cables, and voltage match to avoid equipment damage.



If any of the above items is damaged or missing, contact your retailer.

1.3 Manual Objectives

This manual describes in details Avalue Technology EMX-MTLP Single Board.

We have tried to include as much information as possible, but we have not duplicated information that is provided in the standard IBM Technical References, unless it proved to be necessary to aid in the understanding of this board.

We strongly recommend that you study this manual carefully before attempting to set up EMX-MTLP or change the standard configurations. Whilst all the necessary information is available in this manual, we would recommend that unless you are confident, you contact your supplier for guidance.

Please be aware that it is possible to create configurations within the CMOS RAM that make booting impossible. If this should happen, clear the CMOS settings, (see the description of the Jumper Settings for details).

If you have any suggestions or find any errors regarding this manual and want to inform us of these, please contact our Customer Service department with the relevant details.

1.4 System Specifications

System	
CPU	Onboard Meteor Lake-U & H series Intel® BGA Processor (TDP: 15~28W) H-Series: 28W, U-Series: 15W
BIOS	AMI uEFI BIOS, 256Mbit SPI Flash ROM
I/O Chip	EC-ITE: IT5782VG
System Memory	Two 262-pin DDR5 up to 5600MHz SO-DIMM socket, supports up to 64GB Max
Watchdog Timer	H/W Reset, 1sec. – 65535sec./min.1sec. or 1min. step
H/W Status Monitor	CPU temperature monitoring Voltage monitoring CPU fan speed control
RAID	Intel® VMD RAID 0/1 **supported by identical interface (PCIe or SATA) PCIe interface: 2 x M.2 Key M SATA interface: 2 x SATA port
TPM	Onboard NuvoTon NPCT760AABYX (7.2.3.1) support SPI TPM 2.0
iAMT	Yes
Expansion Slot	
M.2	1 x M.2 Key-B 2242/3042/3052 with USB3.2 Gen1x1 (from USB Hub IC), PCIe x1 Signal, Nano SIM card slot for LTE/IO Cards support WWAN+GNSS or PCIe x1 SSD, and USB2.0. * Only supports one SIM card * Does not support I2S and PCM functions * Only supports one SIM card (co-lay 1 x 10pin FPC connector for uSIM card adapter) * 1 x 1 x 3 pin, pitch 2.00mm connector for M.2 module card 3.3V and 3.8V selection (Jumper default: 1-2 for 3.3V) 1 x M.2 Key E 2230 support Wi-Fi module and (1 x PCIe x1 & USB 2.0 Signal) 2 x M.2 Key M 2280 (PCIe x4) slot for storage NVMe SSD
PCIe	1 x PCIe x4 Gen4 slot with PClex8 slot
Storage	
M.2	2 x M.2 Key M 2280 (PCIe x4) slot for storage NVMe SSD
SATA	2 x SATA III
Edge I/O	
LAN	1 x Intel® i226-LM 2.5 Gigabit Ethernet Controller

EMX-MTLP User's Manual

	1 x Intel® i226-V 2.5 Gigabit Ethernet Controller
USB	1 x USB Type C on rear I/O, 5V@3A, support USB3.2 Gen2x2 (20G), no PCIe signal. 2 x USB3.2 Gen2 Type A, +5VSB/0.9A 2 x USB3.2 Gen1 on rear I/O (from USB Hub IC)
DP	2 x DP (1 from DP connector, 1 from Type C)
HDMI	2 x HDMI2.0
Audio	Line-out & Mic-in
DC Input	Screw type DC in connector
Onboard I/O	
COM	COM 1: COM 1 support RS- RS232/422/485 connector, with / RI & +5V & +12V Supported and RS422/485 by BIOS setting. 2 x 5 pin, pitch 2.00mm connector for COM1: support RS-232 connector (JCOM1) 2 x 3 pin, pitch 2.00mm header for COM1: support RS-232 connector, Pin 9 with / RI & +5V & +12V Supported (JCOM1_PW) Max: 1A 2 x 3 pin, pitch 2.00mm pin header for COM1: support RS422/485 connector, Pin 5 with / +5V Supported. (J485-1) Max: 1A COM2: 2 x 5 pin, pitch 2.00mm pin header for COM2 support RS-232 connector (JCOM2) COM3 to 6: 2 x 20 pin, pitch 2.00mm pin header for COM3~6: support RS-232 connector (JCOM3_6)
USB	3 x 2 x 5 pin, pitch 2.54mm connector for 6 USB 2.0, +5VSB/0.5A (each port)
GPIO	2 x 10 pin, pitch 2.00mm pin header for 16-bit GPIO, +3.3S level SMBUS (JDIO1) (Max. 1A output)
SATA Power	1 x 4 pin, pitch 2.54mm Wafer for 5/12V Power SATA Power,1A
CPU/System FAN	1 x 4 pin, pitch 2.54mm Wafer for CPU fan connector with smart fan function supported 1 x 3 pin, pitch 2.54mm Wafer for System fan connector
Buzzer	Onboard BUZZER 5V 85dB SMD
Front Panel	2 x 5 pin, pitch 2.54mm pin header for Front panel
RTC Battery	1 x 2 pin, pitch 1.25mm Wafer horizontal type connector for CR2450
AT/ATX Selector	1 x 3 pin, pitch 2.54mm pin header for AT/ATX jumper (JAT1)
Clear CMOS	1 x 3 pin, pitch 2.00mm pin header for CMOS clear (JCMOS1)
LVDS	2 x 20 pin, pitch 1.25mm Wafer connector for LVDS (JLVDS1) 2 x 10 pin, pitch 1.25mm Wafer connector for eDP (JEDP1)
LCD Backlight	1 x 3 pin, pitch 2.00mm Wafer connector LCD backlight brightness adjustment

Brightness	(PWM/DC) (Jumper default: 1-2 for PWM) (JBLS1)				
LCD Inverter	2 x 1 x 5 pin, pitch 2.00mm Wafer connector for LCD inverter backlight connector (JBL1 for LVDS ; JBL2 for eDP)				
BIOS SPI	2 x 4 pin, pitch 2.00mm pin header for BIOS SPI (JBIOS1)				
eSPI	2 x 6 pin, pitch 2.00mm connector for eSPI debug (JESPI1)				
EC Debug	1 x 3 pin, pitch 2.00mm connector for EC internal flash (JEC_1)				
Audio	2 x 6 Pin, pitch 2.54mm (black color pin header for MIT)				
DC-Input	DC in +12V~24V (screw type)				
Amp Connector	1 x 4 pin, pitch wafer 2.00mm connector for 6W x 2 Speaker (SPK1)				
Other	2 x 4 pin, pitch 2.00mm pin header for LAN Activity Indicator LED (JLAN_LED1) 8~9mA				
Display					
Graphic Chipset	Intel® Xe LPG Graphics				
Spec. & Resolution	2 x HDMI 2.0: 3840 x 2160@60 Hz(based on DQV actual test dated 2024/9/13) 1 x DP1.4a: Max: 7680 x 4320@30 Hz 1 X USB Type C supports 3840 x 2160@60Hz based on actual test. LVDS: 1920 x 1080 Dual channel 18/24-bits LVDS (Chrontel CH7511B eDP to LVDS) eDP1.2: Max 4096 x 2304@60 Hz				
Multiple Display	Quadruple Independent Display: 2 x HDMI, DP, Type-C, LVDS, eDP				
Audio					
Audio Codec	Realtek ALC888S audio codec				
Amplifier	TI TPA3113D2PWP Stereo Class-D 6W x 2 Audio Amplifier				
Ethernet					
LAN Chipset	1 x Intel® i226-LM 2.5 Gigabit Ethernet Controller 1 x Intel® i226-V 2.5 Gigabit Ethernet Controller				
LAN Spec.	10/100/1000 Base-Tx GbE compatible & 2.5 Gigabit Ethernet				
LED Indicator		Max. 1G LAN Port			
		ACT/LINK		SPEED	
		LED	Definition	LED	Definition
		Light Off	No Link	Solid Orange	1G
		Solid Yellow	Connection	Solid Green	100M
		Yellow Flashing	Activity	Light Off	10M
		Max. 2.5G LAN Port			
		ACT/LINK		SPEED	
			Definition	LED	Definition
		Light Off	No Link	Solid Orange	2.5G

EMX-MTLP User's Manual

	<table><tr><td>Solid Yellow</td><td>Connection</td><td>Solid Green</td><td>1G/100M</td></tr><tr><td>Yellow Flashing</td><td>Activity</td><td>Light Off</td><td>10M</td></tr></table>	Solid Yellow	Connection	Solid Green	1G/100M	Yellow Flashing	Activity	Light Off	10M
Solid Yellow	Connection	Solid Green	1G/100M						
Yellow Flashing	Activity	Light Off	10M						
Mechanical & Environmental Specification									
Power Requirement	DC in +12V ~ +24V								
ACPI	Single power ATX Support S0, S4, S5 ACPI 5.0 Compliant								
Power Mode	AT / ATX mode Switchable Through Jumper								
Operating Temp.	<ul style="list-style-type: none">15W CPU SKU support: 0~55°C28W CPU SKU support: 0~50°C, heatsink with FAN integrated w/ HDD & SSD, ambient with 0.5 m/s Air flow								
Storage Temp.	-40~ +75°C								
Operating Humidity	40°C @ 95% Relative Humidity, Non-condensing								
Size (L x W)	6.7" x 6.7" (170mm x 170mm)								
Weight	<ul style="list-style-type: none">15W: 510g (shipping with heatsink)28W: 273g (shipping w/o cooler)								
Vibration Test	<p><u>Package Vibration Test</u></p> <p>Reference IEC60068-2-64 Testing procedures</p> <p>Test Fh: Vibration broadband random Test</p> <ol style="list-style-type: none">1. PSD: 0.026G²/Hz, 2.16 Grms2. Non-operation mode3. Test Frequency: 5-500Hz4. Test Axis: X,Y and Z axis5. 30 min. per each axis6. IEC 60068-2-64 Test:Fh <p><u>Random Vibration Operation</u></p> <p>Reference IEC60068-2-64 Testing procedures</p> <p>Test Fh : Vibration broadband random Test</p> <ol style="list-style-type: none">1. PSD: 0.00454G²/Hz, 1.5 Grms2. Operation mode3. Test Frequency : 5-500Hz4. Test Axis : X,Y and Z axis5. 30 minutes per each axis6. IEC 60068-2-64 Test:Fh								


	<u>Random Vibration Non Operation</u> Reference IEC60068-2-64 Testing procedures Test Fh : Vibration broadband random Test 1. PSD: 0.01818G ² /Hz, 3.0 Grms 2. Non Operation mode 3. Test Frequency : 5-500Hz 4. Test Axis : X,Y and Z axis 5. 30 minutes per each axis 6. IEC 60068-2-64 Test:Fh
Drop Test	<u>Packing Drop</u> Reference ISTA 2A, Method : IEC-60068-2-32 Test: Ed Drop Test 1 One corner , three edges, six faces 2 ISTA 2A, IEC-60068-2-32 Test:Ed
OS Information	Win11 64bit Linux



Note: Specifications are subject to change without notice.



1.5 Architecture Overview—Block Diagram

The following block diagram shows the architecture and main components of EMX-MTLP.



2. Hardware Configuration


2.1 Product Overview



2.2 Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board's jumpers and connectors.

Jumpers

Label	Function	Note
JCMOS1	Clear CMOS	3 x 1 header, pitch 2.00mm
JAT1	AT/ATX Power Mode Select	3 x 1 header, pitch 2.54mm
JM2BP1	M.2 KeyB power selector	3 x 1 header, pitch 2.00mm
JCOM1_PW1	COM1 pin9 signal selector	3 x 2 header, pitch 2.00mm
JBLS1	LVDS Backlight Power Select	3 x 1 header, pitch 2.00mm

Connectors

Label	Function	Note
JBL1	LVDS Backlight connector	5 x 1 wafer, pitch 2.00mm
JBL2	eDP Backlight connector	Note: Matching connector: JST PHR-5
SODIMM1/2	2x 260-pin DDR5 5600MTs SO-DIMM	


EMX-MTLP User's Manual

Socket Supports Up to 64GB		
JFAN1	CPU fan connector	4 x 1 wafer, pitch 2.54mm
JSPWR1	SATA Power connector	4 x 1 wafer, pitch 2.54mm
JFAN2	System fan connector	3 x 1 wafer, pitch 2.54mm
SPK1	Amplifier Wafer	4 x 1 wafer, pitch 2.00mm
JESPI1	ESPI Debug Header	6 x 2 header, pitch 2.00mm
BT1	RTC Battery connector	2 x 1 wafer, pitch 1.25mm
JCOM1	Serial port 1 connector	5 x 2 header, pitch 2.00mm
JCOM2	Serial port 2 connector	5 x 2 header, pitch 2.00mm
JCOM3_1	Serial port 3~6 connector	20 x 2 header, pitch 2.00mm
JPWR2	4pin ATX Power connector	2 x 2 wafer, pitch 4.20mm
J485-1	Serial Port 1 RS485/422 Mode connector	3 x 2 header, pitch 2.00mm
JUSB1/2/3	USB2.0 connector 1/2/3	5 x 2 header, pitch 2.54mm
JFAUD1	Front Audio connector	6 x 2 header, pitch 2.54mm
JPD1	JPD connector	4 x 2 header, pitch 2.00mm
JLAN_LED1	LAN Active Indicator LED connector	4 x 2 header, pitch 2.00mm
JFP1	Front Panel connector	5 x 2 header, pitch 2.54mm
JBIOS	BIOS SPI connector	4 x 2 header, pitch 2.00mm
JEC_1	EC_Program	3 x 1 header, pitch 2.00mm
JDIO1	General purpose I/O connector	10 x 2 header, pitch 2.00mm
JLVDS1	LVDS connector	20 x 2 wafer, pitch 1.25mm Note: Matching connector: Hirose DF-40DS-1.25C
JEDP1	eDP connector	10 x 2 wafer, pitch 1.25mm Note: Matching connector: Hirose DF-20DS-1.25C
M2KM1	M.2 2280 TYPE M Slot	
M2KM2	M.2 2280 TYPE M Slot	
M2KB1	M.2 2242/3042/3052 Type B Slot	
M2KE1	M.2 2230 Type E Slot	
JSATA1/2	Serial ATA connector 1/2	
PCIE1	PClex8 connector (for PClex4 signal)	
DCIN1	12~24V Power connector	
DP1	DP connector	


TYPEC1	For DP and USB3.2 Gen2x2, 5V@3A
HDMI1	HDMI connector
USB1/2	USB3.2 connector 1/2
LAN1/2	2 x RJ-45 Ethernet
LOUT1	Line-out audio jack
MIC1	Mic-in audio jack

2.3 Setting Jumpers & Connectors


2.3.1 Clear CMOS (JCMOS1)



Normal*




Clear CMOS




* Default


2.3.2 AT/ATX Power Mode Select (JAT1)



ATX*




AT




* Default

2.3.3 M.2 KeyB power selector (JM2BP1)



3.8V*




3.38V




* Default


2.3.4 COM1 pin9 signal selector (JCOM1_PW1)




RI*



+5V




+12V




* Default


2.3.5 LVDS Backlight Power Select (JBL51)



PWM*





DC





* Default

2.3.6 LVDS Backlight connector (JBL1)





Signal	PIN
+5V	5
LVDS_BKLADJ	4
LVDS_BKLTEN	3
GND	2
+12V	1

2.3.7 eDP Backlight connector (JBL2)





Signal	PIN
+5V	5
EDP_BKLADJ	4
EDP_RT_BKLTEN	3
GND	2
+12V	1

2.3.8 CPU fan connector (JFAN1)





Signal	PIN
PWM	4
TACH	3
+12V	2
GND	1

2.3.9 System fan connector (JFAN2)




Signal	PIN
GND	1
+12V	2
TACH	3

2.3.10 SATA Power connector (JSPWR1)





Signal	PIN
+5V	1
GND	2
GND	3
+12V	4

2.3.11 Amplifier Wafer (SPK1)





Signal	PIN
RSPK-	4
RSPK+	3
LSPK-	2
LSPK+	1

2.3.12 ESPI Debug Header (JESPI1)



Signal	PIN	PIN	Signal
ESPI_ALERT1#	12	11	ESPI_RST#
GND	10	9	ESPI_CS1#
ESPI_CLK_80P	8	7	ESPI_IO3_80P
ESPI_CS#	6	5	ESPI_IO2_80P
PLT_RST#_BUF	4	3	ESPI_IO1_80P
+3.3V	2	1	ESPI_IO0_80P



2.3.13 Serial port 1 connector (JCOM1)



Note: Pin9 can be selected by jumper (JCOM1_PW1) to RI / +5V / +12V


Signal	PIN	PIN	Signal
NC	10	9	RI#
CTS#	8	7	RTS#
DSR#	6	5	GND
DTR#	4	3	TXD
RXD	2	1	DCD#

2.3.14 Serial port 2 connector (JCOM2)





Signal	PIN	PIN	Signal
NC	10	9	RI#
CTS#	8	7	RTS#
DSR#	6	5	GND
DTR#	4	3	TXD
RXD	2	1	DCD#

2.3.15 Serial port 3~6 connector (JCOM3_1)





Signal	PIN	PIN	Signal
NC	40	39	RI6#
CTS6#	38	37	RTS6#
DSR6#	36	35	GND
DTR6#	34	33	TXD6
RXD6	32	31	DCD6#
NC	30	29	RI5#
CTS5#	28	27	RTS5#
DSR5#	26	25	GND
DTR5#	24	23	TXD5
RXD5	22	21	DCD5#
NC	20	19	RI4#
CTS4#	18	17	RTS4#
DSR4#	16	15	GND
DTR4#	14	13	TXD4
RXD4	12	11	DCD4#
NC	10	9	RI3#
CTS3#	8	7	RTS3#
DSR3#	6	5	GND
DTR3#	4	3	TXD3
RXD3	2	1	DCD3#

2.3.16 RTC Battery connector (BT1)





Signal	PIN
+VDD_RTC	1
GND	2

2.3.17 4pin ATX Power connector (JPWR2)





Signal	PIN	PIN	Signal
GND	2	4	+V12-24_DCIN
GND	1	3	+V12-24_DCIN

2.3.18 Serial Port 1 RS485/422 Mode connector (J485-1)





Signal	PIN	PIN	Signal
GND	6	5	+5V
422RX-	4	3	422RX+
485TX+	2	1	485TX-

2.3.19 USB2.0 connector (JUSB1)





Signal	PIN	PIN	Signal
+5V	1	2	+5V
DATA-	3	4	DATA-
DATA+	5	6	DATA+
GND	7	8	GND
		10	NC

2.3.20 USB2.0 connector (JUSB2)





Signal	PIN	PIN	Signal
+5V	1	2	+5V
DATA-	3	4	DATA-
DATA+	5	6	DATA+
GND	7	8	GND
		10	NC

2.3.21 USB2.0 connector (JUSB3)





Signal	PIN	PIN	Signal
+5V	1	2	+5V
DATA-	3	4	DATA-
DATA+	5	6	DATA+
GND	7	8	GND
		10	NC

2.3.22 Front Audio connector (JFAUD1)





Signal	PIN	PIN	Signal
FRONT_RIN	1	2	FRONT_LIN
GND	3	4	GND
LINE2_R	5	6	LINE2_L
MIC2_R	7	8	MIC2_L
AMP_DIS_JD	9	10	LINE2_JD
MIC2_JD	11	12	GND

2.3.23 JPD connector (JPD1)



Signal	PIN	PIN	Signal
X_LDO_3V3	1	2	X_SML1_CLK_R
X_EEPROM_I2C_SCL	3	4	X_SML1_DAT_R
X_EEPROM_I2C_SDA	5	6	X_PMCALERT#_R
GND	7	8	GND



2.3.24 LAN Active Indicator LED connector (JLAN_LED1)



Signal	PIN	PIN	Signal
FRONT_LAN1_ACT	1	2	FRONT_LAN1_LINK100_1000#
GND	3	4	FRONT_LAN1_LINK2500#
FRONT_LAN2_ACT	5	6	FRONT_LAN2_LINK100_1000#
GND	7	8	FRONT_LAN2_LINK2500#



EMX-MTLP User’s Manual

2.3.25 Front Panel connector (JFP1)




Function	Signal	PIN	PIN	Signal	Function
HDD LED	HDD_LED+	1	2	PWR_LED+	Power
	HDD_LED-	3	4	PWR_LED-	LED
Reset button	SYS_RST#	5	6	PWRBTN#	Power
	GND	7	8	GND	button
	NC	9			

2.3.26 eDP connector (JEDP1)





Signal	PIN	PIN	Signal
VCC_PAL	19	20	VCC_PAL
TXP2	17	18	HPD
TXN2	15	16	GND
GND	13	14	AUXP
TXP1	11	12	AUXN
TXN1	9	10	GND
GND	7	8	NC
TXP0	5	6	TXP3
TXN0	3	4	TXN3
GND	1	2	GND

2.3.27 LVDS connector (JLVDS1)





Signal	PIN	PIN	Signal
+5V	2	1	+3.3V
+5V	4	3	+3.3V
+5V	6	5	+3.3V
GND	8	7	GND
DATAP0	10	9	DATAP1
DATAN0	12	11	DATAN1
GND	14	13	GND
DATAP2	16	15	DATAP3
DATAN2	18	17	DATAN3
GND	20	19	GND
DATAP4	22	21	DATAP5
DATAN4	24	23	DATAN5
GND	26	25	GND
DATAP6	28	27	DATAP7
DATAN6	30	29	DATAN7
GND	32	31	GND
CLK1P	34	33	CLK2P
CLK1N	36	35	CLK2N
GND	38	37	GND
+12V	40	39	+12V

2.3.28 EC_Program (JEC_1)





PIN	Signal
3	GND
2	EC_SMCLK_DEBUG
1	EC_SMDAT_DEBUG

2.3.29 General purpose I/O connector (JDIO1)



Signal	PIN	PIN	Signal
DI0	1	2	DO0
DI1	3	4	DO1
DI2	5	6	DO2
DI3	7	8	DO3
DI4	9	10	DO4
DI5	11	12	DO5
DI6	13	14	DO6
DI7	15	16	DO7
5V_SMB_CLK	17	18	5V_SMB_DATA
GND	19	20	+5V

2.3.30 BIOS SPI connector (JBIOS1)



Signal	PIN	PIN	Signal
+1.8V	1	2	GND
SPI_ROM_CS#	3	4	SPI_ROM_CLK
SPI_ROM_MISO	5	6	SPI_ROM_MOSI
SPI_HOLD#	7	8	SPI_WP#

3. Drivers Installation

All the drivers are available on Avalue Downloads Area (<https://www.avalue.com/en/support/download>). Type the model name and press Enter to find all the relevant software, utilities, and documentation.

Chipset 1Audio 2Graphics 1LAN 1Other Driver 3ME 1

Chipset

Total 1 Files

No.	Release Date	Title, Description	Operating System	Download
01	2025-05-09	Intel MTL Chipset driver 10.1.19627.8423 Intel MTL Chipset driver 10.1.19627.8423	Windows 11 64bit	

Audio

Total 2 Files

No.	Release Date	Title, Description	Operating System	Download
01	2025-05-09	Realtek Audio Driver 9721.1 Realtek Audio Driver 9721.1	Windows 11 64bit	
02	2025-05-09	Intel(R)_SST_MTL_v20.40.10915.2 Intel(R)_SST_MTL_v20.40.10915.2	Windows 11 64bit	

(For reference only)



Note: Installation procedures and screen shots in this section are for your reference and may not be exactly the same as shown on your screen.


3.1 Install Chipset Driver

All drivers can be found on the Avalue Official Website:


www.avalue.com.




Note: The installation procedures and screen shots in this section are based on Windows 11 operation system.




Step 3. Click Install.



Step1. Click Next.



Step 4. Click Finish to complete setup.




Step 2. Click Accept.

3.2 Install VGA Driver


All drivers can be found on the Avalue Official Website:
www.avalue.com.




Note: The installation procedures and screen shots in this section are based on Windows 11 operation system.




Step 3. Click Accept.




Step1. Click Begin installation.



Step 4.



Step 2. Click I agree.



Step 5. Click Finish to complete setup.


3.3 Install ME Driver

All drivers can be found on the Avalue Official Website:


www.avalue.com.




Note: The installation procedures and screen shots in this section are based on Windows 11 operation system.




Step 3. Click Next.




Step1. Click Next to continue installation.



Step 4.



Step 2. Click Next.



Step 5. Click Finish to complete setup.


3.4 Install Audio Driver

All drivers can be found on the Avalue Official Website:

www.avalue.com.




Note: The installation procedures and screen shots in this section are based on Windows 11 operation system.



Step 3. Click **Finish** to complete setup.



Step1. Click **Next**.



Step 2.


3.5 Install Serial IO Driver

All drivers can be found on the Avalue Official Website:


www.avalue.com.




Note: The installation procedures and screen shots in this section are based on Windows 11 operation system.




Step 3. Click Next.




Step1. Click Next to continue installation.




Step 4. Click Next.



Step 2. Click Next.



Step 5.



Step 6. Click **Finish** to complete setup.


3.6 Install Ethernet Driver

All drivers can be found on the Avalue Official Website:


www.avalue.com.




Note: The installation procedures and screen shots in this section are based on Windows 11 operation system.



Step 3. Click Close.



Step1. Click Install Drivers to continue installation.



Step 2. Click OK.


3.7 Install Smart Sound Technology (ISST) Driver

All drivers can be found on the Avalue Official Website:


www.avalue.com.




Note: The installation procedures and screen shots in this section are based on Windows 11 operation system.




Step1. Click High Definition Audio Controller.




Step 2. Click Action Update driver.



Step 3. Click Browse my computer for drivers.




Step 4. Click Next.




Step 5. Click OK.

EMX-MTLP User's Manual



Step 6.




Step 7. Click **Close** to complete setup.

3.8 Install Intel@NPU Driver


All drivers can be found on the Avalue Official Website:
www.avalue.com.




Note: The installation procedures and screen shots in this section are based on Windows 11 operation system.




Step 2.



Step 3.




Step 4. Click OK.



Step1. Click PCI Device.

EMX-MTLP User’s Manual



Step 5. Click **Close** to complete setup.

4.BIOS Setup

4.1 Introduction

The BIOS setup program allows users to modify the basic system configuration. In this following chapter will describe how to access the BIOS setup program and the configuration options that may be changed.

4.2 Starting Setup

AMI BIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the NVRAM and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing <ESC> or immediately after switching the system on, or

By pressing the <ESC> or key when the following message appears briefly at the left-top of the screen during the POST (Power On Self Test).

Press <ESC> or to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

4.3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Button	Description
↑	Move to previous item
↓	Move to next item
←	Move to the item in the left hand
→	Move to the item in the right hand
Esc key	Main Menu -- Quit and not save changes into NVRAM Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 key	Previous Values
F3 key	Optimized defaults
F4 key	Save & Exit Setup

- **Navigating Through The Menu Bar**

Use the left and right arrow keys to choose the menu you want to be in.



Note: Some of the navigation keys differ from one screen to another.

- **To Display a Sub Menu**

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “➤” pointer marks all sub menus.

4.4 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or the <Enter> key again.

4.5 In Case of Problems

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AMI BIOS supports an override to the NVRAM settings which resets your system to its defaults.


The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both BIOS Vendor and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

4.6 BIOS setup

Once you enter the Aptio Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

4.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.



4.6.1.1 System Date

Use the system date option to set the system date. Manually enter the Month, day and year.

4.6.1.2 System Time


Use the system time option to set the system time. Manually enter the hours, minutes and seconds.




Note: The BIOS setup screens shown in this chapter are for reference purposes only, and may not exactly match what you see on your screen.
Visit the Avalue website (www.avalue.com) to download the latest product and BIOS information.

4.6.2 Advanced Menu

This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.



4.6.2.1 Connectivity Configuration



Item	Options	Description
CNVi Mode	Disable Integrated Auto Detection [Default] ,	This option configures Connectivity. [Auto Detection] means that if Discrete solution is discovered it will be enabled by default. Otherwise Integrated solution (CNVi) will be enabled; [Disable Integrated] disables Integrated Solution. NOTE: When CNVi is present, the GPIO pins that are used for radio interface cannot be assigned to the other native function.

4.6.2.2 CPU Configuration


Use the CPU configuration menu to view detailed CPU specification and configure the CPU.




EMX-MTLP User's Manual

Item	Options	Description
Intel (VMX) Virtualization Technology	Disabled Enabled[Default]	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.
Active Performance-cores	All[Default] /7/6/5/4/3/2/1	Number of P-cores to enable in each processor package. Note: Number of Cores and E-Cores are looked at together. When both are {0,0}, Pcode will enable all cores.
Active Efficient-cores	All[Default] /31/30/29/28/27/26/25/ 24/23/22/21/20/19/18/17/ 16/15/14/13/12/11/10/9/ 8/7/6/5/4/3/2/1/0	Number of E-cores to enable in each processor package. Note: Number of Cores and E-Cores are looked at together. When both are {0,0}, Pcode will enable all cores.


4.6.2.2.1 Efficient-core Information



4.6.2.2.2 Performance-core Information




4.6.2.3 Power & Performance




EMX-MTLP User’s Manual

4.6.2.3.1 CPU - Power Management Control




Item	Options	Description
Boot Max Frequency	Disabled Enabled[Default]	Enable/Disable Boot Maximum Frequency in CPU strap.
Intel(R) SpeedStep(tm)	Disabled Enabled[Default]	Allows more than two frequency ranges to be supported.
Intel(R) Speed Shift Technology	Disabled Enabled[Default]	Enable/Disable Intel(R) Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.
Turbo Mode	Disabled Enabled[Default]	Enable/Disable processor Turbo Mode.
C states	Disabled Enabled[Default]	Enable/Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.
Enhanced C-states	Disabled Enabled[Default]	Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-State.

4.6.2.4 System Agent (SA) Configuration



Item	Options	Description
NPU Device (B0:D11:F0)	Enabled[Default] Disabled	Enable/Disable NPU (Neural Processing Unit) Device.

4.6.2.4.1 Memory Configuration




EMX-MTLP User’s Manual

4.6.2.4.2 Graphics Configuration




Item	Options	Description
Primary Display	Auto[Default] IGFX	Select AUTO set IGD to be Primary Display if no external Graphics Device connected otherwise external Graphics Device detected on first PCIe port will be Primary Display or Select IGFX for IGD to be Primary Display Or Select HG for Hybrid Gfx.

4.6.2.4.3 VMD setup menu




Item	Options	Description
Enable VMD controller	Disabled[Default] Enabled	Enable/Disable VMD controller

4.6.2.5 PCIE Configuration



4.6.2.5.1 PCI Express Root Port PXPA3(M.2 KeyE)



Item	Options	Description
PCI Express Root Port PXPA3	Disabled Enabled[Default]	Control the PCI Express Root Port.
ASPM	Disabled[Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM

EMX-MTLP User's Manual


L1 Substates	Disabled [Default] L1.1 L1.1&L1.2	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3 Gen4 Gen5	Configure PCIe Speed

4.6.2.5.2 PCI Express Root Port PXPB1(M.2 KeyB)



Item	Options	Description
PCI Express Root Port PXPB1	Disabled Enabled [Default]	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM
L1 Substates	Disabled [Default] L1.1 L1.1&L1.2	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3 Gen4 Gen5	Configure PCIe Speed


4.6.2.5.3 PCI Express Root Port PXPB3(LAN1-I226)



Item	Options	Description
PCI Express Root Port PXPB3	Disabled Enabled [Default]	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM
L1 Substates	Disabled [Default] L1.1 L1.1&L1.2	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3 Gen4 Gen5	Configure PCIe Speed


EMX-MTLP User’s Manual

4.6.2.5.4 PCI Express Root Port PXPB4(LAN2-I226)



Item	Options	Description
PCI Express Root Port PXPB4	Disabled Enabled [Default]	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM
L1 Substates	Disabled [Default] L1.1 L1.1&L1.2	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3 Gen4 Gen5	Configure PCIe Speed


4.6.2.5.5 PCI Express Root Port PXPC(PCIE slot)



Item	Options	Description
PCI Express Root Port PXPC	Disabled Enabled [Default]	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM
L1 Substates	Disabled [Default] L1.1 L1.1&L1.2	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3 Gen4 Gen5	Configure PCIe Speed


EMX-MTLP User’s Manual

4.6.2.5.6 PCI Express Root Port PXPDP(M.2 KeyM1)



Item	Options	Description
PCI Express Root Port PXPDP	Disabled Enabled [Default]	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM
L1 Substates	Disabled [Default] L1.1 L1.1&L1.2	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3 Gen4 Gen5	Configure PCIe Speed

4.6.2.5.7 PCI Express Root Port PXPE(M.2 KeyM2)



Item	Options	Description
PCI Express Root Port PXPE	Disabled Enabled [Default]	Control the PCI Express Root Port.
ASPM	Disabled [Default] L0s L1 L0sL1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM
L1 Substates	Disabled [Default] L1.1 L1.1&L1.2	PCI Express L1 Substates settings.
PCIe Speed	Auto [Default] Gen1 Gen2 Gen3 Gen4 Gen5	Configure PCIe Speed

EMX-MTLP User’s Manual

4.6.2.6 PCH-IO Configuration



4.6.2.6.1 SATA Configuration




Item	Options	Description
SATA Controller(s)	Enabled[Default] Disabled	Enable/Disable SATA Device.
Port 0/1	Disabled Enabled[Default]	Enable/Disable SATA Port
SATA Device Type	Hard Disk Drive Solid State Drive[Default]	Identify the SATA port is connected to Solid State Drive or Hard Disk Drive

4.6.2.6.2 HD Audio Configuration



Item	Options	Description
HD Audio	Disabled Enabled[Default]	Control Detection of the HD-Audio device. Disabled = HDA will be unconditionally disabled. Enabled = HDA will be unconditionally enabled.

4.6.2.7 PCH-FW Configuration



Item	Options	Description
ME State	Disabled Enabled[Default]	When Disabled, ME will be put into ME Temporarily Disabled Mode. NOTE: Once this option is changed and saved, it is grayed out to prevent command been sent again before reset.

EMX-MTLP User's Manual

TPM Device Selection	dTPM[Default] PTT	Selects TPM device: PTT or dTPM. PTT – Enables PTT in SkuMgr dTPM 1.2 – Disables PTT in SkuMgr Warning! PTT/dTPM will be disabled and all data saved on it will be lost.
-----------------------------	-----------------------------	---

4.6.2.7.1 Firmware Update Configuration



Item	Options	Description
Me FW Image Re-Flash	Disabled[Default] Enabled	Enable/Disable Me FW Image Re-Flash function.

4.6.2.8 Trusted Computing



Item	Options	Description
Security Device Support	Disable Enable[Default]	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

4.6.2.9 ACPI Settings



Item	Options	Description
Enable Hibernation	Disabled Enabled[Default],	Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may not be effective with some OS.


4.6.2.10 Board & Panel Configuration



EMX-MTLP User's Manual


Item	Options	Description
Active Panel	Disabled Enabled [Default]	Active Internal LVDS (eDP -> Ch7511-to-LVDS)
CH7511 EDID Panel Option	1024x768 24/1 [Default] 800x600 18/1 1024x768 18/1 1366x768 18/1 1024x600 18/1 1280x800 18/1 1920x1200 24/2 1920x1080 18/2 1280x1024 24/2 1440x900 18/2 1600x1200 24/2 1366x768 24/1 1920x1080 24/2 1680x1050 24/2	Port1-EDP to LVDS (Chrotel 7511) Panel EDID Option
Panel Brightness Control Method	BIOS [Default] OS driver	Panel Brightness Control Method. 1. BIOS 2. OS Driver
Panel Brightness	0% 25% 50% 75% 100% [Default]	Select Panel back light PWM duty.
Panel Back Light PWM Frequency	200 [Default] 1k 10k 20k	Select Panel back light PWM Frequency.
Power Off mode(EU 2013/617)	Traditional S5 [Default] Off mode with WOLan1 Off mode w/o WOL(ErP)	Power Off mode (EU 2013/617).
PWR-On After PWR-Fail	Off [Default] On Last start	AC loss resume.
Wake Up by Ring	Disabled Enabled [Default]	Wake Up by Ring from S4/S5
Watch Dog	Disabled [Default] 30 Sec 40 Sec 50 Sec 1 Min 2 Min 10 Min 20 Min	Select WatchDog.
USB Standby Power	Disabled Enabled [Default]	Enabled/Disabled USB Standby Power during S4/S5

4.6.2.10.1 SHOW DMI INFO



4.6.2.11 Super IO Configuration


You can use this item to set up or change the Super IO configuration for serial ports. Please refer to 4.6.2.11.1 ~ 4.6.2.11.6 for more information.



Item	Description
Serial Port 1 Configuration	Set Parameters of Serial Port 1 (COM1).
Serial Port 2 Configuration	Set Parameters of Serial Port 2 (COM2).
Serial Port 3 Configuration	Set Parameters of Serial Port 3 (COM3).
Serial Port 4 Configuration	Set Parameters of Serial Port 4 (COM4).
Serial Port 5 Configuration	Set Parameters of Serial Port 5 (COM5).


Serial Port 6 Configuration	Set Parameters of Serial Port 6 (COM6).
-----------------------------	---

4.6.2.11.1 Serial Port 1 Configuration




Item	Options	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
UART 232 422 485	UART 232[Default], UART 422, UART 485	Change the Serial Port as RS232/422/485

4.6.2.11.2 Serial Port 2 Configuration




Item	Options	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).

4.6.2.11.3 Serial Port 3 Configuration



Item	Options	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).


4.6.2.11.4 Serial Port 4 Configuration



EMX-MTLP User’s Manual


Item	Options	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).

4.6.2.11.5 Serial Port 5 Configuration




Item	Options	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).

4.6.2.11.6 Serial Port 6 Configuration



Item	Options	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).

4.6.2.12 EC 5782 HW monitor



Item	Options	Description
Smart Fan Function	Disabled[Default], Enabled	Enable or Disable Smart Fan

4.6.2.13 S5 RTC Wake Settings



EMX-MTLP User's Manual

Item	Options	Description
Wake system from S5	Disabled[Default], Fixed Time Dynamic Time	Enable or disable System wake on alarm event. Select FixedTime, system will wake on the hr::min::sec specified. Select DynamicTime, System will wake on the current time + Increase minute(s)


4.6.2.14 Serial Port Console Redirection



Item	Options	Description
Console Redirection	Disabled[Default], Enabled	Console Redirection Enable or Disable.
Console Redirection EMS	Disabled[Default], Enabled	Console Redirection Enable or Disable.

4.6.2.15 USB Configuration

The USB Configuration menu helps read USB information and configures USB settings.



Item	Options	Description
USB transfer time-out	1 sec 5 sec 10 sec 20 sec [Default]	The time-out value for Control, Bulk, and Interrupt transfers.
Device reset time-out	10 sec 20 sec [Default] 30 sec 40 sec	USB mass storage device Start Unit command time-out.
Device power-up delay	Auto [Default] Manual	Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100ms, for a Hub port the delay is taken form Hub descriptor.

4.6.2.16 Network Stack Configuration




Item	Options	Description
Network Stack	Enabled Disabled[Default]	Enable/Disable UEFI Network Stack.

4.6.2.17 NVMe Configuration



4.6.3 Security



- Administrator Password

Set setup Administrator Password

- User Password

Set User Password

4.6.4.1 Security Boot




Item	Options	Description
Secure Boot	Disabled Enabled[Default]	Secure Boot feature is Active if Secure Boot is Enabled, Platform Key (PK) is enrolled and the System is in User mode. The mode change requires platform reset

EMX-MTLP User’s Manual


Secure Boot Mode	Standard Custom[Default]	Secure Boot mode options: Standard or Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication
------------------	-----------------------------	---

4.6.4.1.1 Expert Key Management




Item	Options	Description
Factory Key Provision	Disabled Enabled[Default]	Install factory default Secure Boot keys after the platform reset and while the System is in Setup mode

4.6.4 Boot



Item	Options	Description
Setup Prompt Timeout	1	Number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.
Bootup NumLock State	On[Default] Off	Select the keyboard NumLock state
Fast Boot	Disabled[Default] Enabled	Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.
Quiet Boot	Disabled[Default] Enabled	Enables or disables Quiet Boot option
Boot Option #1	Sets the system boot order	

4.6.5 Save and Exit



4.6.5.1 Save Changes and Reset

Reset the system after saving the changes.

4.6.5.2 Discard Changes and Reset

Any changes made to BIOS settings during this session of the BIOS setup program are discarded. The setup program then exits and reboots the controller.

EMX-MTLP User’s Manual

4.6.5.3 Restore Defaults

This option restores all BIOS settings to the factory default. This option is useful if the controller exhibits unpredictable behavior due to an incorrect or inappropriate BIOS setting.


4.6.5.4 UEFI: InnostorInnostor 1.00, Partition 1 (Innostor Innostor 1.00)

4.6.6 MEBx




Item	Description
Intel(R) ME Password	MEBx Login

5. Mechanical Drawing



Unit: mm



Unit: mm

