

# EPC-ASL

Intel® Processor N97 Fanless Compact System

## Quick Reference Guide

1<sup>st</sup> Ed –18 April 2025

### Copyright Notice

Copyright © 2025 Avalue Technology Inc., ALL RIGHTS RESERVED.

Document Amendment History

Revision	Date	By	Comment
1 <sup>st</sup>	April 2025	Avalue	Initial Release

## Declaration of Conformity



This device complies with part 15 fcc rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class "a" digital device, pursuant to part 15 of the fcc rules.

These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### CE statement

The product(s) described in this manual complies with all application European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

## Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

## Copyright Notice

© 2025 by Avalue Technology Inc. All rights are reserved. No parts of this manual may be copied, modified, or reproduced in any form or by any means for commercial use without the prior written permission of Avalue Technology Inc. All information and specification provided in this manual are for reference only and remain subject to change without prior notice.

## Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows is registered trademark of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

## Disclaimer

This manual is intended to be used as a practical and informative guide only and is subject to change without notice. It does not represent a commitment on the part of Avalue. This

product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

### A Message to the Customer

#### ***Avalue Customer Services***

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

#### ***Technical Support and Assistance***

1. Visit the Avalue website at <https://www.avalue.com/> where you can find the latest information about the product.
2. Contact your distributor or our technical support team or sales representative for technical support if you need additional assistance. Please have following information ready before you call:
  - Product name and serial number
  - Description of your peripheral attachments
  - Description of your software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wording of any error messages

To receive the latest version of the user's manual; please visit our Web site at:

[www.avalue.com](http://www.avalue.com)

## ***Product Warranty (Returns & Warranties policy)***

### **1. Purpose**

Avalue establishes the following maintenance specifications and operation procedures for providing the best quality of service and shortened repair time to our customers.

### **2. Warranty**

#### **2.1 Warranty Period**

Avalue endeavors to offer customers the most comprehensive post-sales services and protection; besides offering a 2-year warranty for standard Avalue products, an extended warranty service can also be provided based on additional request from the customer. Within the warranty period, customers are entitled to receive comprehensive and prompt repair and warranty.

Standard products manufactured by Avalue are offered a 2-year warranty, from the date of delivery from Avalue. For ODM/OEM products manufactured by Avalue or PCBA with conformal coating, will follow up the define warranty of the agreement, otherwise will be offered 1-year warranty for ODM/OEM products but non-warranty for PCBA with conformal coating. For outsourcing parts kit by Avalue (ex: Motherboard, LCD touch panel, CPU, RAM, HDD) are offered a 6-month warranty, and Mobile/Tablet PC battery are offered a warranty of the half year, from the date of delivery by Avalue. Products before the mass production stage, i.e. engineering samples are not applied in this warranty or service policy. For extended warranty and cross-territory services, product defects resulting from design, production process or material are covered by the pre-set warranty period after the date of delivery from Avalue. For non-Avalue products, the product warranty and repair time shall be based on the service standards provided by the original manufacturer; in principle Avalue will provide these products a warranty service for no more than one year.

#### **2.2 Maintenance services within the warranty period**

In the case of Avalue product DOA (Defect-on-Arrival) when the customer finds any defect within 1 month after the delivery, Avalue will replace it with a new product in a soonest way. Except for custom products, once the customer is approved of a Cross-Shipment Agreement, which allows for delivery a new product to the customer before receiving the defective one, Avalue will immediately proceed with new product replacement for the said DOA case. On validation of the confirmed defect, Avalue is entitled to reserve the right whether to provide a new product for replacement. For the returned defective new product, it is necessary to verify that there shall be no bruise, alteration, scratch or marking to the appearance, and that none of the delivered accessories missing; otherwise, the customer will be requested to pay a processing fee. On the other hand, if the new product defect is resulting from incorrect configuration or erroneous use by the user instead of any problem of the hardware itself, the customer will also be requested to pay for relevant handling fees.

## EPC-ASL

As for other conditions, Avalue will handle defects by way of repair. The customer will be requested to send the defective product to an Avalue authorized service center, and Avalue will return the repaired product back to the customer as soon as possible.

### 2.3 Ruling of an out-of-warranty defect

The following situations are not included in the warranty:

- The warranty period has expired.
- Product has been altered or its label of the serial number has been torn off.
- Product functionality issues resulting from improper use by the user, unauthorized dismantle or alteration, unfit operation environment, improper maintenance, accident or other causes. Avalue reserves the right for the ruling of the aforementioned situations.
- Product damage resulting from lightning, flood, earthquake or other calamities.
- The warranty rules of non-Avalue products and accessories shall be in accordance with standards set up by the original manufacturer. These products and accessories include RAM, HDD, FDD, CD-ROM, CPU, FAN, etc.
- Product upgrade request or test request submitted by the customer after expiration of the warranty.
- PCBA with conformal coating.
- Avalue semi-product and outsourced products without Avalue serial number.
- Products before the mass production stage, i.e. engineering samples.

## 3. Procedure for sending for repair

### 3.1 Attain a RMA number

A customer's rejected product returned for repair shall have a RMA (Return Merchandise Authorization) number. Without a RMA number, Avalue will not provide any repair service for the rejected product, and the product will be returned to the customer at customer's cost. Avalue will not issue any notice for the return of the product.

Each returned product for repair shall have a RMA number, which is simply the authorization of the return for repair; it is not a guarantee that the returned goods can be repaired or replaced. For applying for a RMA number, the customer may enter the eRMA webpage of Avalue <https://www.avalue.com/en/member> and log-in with an account number and a password authorized by Avalue. The system will then automatically issue a RMA number.

When applying for the RMA number, it is essential to fill in basic information of the customer and the product, together with detailed description of the problem encountered. If possible, avoid using ambiguous words such as "does not work" or "problematic". Without a substantial description of the problem, it is hard to start the repair and will cause prolonged repair time. Lacking detailed statement of fault steps also makes the problem hard to be identified, sometimes resulting in second-time repairs.

In case the customer can't define the cause of problem, please contact Avalue application engineers. Sometimes when the problem can be resolved even before the customer sends back the product.

On the other hand, if the customer only returns the key parts to Avalue for repair, it is necessary that the serial number of the entire unit is given in the "Problem Description" field, so that warranty period can be ruled accordingly; or Avalue will handle the case as an Out-of- warranty case.

### 3.2 Return of faulty product for repair

It is recommended that the customer not to return the accessories (manual, connection cables, etc.) with the products for repair, devices such as CPU, DRAM, CF memory card, etc., shall also be removed from the faulty goods before return for repair. If these devices are relevant to described repair problems and necessary to be returned with the goods; please clearly indicate the items included in the eRMA application form. Avalue shall not be responsible for any item that is not itemized. Moreover, make sure the problem(s) are detailed in the "Problem Description" field.

In the list of delivery, the customer may fill-in a value which is lower than the actual value, to prevent customs levying a higher tax over the excessive value of the return goods. The customer shall be held responsible for extra fees caused by this. We strongly recommend that "Invoice for customs purpose only with no commercial value" be indicated on the delivery note. Also for the purpose of expedited handling, please printout the RMA number and put it in the carton, also indicate the number outside of the carton, with the recipient addressing to Avalue RMA Department.

When returning the defective product, please use an anti-static bag or ESD material to pack it properly. In case of improper packing resulting in damages in the transportation process, Avalue reserves the right to reject the un-repaired faulty good at the customer's costs. Furthermore, it is suggested that the faulty goods shall be sent via a door-to-door courier service. The customer shall be held responsible for any customs clearance fee or extra expenses if Air-Cargo is used for the delivery.

In case of a DOA situation of a new product, Avalue will be responsible for the product and the freight. If the faulty goods are within the warranty period, the sender will take responsibility for the freight. For an out-of-warranty case, the customer shall be responsible for the freight of both trips.

### 3.3 Maintenance Charge

Avalue will charge a moderate repair fee for the following conditions:

- The warranty period has expired.
- Product has been altered or its label of the serial number has been torn off.
- Product functionality issues resulting from improper use by the user, unauthorized dismantle or alteration, unfit operation environment, improper maintenance, accident

or other causes. Avalue reserves the right for the ruling of the aforementioned situations.

- Product damage resulting from lightning, flood, earthquake or other calamities.
- The warranty rules for non-Avalue products and accessories shall be in accordance with standards set up by the original supplier. These products and accessories include RAM, HDD, FDD, CD-ROM, CPU, FAN, etc.
- Product upgrade request or test request submitted by the customer after expiry of the warranty.
- PCBA with conformal coating.
- Avalue semi-product and outsourced products without Avalue serial number
- Products before the mass production stage, i.e. engineering samples.
- In case the products received are examined as NPF (No Problem Found) within the warranty period, the customer shall be responsible for the freight of both trips.
- Please contact your local distributor to examine in advance to prevent unnecessary freight cost.

For system failure of out-of-warranty products, Avalue will provide a quotation prior to repair service. When the customer applies for the cost, please refer to the Quotation number. In case the customer does not return the DOA product that has already been replaced by a new one, or the customer does not sign back the quotation of the out-of-warranty maintenance, Avalue reserves the right of whether or not to provide the repair service. In case the customer does not reply in 3 months, Avalue shall directly scrap or return the product back to customer at customer's cost without further notice to the customer.

### **3.4 Maintenance service of phased-out products**

For servicing phased-out products, Avalue provides an extended period, starting the date of phase-out, as a guaranteed maintenance period of such products, for continuance of the maintenance service to meet customer's requirements. In case of unexpected factors causing Avalue to be unable to repair/replace a warranted but phased-out product, Avalue will, depending on the availability, upgrade the product (free of charge with continued warranty period as of the original product), or, give partial refund (based on the length of the remaining warranty period) to solve this kind of problem.

### **3.5 Maintenance Report**

On completion of repair of a defective product, a Maintenance Report indicating the maintenance result and part(s) replaced (if any) will be sent to the customer together with the product. If the customer demands an additional maintenance analysis report, a service fee of various level will be charged depending on the warranty status. In case the analysis result shows that the defect attributes to Avalue's faulty design or process, the analysis fee will be exempted.

### 4. Service Products

Avalue provides service products to manage with different customer needs. Should you have any need, please consult to Avalue Sales Department.

#### Defect Analysis Report (DAR)

Avalue provides DAR (Defect Analysis Report) services aiming to elevating customer satisfaction. A DAR includes defect cause identification/verification/suggestion and improvement precautions, with instructions on correct usage for the avoidance of any reoccurrence.

#### Upgrade Service

Avalue is capable to provide system upgrade service for customization requirements. This upgrade service is applicable for main parts, such as CPU, memory, HDD, SSD, storage devices; also replacements motherboards of systems. Please contact Avalue sales for details to evaluate the possibility of system upgrade service and obtain information of lead time and price.

## Safety Instructions

### Safety Precautions

Before installing and using this device, please note the following precautions.

1. Read these safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Disconnected this equipment from any AC outlet before cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
8. Use a power cord that has been approved for using with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to

## **EPC-ASL**

avoid damage by transient overvoltage.

12. Never pour any liquid into an opening. This may cause fire or electrical shock.












13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel. If one of the following situations arises, get the equipment checked by service personnel:

- The power cord or plug is damaged.
- Liquid has penetrated into the equipment.
- The equipment has been exposed to moisture.
- The equipment does not work well, or you cannot get it work according to the user's manual.
- The equipment has been dropped and damaged.
- The equipment has obvious signs of breakage.






14. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

15. Equipment intended only for use in a RESTRICTED ACCESS AREA.

## Explanation of Graphical Symbols

	Warning	A WARNING statement provides important information about a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Caution	A CAUTION statement provides important information about a potentially hazardous situation which, if not avoided, may result in minor or moderate injury to the user or patient or in damage to the equipment or other property.
	Note	A NOTE provides additional information intended to avoid inconveniences during operation.
		Direct current.
		Alternating current
		Stand-by, Power on
		FCC Certification
		CE Certification
		Follow the national requirements for disposal of equipment.
		Stacking layer limit
		This side up

## EPC-ASL

		Fragile Packaging
		Beware of water damage, moisture-proof
		Carton recyclable
		Handle with care
		Follow operating instructions of consult instructions for use.

## Disposing of your old product

### **WARNING:**

There is danger of explosion if the battery is mishandled or incorrectly replaced. Replace only with the same type of battery. Do not disassemble it or attempt to recharge it outside the system. Do not crush, puncture, dispose of in fire, short the external contacts, or expose to water or other liquids. Dispose of the battery in accordance with local regulations and instructions from your service provider.

### **CAUTION:**

- Lithium Battery Caution: Danger of explosion if battery is incorrectly replaced. Replace only with same or equivalent type. Dispose batteries according to manufacturer's instructions.
- Disposal of a BATTERY into fire or a hot oven, or mechanically crushing or cutting of a BATTERY, that can result in an EXPLOSION
- Leaving a BATTERY in an extremely high temperature surrounding environment that can result in an EXPLOSION or the leakage of flammable liquid or gas.
- A BATTERY subjected to extremely low air pressure that may result in an EXPLOSION or the leakage of flammable liquid or gas.

### **Mise en garde!**

AVERTISSEMENT : Il existe un risque d'explosion si la batterie est mal manipulée ou remplacée de manière incorrecte. Remplacez uniquement par le même type de batterie. Ne le démontez pas et ne tentez pas de le recharger en dehors du système. Ne pas écraser, percer, jeter au feu, court-circuiter les contacts externes ou exposer à l'eau ou à d'autres liquides. Jetez la batterie conformément aux réglementations locales et aux instructions de votre fournisseur de services.

### **MISE EN GARDE:**

- Pile au lithium Attention : Danger d'explosion si la pile n'est pas remplacée correctement. Remplacer uniquement par un type identique ou équivalent. Jetez les piles conformément aux instructions du fabricant.
- L'élimination d'une BATTERIE dans le feu ou dans un four chaud, ou l'écrasement ou le découpage mécanique d'une BATTERIE, pouvant entraîner une EXPLOSION
- Laisser une BATTERIE dans un environnement à température extrêmement élevée pouvant entraîner une EXPLOSION ou une fuite de liquide ou de gaz inflammable.
- UNE BATTERIE soumise à une pression d'air extrêmement basse pouvant entraîner une EXPLOSION ou une fuite de liquide ou de gaz inflammable.

# Content

<b>1.</b>	<b>Getting Started .....</b>	<b>17</b>
1.1	Safety Precautions .....	17
1.2	Packing List.....	17
1.3	System Specifications .....	19
1.4	System Overview .....	22
1.4.1	Front View.....	22
1.4.2	Rear View .....	22
1.5	System Dimensions .....	23
1.6	Operating Principle.....	24
<b>2.</b>	<b>Hardware Configuration .....</b>	<b>25</b>
2.1	EPC-ASL connector mapping .....	26
2.1.1	Serial port connector (COM).....	26
2.2	ECM-ASL Product Overview .....	27
2.3	ECM-ASL Jumper and Connector List .....	28
2.4	ECM-ASL Setting Jumpers & Connectors.....	30
2.4.1	AT/ATX Input power select (JSATX1) .....	30
2.4.2	Clear CMOS (JRTC1).....	30
2.4.3	M.2 Key power select (JP1).....	31
2.4.4	Serial port 1 pin9 signal select (JRI1).....	31
2.4.5	LCD backlight brightness adjustment (JSBKL1) .....	32
2.4.6	CPU fan connector (JFAN1).....	32
2.4.7	SPI connector (JSPI1) .....	33
2.4.8	ESPI connector (JESPI1) .....	33
2.4.9	eDP/LVDS connector (JLVDS1).....	34
2.4.10	Serial port 1 in RS-422/485 mode (J422_485).....	35
2.4.11	Serial port 2 connector (JCOM2).....	35
2.4.12	Serial port 3 connector (JCOM3).....	36
2.4.13	Serial port 4 connector (JCOM4).....	36
2.4.14	General purpose I/O connector (JDIO1) .....	37
2.4.15	LCD inverter backlight connector (JBKL1) .....	37
2.4.16	USB2.0 connector (JUSB1).....	38
2.4.17	PC Buzzer connector (JBZ1).....	38
2.4.18	Battery connector (JBAT1) .....	39
2.4.19	Front Panel connector 1 (JFP1) .....	39

2.4.20	SATA Power connector (JSATAPW1).....	40
2.4.21	Power connector (JDCIN1).....	40
2.4.22	Audio connector (JAUDIO1).....	41
2.4.22.1	Signal Description – Audio connector (JAUDIO1).....	41
2.4.23	EC connector (JEC1).....	41
2.4.24	SIM card slot (JSIM1) .....	42
<b>3.</b>	<b>Installation .....</b>	<b>43</b>
3.1	Installing Hard Disk & Memory (EPC-ASL) .....	45
3.2	Installing M.2 B-Key (3052)/(2242 or 3042) card (EPC-ASL).....	48
3.3	Installing M.2 E-Key (2230) card (EPC-ASL) .....	49
3.4	Installing Mounting Brackets (EPC-ASL).....	50
3.5	System Mounting .....	51
<b>4.</b>	<b>Drivers Installation .....</b>	<b>52</b>
4.1	Install Chipset Driver .....	53
4.2	Install VGA Driver.....	54
4.3	Install ME Driver.....	55
4.4	Install Audio Driver .....	56
4.5	Install Serial IO Driver .....	58
4.6	Install Ethernet Driver.....	60
<b>5.</b>	<b>BIOS Setup.....</b>	<b>62</b>
5.1	Introduction .....	63
5.2	Starting Setup .....	63
5.3	Using Setup .....	64
5.4	Getting Help.....	65
5.5	In Case of Problems.....	65
5.6	BIOS setup.....	66
5.6.1	Main Menu .....	66
5.6.1.1	System Language.....	67
5.6.1.2	System Date .....	67
5.6.1.3	System Time.....	67
5.6.2	Advanced Menu.....	67
5.6.2.1	Connectivity Configuration.....	68
5.6.2.2	CPU Configuration.....	68
5.6.2.2.1	Efficient-core Information.....	69
5.6.2.3	Power & Performance .....	69
5.6.2.3.1	CPU – Power Management Control .....	70
5.6.2.3.1.1	View/Configure Turbo Options.....	71
5.6.2.4	PCH-FW Configuration .....	71
5.6.2.4.1	Firmware Update Configuration.....	72
5.6.2.4.2	PTT Configuration.....	72

## EPC-ASL

5.6.2.5	Trusted Computing .....	73
5.6.2.6	APCI Settings .....	73
5.6.2.7	IT5782 Super IO Configuration.....	74
5.6.2.7.1	Serial Port 1 Configuration .....	75
5.6.2.7.2	Serial Port 2 Configuration .....	75
5.6.2.8	EC 5782 HW Monitor.....	76
5.6.2.9	S5 RTC Wake Settings.....	76
5.6.2.10	Serial Port Console Redirection .....	77
5.6.2.11	USB Configuration .....	78
5.6.2.12	Network Stack Configuration .....	79
5.6.2.13	NVMe Configuration .....	79
5.6.3	Chipset.....	80
5.6.3.1	System Agent (SA) Configuration.....	80
5.6.3.1.1	Memory Configuration .....	81
5.6.3.1.2	Graphics Configuration .....	81
5.6.3.2	PCH-IO Configuration.....	82
5.6.3.2.1	PCI Express Configuration .....	82
5.6.3.2.1.1	PCI Express Root Port 7(LAN1-I226).....	83
5.6.3.2.1.2	PCI Express Root Port 9(M.2 KeyE).....	84
5.6.3.2.1.3	PCI Express Root Port 10(LAN2-I226).....	85
5.6.3.2.1.4	PCI Express Root Port 12(M.2 KeyB).....	86
5.6.3.2.2	SATA Configuration .....	87
5.6.3.2.3	HD Audio Configuration.....	87
5.6.3.3	Board & Panel Configuration .....	88
5.6.4	Security .....	89
5.6.4.1	Secure Boot .....	90
5.6.5	Boot.....	90
5.6.6	Save and Exit.....	91
5.6.6.1	Save Changes and Reset.....	92
5.6.6.2	Discard Changes and Reset.....	92
5.6.6.3	Restore Defaults .....	92
5.6.6.4	Launch EFI Shell from filesystem device .....	92
<b>6.</b>	<b>Maintenance &amp; Troubleshooting.....</b>	<b>93</b>
<b>7.</b>	<b>Product Application .....</b>	<b>98</b>

# 1. Getting Started

## 1.1 Safety Precautions

### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

## 1.2 Packing List

Before installation, please ensure all the items listed in the following table are included in the package.

Item	Description	Q'ty
1	EPC-ASL System	1
2	AC/DC Adapter 12V/5A	1
3	Wall Mount Kit	1
4	M.2 2252 to 2242 Bracket	1
5	Screw Kit for Peripherals	1



If any of the above items is damaged or missing, contact your retailer.

## Unpacking

**Note:**

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the Avalue reseller or vendor the product was purchased from or contact an Avalue sales representative directly by sending an email to [sales@avalue.com](mailto:sales@avalue.com)

To unpack the box PC, follow the steps below.

Step 1: Carefully cut the tape sealing the box. Only cut deep enough to break the tape.

Step 2: Open the outside box.

Step 3: Carefully cut the tape sealing the box. Only cut deep enough to break the tape.

Step 4: Open the inside box.

Step 5: Take out the box pc from the boxes.

Step 6: Remove the peripheral parts from the box.

## 1.3 System Specifications

System Information					
SBC		ECM-ASL			
Processor		Intel® Processor N97, 6M Cache, up to 3.60 GHz (12W)			
System Memory		1x262-pin SODIMM socket Max. up to 16GB DDR5 4800MT/s			
I/O Chipset		EC ITE: IT5782VG			
Watchdog Timer		H/W Reset, 1sec. ~ 65535min. and 1sec. or 1min./step			
H/W Status Monitor		Monitoring CPU Temperature, Voltage with Auto Throttling Control			
ACPI		Single power ATX Support S0, S3, S4, S5			
TPM		TPM 2.0 NuvoTon_NPCT750AABYX			
Operating System		Win10, Win11, Linux			
Expansion					
M.2 (Signal)		1xM.2 Key-B 3042/3052/2242 (PCIex1+USB3.2 GEN 1 + USB2.0), with 1 x SIM card Slot for SSD/LTE/IO Cards support WWAN+GNSS and SSD 1xM.2 Key-E 2230 support CNVi and Wi-Fi 6E module (1x PCI-e x1 & USB 2.0 Signal)			
Storage					
M.2 (Signal)		1xM.2 Key-B 2242 SSD (PCIex1)			
2.5” Drive Bay (Height)		1xInternal 2.5” Drive Bay (9.5mm or 7mm)			
Front I/O					
Power Button		1xPWR BTN w/LED			
Reset Button		1xReset Button			
USB Port		2xUSB2.0			
Audio Port		1xMic-in, 1xLine-out			
Rear I/O					
Serial Port		2xRS232			
USB Port		3xUSB 3.2 Gen.2 Type A +5VSB/0.9A 1xUSB 2.0 Type A +5VSB/0.5A			
Display Port		1xDP 1.4a 1xHDMI 2.0b			
LAN Port		2xRJ45			
LAN Port LED Indicator		Max. 2.5G LAN Port			
		ACT/LINK		SPEED	
			Definition	LED	Definition
		Light Off	No Link	Solid Orange	2.5G
		Solid Yellow	Connection	Solid Green	1G/100M

## EPC-ASL

	Yellow Flashing	Activity	Light Off	10M	
Antenna	2xAntenna w/cover				
AC/DC Input Conn.	1xLockable DC Jack				
Left I/O (View on front side)					
Antenna	1xAntenna w/cover				
Right I/O (View on front side)					
Antenna	1xAntenna w/cover				
Display					
Graphic Chipset	Integrated Intel® UHD Graphics				
Spec. & Resolution	1xDP++: 1920 x 1080@60 Hz (DP 1.4a: 4096 x 2160@60Hz)				
	1xHDMI 2.0b: 4096 x 2160@60 Hz				
Audio					
Audio Codec	RealTek ALC888S-VD2-GR				
Audio Port	1xMic-in, 1xLine-out				
Ethernet					
LAN Chipset	Intel® I226V 2.5 Gigabit Ethernet Controller				
LAN Spec.	10/100/1000/2.5G speeds				
Power Requirement					
Voltage Input Spec.	Typical +12/24Vdc				
Voltage Input Conn.	Lockable DC Jack				
ACPI	Single power ATX Support S0, S3, S4, S5				
Power Mode	AT/ATX (ATX is default setting)				
Adapter	60W AC to DC Adapter (Default)				
	120W AC to DC Adapter (Option)				
	Note1: 60W for general mode (storage, communication, display, USB port, room temp.)				
	Note2: 120W for full load mode (general mode pluses max. workload and operating temp.)				
Mechanical & Environment					
Operating Temp.	0°C ~ 50°C (14F ~ 122°F) with 0.5m/s air flow				
Storage Temp.	-30~70C° (-22°F ~ 158°F)				
Operating Humidity	40°C @ 95% Relative Humidity, Non-condensing				
Dimension (W*L*H)	177x126x57mm				
Weight	1.3KG				
Mounting Kit	Stand/Wall mount (default), VESA/Din Rail (Optional)				
Reliability					
Vibration Test	Random Vibration Operation				
	1. PSD: 0.00454G²/Hz , 1.5 Grms				
	2. Operation mode				


	<p>3. Test Frequency : 5-500Hz</p> <p>4. Test Axis : X,Y and Z axis</p> <p>5. 30 minutes per each axis</p> <p>6. IEC 60068-2-64 Test:Fh</p> <p>7. Storage : CF or SSD</p> <p>Sine Vibration test (Non-operation)</p> <p>1 PSD: 0.01818G<sup>2</sup>/Hz , 3.0 Grms</p> <p>2 Non-Operation mode</p> <p>3 Test Frequency : 5-500Hz</p> <p>4 Test Axis : X,Y and Z axis</p> <p>5 30 min. per each axis</p> <p>6 IEC 60068-2-64 Test:Fh</p> <p>Package Vibration Test:</p> <p>1 Test PSD : 0.026G<sup>2</sup>/Hz , 2.16 Grms</p> <p>2 Test frequency : 5~500 Hz</p> <p>3 Test axis : X,Y and Z axis</p> <p>4 Test time : 30 minutes per each axis</p> <p>5 IEC 60068-2-64 Test Fh</p>
<b>Shock Test</b>	<p>1. Wave form : Half Sine wave</p> <p>2. Acceleration Rate : 10g for operation mode</p> <p>3. Duration Time : 11ms</p> <p>4. No. of Shock : Z axis 300 times</p> <p>5. Test Axis: Z axis</p> <p>6. Operation mode</p> <p>7. Reference IEC 60068-2-27 Testing procedures</p> <p>Test Eb : Shock Test</p>
<b>Drop Test</b>	<p>Package drop test</p> <p>Reference ISTA 2A, Method : IEC-60068-2-32 Test:Ed</p> <p>Test Ea : Drop Test</p> <p>1 Test phase : One corner, three edges, six faces</p> <p>2 Test high : 96.5cm</p> <p>3 Package weight : 5Kg</p> <p>4 Test drawing</p>




**Note:** Specifications are subject to change without notice.

1.4 System Overview

1.4.1 Front View




1.4.2 Rear View



Connectors

Label	Function	Note
Power Switch	Power on button	
HDD LED	HDD LED indicator	
Power Reset	Power Reset button	
USB2.0	3 x USB 2.0 connector	
USB3.2	3 x USB 3.2 connector	
COM	2 x Serial port connector	
Mic-in	Mic-in audio jack	
Line-out	Line-out audio jack	
DC IN	DC power-in connector	
2 x 2.5GbE	2 x RJ-45 Ethernet	
HDMI	HDMI connector	
DP	DP connector	
Antenna	4 x Antenna w/cover	

1.5 System Dimensions



(Unit: mm)

### 1.6 Operating Principle

(a) Installation:

- Take the device and accessories from package and put in the suitable place.
- Check the packing list (accessories).
- Connect the power cord to the device.
- Put the plug of power cord into receptacle of power source.
- Press power button "Power Icon" on the device to start the device.

(b) Installation for monitor:

- Plug in the monitor cable (HDMI or DP).

(c) Installation keyboard and mouse.

- Plug in mouse and keyboard.

(d) Operation for Turn ON the system

- Turn ON the system.
- Press the power ON/OFF icon firmly to turn power ON/OFF.
- The power ON/OFF LED will turn blue to indicate power is on. *\*Note*
- Check with the Icon behavior for power status.

*\*Note*: Power LED.

S0: On

S3: Blinking

S4/S5: Off

BIOS P.O.S.T: Blinking.

## 2. Hardware Configuration

For advanced information, please refer to:

- 1- ECM-ASL main board included in this manual.





**Note:** If you need more information, please visit our website:

[www.avalue.com](http://www.avalue.com)



2.1 EPC-ASL connector mapping

2.1.1 Serial port connector (COM)



Signal	PIN	PIN	Signal
NDCD#	1	6	NDSR#
NRXD	2	7	NRTS#
NTXD	3	8	NCTS#
NDTR#	4	9	NRI#
GND	5		


## 2.2 ECM-ASL Product Overview



## 2.3 ECM-ASL Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board's jumpers and connectors.

### Jumpers

Label	Function	Note
<b>JSATX1</b>	AT/ATX Input power select	3 x 1 header, pitch 2.00mm
<b>JRTC1</b>	Clear CMOS	3 x 1 header, pitch 2.00mm
<b>JP1</b>	M.2 Key power select	3 x 1 header, pitch 2.00mm
<b>JRI1</b>	Serial port 1 pin9 signal select	3 x 2 header, pitch 2.00mm
<b>JSBKL1</b>	LCD backlight brightness adjustment	3 x 1 header, pitch 2.00mm


### Connectors

Label	Function	Note
<b>JBKL1</b>	LCD inverter backlight connector	5 x 1 wafer, pitch 2.00mm Matching Connector: JST PHR-5
<b>JFAN1</b>	CPU fan connector	4 x 1 wafer, pitch 2.54mm


<b>COM1</b>	Serial port 1 connector	
<b>JCOM2/3/4</b>	Serial port 2/3/4 connector	5 x 2 header, pitch 2.00mm
<b>J422_485</b>	Serial port 1 in RS-422/485 mode	3 x 2 header, pitch 2.00mm
<b>JDIO1</b>	General purpose I/O connector	6 x 2 header, pitch 2.00mm
<b>JDCIN1</b>	Power connector	2 x 2 wafer, pitch 4.20mm
<b>M2KE1</b>	M.2 KEY-E 2230 connector	
<b>M2B1</b>	M.2 KEY-B 3042/2242 connector	
<b>LAN1</b>	2 x RJ-45 Ethernet	
<b>DP_HDMI1</b>	HDMI connector DP connector	
<b>JFP1</b>	Front Panel connector	5 x 2 header, pitch 2.00mm
<b>USB1</b>	1 x USB2.0 connector 1 x USB3.2 Gen2 connector	
<b>USB2</b>	USB3.2 Gen2 connector	
<b>JUSB1</b>	USB2.0 connector	5 x 2 header, pitch 2.00mm
<b>JEC1</b>	EC connector	3 x 1 header, pitch 2.00mm
<b>JSPI1</b>	SPI connector	4 x 2 header, pitch 2.00mm
<b>JESPI1</b>	ESPI connector	6 x 2 wafer, pitch 1.00mm
<b>SATA1</b>	Serial ATA connector	
<b>JSATAPW1</b>	SATA power connector	2 x 1 wafer, pitch 2.00mm
<b>JLVDS1</b>	eDP/LVDS connector	DIN 40-pin wafer, pitch 1.25mm Matching Connector: Hirose DF13-40DS-1.25C
<b>JBZ1</b>	PC Buzzer connector	2 x 1 wafer, pitch 2.00mm
<b>SODIMM1</b>	DDR5 SODIMM socket	
<b>SIM1</b>	SIM card slot	
<b>JBAT1</b>	Battery connector	2 x 1 wafer, pitch 1.25mm
<b>JAUDIO1</b>	Audio connector	6 x 2 header, pitch 2.00mm
<b>JSIM1</b>	SIM card slot	10 x 1 FPC, pitch 0.50mm

2.4 ECM-ASL Setting Jumpers & Connectors


2.4.1 AT/ATX Input power select (JSATX1)



ATX




AT\*




\* Default


2.4.2 Clear CMOS (JRTC1)



Normal\*





Clear CMOS





\* Default

2.4.3 M.2 Key power select (JP1)




\* Default

2.4.4 Serial port 1 pin9 signal select (JRI1)




\* Default


2.4.5 LCD backlight brightness adjustment (JSBKL1)



PWM Mode\*





DC Mode





\* Default

2.4.6 CPU fan connector (JFAN1)




Signal	PIN
GND	1
+12V	2
CFAN_IN_TACH	3
CFAN_OUT_PWM	4

2.4.7 SPI connector (JSPI1)




Signal	PIN	PIN	Signal
+3.3VSB	1	2	GND
ROM_CS#	3	4	ROM_SPI_CLK
ROM_SPI_MISO	5	6	ROM_SPI_MOSI
HOLD#	7	8	SPI_WP#

2.4.8 ESPI connector (JESPI1)





Signal	PIN	PIN	Signal
ESPI_IO0_CN	1	2	+3.3VSB
ESPI_IO1_CN	3	4	PLT_BUF_RST#
ESPI_IO2_CN	5	6	ESPI_CS#0
ESPI_IO3_CN	7	8	ESPI_CLK_CN
ESPI_CS1#	9	10	GND
ESPI_RST#	11	12	ESPI_ALERT#1

2.4.9 eDP/LVDS connector (JLVDS1)



Signal	PIN	PIN	Signal
+3.3V	1	2	+5V
+3.3V	3	4	+5V
+3.3V	5	6	+5V
GND	7	8	GND
LVDS_DATAP1/eDPP1	9	10	LVDS_DATAP0/eDP_HPDP
LVDS_DATAN1/eDPN1	11	12	LVDS_DATAN0
GND	13	14	GND
LVDS_DATAP3	15	16	LVDS_DATAP2/eDPP0
LVDS_DATAN3	17	18	LVDS_DATAN2/eDPN0
GND	19	20	GND
LVDS_DATAP5	21	22	LVDS_DATAP4
LVDS_DATAN5	23	24	LVDS_DATAN4
GND	25	26	GND
LVDS_DATAP7	27	28	LVDS_DATAP6
LVDS_DATAN7	29	30	LVDS_DATAN6
GND	31	32	GND
LVDS_CLK2P	33	34	LVDS_CLK1P/eDPAUXP
LVDS_CLK2N	35	36	LVDS_CLK1N/eDPAUXN
GND	37	38	GND
+12V	39	40	+12V

2.4.10 Serial port 1 in RS-422/485 mode (J422\_485)





RS-422

Signal	PIN	PIN	Signal
TX+	2	1	TX-
RX-	4	3	RX+
GND	6	5	+5V

RS-485



Signal	PIN	PIN	Signal
DATA +	2	1	DATA -
	4	3	
GND	6	5	+5V

2.4.11 Serial port 2 connector (JCOM2)





Signal	PIN	PIN	Signal
		9	COM_RI#_2
COM_CTS#_2	8	7	COM_RTS#_2
COM_DSR#_2	6	5	GND
COM_DTR#_2	4	3	COM_TXD_2
COM_RXD_2	2	1	COM_DCD#_2

2.4.12 Serial port 3 connector (JCOM3)





Signal	PIN	PIN	Signal
		9	COM_RI#_3
COM_CTS#_3	8	7	COM_RTS#_3
COM_DSR#_3	6	5	GND
COM_DTR#_3	4	3	COM_TXD_3
COM_RXD_3	2	1	COM_DCD#_3

2.4.13 Serial port 4 connector (JCOM4)




Signal	PIN	PIN	Signal
		9	COM_RI#_4
COM_CTS#_4	8	7	COM_RTS#_4
COM_DSR#_4	6	5	GND
COM_DTR#_4	4	3	COM_TXD_4
COM_RXD_4	2	1	COM_DCD#_4

2.4.14 General purpose I/O connector (JDIO1)





Signal	PIN	PIN	Signal
DIO_GP20	1	2	DIO_GP10
DIO_GP21	3	4	DIO_GP11
DIO_GP22	5	6	DIO_GP12
DIO_GP23	7	8	DIO_GP13
SMB_SCL_DIO	9	10	SMB_SDA_DIO
GND	11	12	+5V

2.4.15 LCD inverter backlight connector (JBKL1)





Signal	PIN
+12V	1
GND	2
LVDS_BKLT_EN	3
LVDS_BKLADJ	4
+5V	5

2.4.16 USB2.0 connector (JUSB1)




Signal	PIN	PIN	Signal
+5VSB	1	2	+5VSB
USB2_R_DN7	3	4	USB2_R_DN8
USB2_R_DP7	5	6	USB2_R_DP8
GND	7	8	GND
		10	GND

2.4.17 PC Buzzer connector (JBZ1)





Signal	PIN
+3.3V	1
SPKR-	2

2.4.18 Battery connector (JBAT1)





Signal	PIN
+RTCBATT	1
GND	2

2.4.19 Front Panel connector 1 (JFP1)





Signal	PIN	PIN	Signal
HDD_LED+	1	2	PWR_LED+
HDD_LED-	3	4	PWR_LED-
EXT_SYSRST#	5	6	EXT_PWRBTN#
GND	7	8	GND
NC	9		

2.4.20 SATA Power connector (JSATAPW1)





Signal	PIN
GND	1
+5V	2

2.4.21 Power connector (JDCIN1)



Signal	PIN	PIN	Signal
GND	1	2	GND
+VIN_9-36V	3	4	+VIN_9-36V

2.4.22 Audio connector (JAUDIO1)




Signal	PIN	PIN	Signal
LINEOUT_R	1	2	LINEOUT_L
GND_AUD	3	4	GND_AUD
LINEIN_R	5	6	LINEIN_L
MICIN_R	7	8	MICIN_L
LINEOUT1_JD	9	10	LINE1-JD
MIC1_JD	11	12	GND_AUD

2.4.22.1 Signal Description – Audio connector (JAUDIO1)



Signal	Signal Description
LINE1-JD	AUDIO IN (LINE_RIN/LIN)sense pin
LINEOUT1_JD	AUDIO Out(ROUT/LOUT) sense pin
MIC1_JD	MIC IN (MIC_RIN/LIN) sense pin

2.4.23 EC connector (JEC1)



Signal	PIN
EC_SMDAT_DBG	1
EC_SMCLK_DBG	2
GND	3

2.4.24 SIM card slot (JSIM1)



Signal	PIN
NC	10
SIM_CD_R	9
GND	8
UIM_DATA_R	7
UIM_CLK_R	6
GND	5
NC	4
UIM_RESET#_R	3
GND	2
+VCC_SIM	1

## 3. Installation

---

### Removing the Top Cover Warning

To prevent electric shock or system damage, before removing the chassis cover, must turn off power and disconnect the unit from power source.

Electrostatic discharge (ESD) can cause serious damage to electronic components. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the product is accessed internally, or any other electrical component is handled, the following anti-static precautions are strictly adhered to:


- Wear an anti-static wristband: Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- Self-grounding: Before handling the board, touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- Use an anti-static pad: When configuring the product, place it on an anti-static pad. This reduces the possibility of ESD damaging the product.
- Only handle the edges of the PCB: When handling the PCB, hold the PCB by the edges.

### Installation Precautions


When installing the box PC, please follow the precautions listed below:

- Power turned off: When installing the box PC, make sure the power is off. Failing to turn off the power may cause severe injury to the body and/or damage to the system.
- Certified Engineers: Never open the equipment. For safety reasons, the equipment should be opened only by qualified skilled person.
- Anti-static Discharge: If a user open the rear of the box PC, to configure the jumpers or plug in added peripheral devices, ground themselves first and wear an anti-static wristband.

### 3.1 Installing Hard Disk & Memory (EPC-ASL)




**Step1.** For HDD installation, remove four screws from bottom cover.




**Step2.** Install HDD.

**Step3.** Fix HDD with four screws.


**Step4.** Insert sata cable and sata power cable.



**Step5.** Put the bottom back and fix with four screws.



**Step6.** Slide the DDR5 SODIMM into the memory socket and press it down until properly seated.




### Paste Graphite copper sheet

**Step7.** Remove the release paper from the Graphite copper sheet.

**Step8.** Position the sheet directly above the memory, ensuring it is well-aligned for proper coverage.


### 3.2 Installing M.2 B-Key (3052)/(2242 or 3042) card (EPC-ASL)



**Step1.** Fix bracket and standoff screw with M3\*4 screw.


**Step2.** Insert M.2 B-Key (3052)/(2242 or 3042) card into designated locations and fasten with M2\*3 screw to complete installation.

### 3.3 Installing M.2 E-Key (2230) card (EPC-ASL)



**Step1.** Insert M.2 E-Key card into designated locations and fasten with M3\*4 screw to complete installation.

### 3.4 Installing Mounting Brackets (EPC-ASL)



**Step1.** Fasten four M3\*5 screws on each side of the system to secure Mounting brackets.

### 3.5 System Mounting

**Warning!** *More than one person should participate in mounting the box PC to prevent accidental damage to the personal injury.*



#### Safety Precautions

Observe the following common safety precautions before installing any electronic device:

- Use separate, non-intersecting paths to route power and networking wires. If power wiring and device wiring paths must be crossed make sure the wires are perpendicular at the intersection point.
- Keep the wires separated according to the interface. Wires that share similar electrical characteristics must be bundled together.
- Do not bundle input wiring with output wiring. Keep them separate.
- When necessary, it is strongly advised that you label wiring to all devices in the system.

# 4. Drivers Installation

All the drivers are available on Avalue Downloads Area (<https://www.avalue.com/en/support/download>). Type the model name and press Enter to find all the relevant software, utilities, and documentation.

**Note:**  
The box PC with projected capacitive type touchscreen and Windows 7 (or later) OS does not require touch driver installation. This is because there is a HID touch digitizer built-in driver in Windows 7 or later.

Chipset 1 Audio 1 Graphics 1 LAN 1 Other 1

Chipset

Total 1 Files

No.	Release Date	Title	Description	Download
01	2023-09-20	Intel Chipset Driver for Win10 x64	Windows 10 64bit	

Audio

Total 1 Files

No.	Release Date	Title	Description	Download
01	2023-09-20	Realtek Audio Driver for Win10 x64	Windows 10 64bit	

(For reference only)



**Note:** Installation procedures and screen shots in this section are for your reference and may not be exactly the same as shown on your screen.

## 4.1 Install Chipset Driver


All drivers can be found on the Avalue Official Website:  
[www.avalue.com](http://www.avalue.com).




**Note:** The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.




**Step 3. Click Install.**



**Step1. Click Next.**



**Step 4. Installing.**



**Step 2. Click Accept.**



**Step 5. Click Finish to complete setup.**


## 4.2 Install VGA Driver

All drivers can be found on the Avalue Official Website:

[www.avalue.com](http://www.avalue.com).




**Note:** The installation procedures and screen shots in this section are based on Windows 10 operation system.




**Step 3. Click Repair.**




**Step 1. Click Begin installation.**



**Step 4. Installing.**



**Step 2. Click I agree.**



**Step 5. Click Finish to complete setup.**


## 4.3 Install ME Driver

All drivers can be found on the Avalue Official Website:


[www.avalue.com](http://www.avalue.com).




**Note:** The installation procedures and screen shots in this section are based on Windows 10 operation system.




**Step 3. Click Next.**




**Step 1. Click Next** to continue installation.



**Step 4. Click Next.**



**Step 2. Click Next.**



**Step 5. Click Finish** to complete setup.


## 4.4 Install Audio Driver

All drivers can be found on the Avalue Official Website:


[www.avalue.com](http://www.avalue.com).




**Note:** The installation procedures and screen shots in this section are based on Windows 10 operation system.




**Step 1. Into Device Manager, Click High Definition Audio Controller.**




**Step 2. Click Update driver.**




**Step 3. Click Browse my computer for drivers.**




**Step 4. Click Browse.**




**Step 5. Click OK.**




Step 6. Installing.




Step 7. Click **Close**.



Step 8. Install **Realtek Audio Driver**.



Step 9. Installing.



Step 10. Click **Finish** to complete setup.


## 4.5 Install Serial IO Driver

All drivers can be found on the Avalue Official Website:

[www.avalue.com](http://www.avalue.com).



**Note:** The installation procedures and screen shots in this section are based on Windows 10 operation system.



**Step 3. Click Next.**




**Step 1. Click Next** to continue installation.



**Step 4. Click Next.**



**Step 2. Click Next.**



**Step 5. Click Finish** to complete setup.



**Step 6.** Click **Finish** to complete setup.


## 4.6 Install Ethernet Driver

All drivers can be found on the Avalue Official Website:


[www.avalue.com](http://www.avalue.com).



**Note:** The installation procedures and screen shots in this section are based on Windows 10 operation system.




**Step 1. Click Install Drivers and Software.**




**Step 2. Click Next.**



**Step 3. Click Next.**




**Step 4. Click Next.**



**Step 5. Click Install.**



Step 6. Installing.



Step 7. Click **Finish** to complete setup.

## 5.BIOS Setup

---

## 5.1 Introduction

The BIOS setup program allows users to modify the basic system configuration. In this following chapter will describe how to access the BIOS setup program and the configuration options that may be changed.

## 5.2 Starting Setup

AMI BIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the NVRAM and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing <ESC> or <Del> immediately after switching the system on, or

By pressing the <ESC> or <Del> key when the following message appears briefly at the left-top of the screen during the POST (Power On Self Test).

**Press <ESC> or <Del> to enter SETUP**

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

## 5.3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Button	Description
↑	Move to previous item
↓	Move to next item
←	Move to the item in the left hand
→	Move to the item in the right hand
Esc key	Main Menu -- Quit and not save changes into NVRAM Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 key	Previous Values
F3 key	Optimized defaults
F4 key	Save & Exit Setup

- **Navigating Through The Menu Bar**

Use the left and right arrow keys to choose the menu you want to be in.



**Note:** Some of the navigation keys differ from one screen to another.

- **To Display a Sub Menu**

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “➤” pointer marks all sub menus.

## 5.4 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or the <Enter> key again.

## 5.5 In Case of Problems

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AMI BIOS supports an override to the NVRAM settings which resets your system to its defaults.



The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both BIOS Vendor and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

5.6 BIOS setup

Once you enter the Aptio Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

5.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.



### 5.6.1.1 System Language

This option allows choosing the system default language.

### 5.6.1.2 System Date

Use the system date option to set the system date. Manually enter the Month, day and year.

### 5.6.1.3 System Time

Use the system time option to set the system time. Manually enter the hours, minutes and seconds.



**Note:** The BIOS setup screens shown in this chapter are for reference purposes only, and may not exactly match what you see on your screen.


Visit the Avalue website ([www.avalue.com](http://www.avalue.com)) to download the latest product and BIOS information.

## 5.6.2 Advanced Menu

This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.




5.6.2.1 Connectivity Configuration



Item	Options	Description
CNVi Mode	Disable Integrated Auto Detection <b>[Default]</b>	This option configures Connectivity. [Auto Detection] means that if Discrete solution is discovered it will be enabled by default. Otherwise Integrated solution (CNVi) will be enabled; [Disable Integrated] disables Integrated Solution. NOTE: When CNVi is present, the GPIO pins that are used for radio.


5.6.2.2 CPU Configuration

Use the CPU configuration menu to view detailed CPU specification and configure the CPU.



Item	Options	Description
Intel (VMX) Virtualization Technology	Disabled Enabled[Default]	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.
Active Efficient-cores	All[Default] 3 2 1	Number of E-cores to enable in each processor package. Note: Number of Cores and E-cores are looked at together. When both are {0,0}, Pcode will enable all cores.


#### 5.6.2.2.1 Efficient-core Information



#### 5.6.2.3 Power & Performance




5.6.2.3.1 CPU – Power Management Control




Item	Option	Description
Intel® SpeedStep™	Enabled[Default], Disabled	Allows more than two frequency ranges to be supported.
Intel® Speed Shift Technology	Enabled[Default], Disabled	Enable/Disable Intel® Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.
Turbo Mode	Enabled[Default], Disabled	Enable/Disable processor Turbo Mode (requires EMTTM enabled too). AUTO means enabled.
C States	Enabled[Default], Disabled	Enable/Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.

5.6.2.3.1.1 View/Configure Turbo Options



5.6.2.4 PCH-FW Configuration




5.6.2.4.1 Firmware Update Configuration




Item	Option	Description
ME FW Image Re-Flash	Disabled[Default], Enabled	Enable/Disable Me FW Image Re-Flash function.

5.6.2.4.2 PTT Configuration




5.6.2.5 Trusted Computing



Item	Options	Description
Security Device Support	Disable, Enable <b>[Default]</b>	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

5.6.2.6 APCI Settings




Item	Options	Description
Enable Hibernation	Disabled Enabled <b>[Default]</b> ,	Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may not be effective with some OS.

ACPI Sleep State	Suspend Disabled, S3 (Suspend to RAM)[Default]	Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed.
------------------	---	---


5.6.2.7 IT5782 Super IO Configuration

You can use this item to set up or change the IT5782 Super IO configuration for serial ports. Please refer to 5.6.2.7.1 ~ 5.6.2.7.2 for more information.




Item	Description
Serial Port 1 Configuration	Set Parameters of Serial Port 1 (COMA).
Serial Port 2 Configuration	Set Parameters of Serial Port 2 (COMB).

5.6.2.7.1 Serial Port 1 Configuration




Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).
UART 232 422 485	UART 232[Default] UART 422 UART 485	Change the Serial Port as RS232/422/485.

5.6.2.7.2 Serial Port 2 Configuration




Item	Option	Description
Serial Port	Enabled[Default], Disabled	Enable or Disable Serial Port (COM).

5.6.2.8 EC 5782 HW Monitor




Item	Options	Description
Smart Fan Function	Enabled, Disabled[Default]	Enables or Disables Smart Fan.

5.6.2.9 S5 RTC Wake Settings



Item	Options	Description
Wake system from S5	Disabled[Default], Fixed Time Dynamic Time	Enable or disable System wake on alarm event. Select Fixed Time, system will wake on the hr::min::sec specified. Select Dynamic Time, System will wake on the current time + Increase minute(s).


5.6.2.10 Serial Port Console Redirection



Item	Options	Description
Console Redirection	Disabled[Default], Enabled	Console Redirection Enable or Disable.
Console Redirection EMS	Disabled[Default], Enabled	Console Redirection Enable or Disable.

5.6.2.11 USB Configuration

The USB Configuration menu helps read USB information and configures USB settings.




Item	Options	Description
<b>XHCI Hand-off</b>	Enabled <b>[Default]</b> Disabled	This is a workaround for OSES without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
<b>USB Mass Storage Driver Support</b>	Disabled Enabled <b>[Default]</b>	Enable/Disable USB Mass Storage Driver Support.
<b>USB transfer time-out</b>	1 sec 5 sec 10 sec 20 sec <b>[Default]</b>	The time-out value for Control, Bulk, and Interrupt transfers.
<b>Device reset time-out</b>	10 sec 20 sec <b>[Default]</b> 30 sec 40 sec	USB mass storage device Start Unit command time-out.
<b>Device power-up delay</b>	Auto <b>[Default]</b> Manual	Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100ms, for a Hub port the delay is taken form Hub descriptor.
<b>Mass Storage Devices</b>	Auto <b>[Default]</b> Floppy Forced FDD Hard Disk CD-ROM	Mass storage device emulation type. 'AUTO' enumerates devices according to their media format. Optical drives are emulated as 'CDROM', drives with no media will be emulated according to a drive type.

5.6.2.12 Network Stack Configuration




Item	Options	Description
Network Stack	Enabled Disabled <b>[Default]</b>	Enable/Disable UEFI Network Stack.


5.6.2.13 NVMe Configuration



5.6.3 Chipset




5.6.3.1 System Agent (SA) Configuration




Item	Option	Description
VT-d	Enabled Disabled <b>[Default]</b>	VT-d capability.

5.6.3.1.1 Memory Configuration




5.6.3.1.2 Graphics Configuration




Item	Option	Description
GTT Size	2MB	Select the GTT Size.
	4MB	
	8MB[Default]	
Aperture Size	128MB	Select the Aperture Size. Note: Above 4GB MMIO BIOS assignment is automatically enabled when selecting > 2048MB aperture. To use this feature, please disable CSM Support.
	256MB[Default]	
	512MB	
	1024MB	

5.6.3.2 PCH-IO Configuration



5.6.3.2.1 PCI Express Configuration



### 5.6.3.2.1.1 PCI Express Root Port 7(LAN1-I226)




Item	Option	Description
<b>PCI Express Root Port 7(LAN1-I226)</b>	Enabled[Default], Disabled	Control the PCI Express Root Port.
<b>ASPM</b>	Disabled[Default], L1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
<b>L1 Substates</b>	Disabled[Default] L1.1 L1.1 & L1.2	PCI Express L1 Substates settings.
<b>PTM</b>	Disabled[Default], Enabled	Enable/Disable Precision Time Measurement.
<b>PCIe Speed</b>	Auto[Default] Gen1 Gen2 Gen3	Configure PCIe Speed.

5.6.3.2.1.2 PCI Express Root Port 9(M.2 KeyE)




Item	Option	Description
<b>PCI Express Root Port 9(M.2 KeyE)</b>	Enabled <b>[Default]</b> , Disabled	Control the PCI Express Root Port.
<b>ASPM</b>	Disabled <b>[Default]</b> , L1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
<b>L1 Substates</b>	Disabled <b>[Default]</b> L1.1 L1.1 & L1.2	PCI Express L1 Substates settings.
<b>PTM</b>	Disabled <b>[Default]</b> , Enabled	Enable/Disable Precision Time Measurement.
<b>PCIe Speed</b>	Auto <b>[Default]</b> Gen1 Gen2 Gen3	Configure PCIe Speed.

### 5.6.3.2.1.3 PCI Express Root Port 10(LAN2-I226)



Item	Option	Description
<b>PCI Express Root Port 10(LAN2-I226)</b>	Enabled <b>[Default]</b> , Disabled	Control the PCI Express Root Port.
<b>ASPM</b>	Disabled <b>[Default]</b> , L1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
<b>L1 Substates</b>	Disabled <b>[Default]</b> L1.1 L1.1 & L1.2	PCI Express L1 Substates settings.
<b>PTM</b>	Disabled <b>[Default]</b> , Enabled	Enable/Disable Precision Time Measurement.
<b>PCIe Speed</b>	Auto <b>[Default]</b> Gen1 Gen2 Gen3	Configure PCIe Speed.

5.6.3.2.1.4 PCI Express Root Port 12(M.2 KeyB)



Item	Option	Description
<b>PCI Express Root Port 12(M.2 KeyB)</b>	Enabled[ <b>Default</b> ], Disabled	Control the PCI Express Root Port.
<b>ASPM</b>	Disabled[ <b>Default</b> ], L1 Auto	Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM.
<b>L1 Substates</b>	Disabled[ <b>Default</b> ] L1.1 L1.1 & L1.2	PCI Express L1 Substates settings.
<b>PTM</b>	Disabled[ <b>Default</b> ], Enabled	Enable/Disable Precision Time Measurement.
<b>PCIe Speed</b>	Auto[ <b>Default</b> ] Gen1 Gen2 Gen3	Configure PCIe Speed.

5.6.3.2.2 SATA Configuration




Item	Options	Description
SATA Controller(s)	Enabled[Default] Disabled,	Enable/Disable SATA Device.
Port 0	Enabled[Default] Disabled	Enable or Disable SATA Port.

5.6.3.2.3 HD Audio Configuration



Item	Option	Description
HD Audio	Disabled Enabled[Default]	Control Detection of the HD-Audio device. Disable = HDA will be unconditionally disabled Enabled = HDA will be unconditionally enabled.


### 5.6.3.3 Board & Panel Configuration



Item	Option	Description
Active Panel	Disabled[Default] Enabled	Active Internal LVDS(eDP->Ch7513-to-LVDS).
CH7513 EDID Panel Option	1024x768 24/1[Default] 800x600 18/1 1024x768 18/1 1366x768 18/1 1024x600 18/1 1280x800 18/1 1920x1200 24/2 1920x1080 18/2 1280x1024 24/2 1440x900 18/2 1600x1200 24/2 1366x768 24/1 1920x1080 24/2 7513-eDP	Port1-EDP to LVDS(Chrotel 7513) Panel EDID Option.
Panel Brightness Control Method	BIOS[Default] OS Driver	Panel Brightness Control Method. 1.BIOS 2.OS Driver.
Panel Brightness	00% 25% 50% 75% 100%[Default]	Select Panel back light PWM duty.
Panel Back Light PWM Frequency	200[Default] 300	Select Panel back light PWM Frequency.

	400 500 700 1k 2k 3k 5k 10k 20k	
<b>ErP Function</b>	Disabled[ <b>Default</b> ] Enabled	ErP Function (Deep S5).
<b>PWR-On After PWR-Fail</b>	Off[ <b>Default</b> ] On Last state	AC loss resume.
<b>Wake Up by Ring</b>	Disabled Enabled[ <b>Default</b> ]	Wake Up by Ring from S3/S4/S5.
<b>Watch Dog</b>	Disabled[ <b>Default</b> ] 30 sec 40 sec 50 sec 1 min 2 min 10 min 30 min	Select WatchDog.
<b>USB Standby Power</b>	Disabled Enabled[ <b>Default</b> ]	Enable/Disabled USB Standby Power during S3/S4/S5.
<b>M.2 Key-B P38 Setting</b>	Low[ <b>Default</b> ] High	Set M.2 KeyB Pin38(DEVSLP) as Low/High.
<b>SHOW DMI INFO</b>	Disabled[ <b>Default</b> ] Enabled	SHOW DMI INFO.

## 5.6.4 Security



EPC-ASL


- **Administrator Password**

Set setup Administrator Password


- **User Password**

Set User Password

5.6.4.1    **Secure Boot**





5.6.5    **Boot**



Item	Option	Description
Setup Prompt Timeout	1~ 65535	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
Bootup NumLock State	On[Default] Off	Select the keyboard NumLock state
Quiet Boot	Disabled[Default] Enabled	Enables or disables Quiet Boot option
Boot Option #1/2	Set the system boot order.	

### 5.6.6 Save and Exit



## **EPC-ASL**

### **5.6.6.1 *Save Changes and Reset***

Reset the system after saving the changes.

### **5.6.6.2 *Discard Changes and Reset***

Any changes made to BIOS settings during this session of the BIOS setup program are discarded. The setup program then exits and reboots the controller.

### **5.6.6.3 *Restore Defaults***

This option restores all BIOS settings to the factory default. This option is useful if the controller exhibits unpredictable behavior due to an incorrect or inappropriate BIOS setting.

### **5.6.6.4 *Launch EFI Shell from filesystem device***

Attempts to Launch EFI Shell application (Shellx64.efi) from one of the available filesystem devices.

## 6. Maintenance & Troubleshooting

---

### System Maintenance Introduction

If the components of the product fail they must be replaced.

Please contact the system reseller or vendor to purchase the replacement parts. Please follow the safety precautions outlined in the sections that follow

### General Safety Precautions

Please ensure the following safety precautions are adhered to at all times.

1. Follow the electrostatic precautions outlined below whenever the device is opened.
2. Make sure the power is turned off and the power cord is disconnected whenever the product is being installed, moved or modified.
3. To prevent the risk of electric shock, make sure power cord is unplugged from wall socket. To fully disengage the power to the unit, please disconnect the power cord from the AC outlet. Refer servicing to qualified service personnel. The AC outlet shall be readily available and accessible.
4. Do not apply voltage levels that exceed the specified voltage range. Doing so may cause fire and/or an electrical shock. Use a power cord that matches the voltage of the power outlet, which has been approved and complies with the safety standard of your particular country.
5. Electric shocks can occur if the product chassis is opened when it is running. To avoid risk of electric shock, this device must only be connected to a supply mains with protective earth.
6. Do not drop or insert any objects into the ventilation openings of the product.
7. If considerable amounts of dust, water, or fluids enter the device, turn off the power supply immediately, unplug the power cord, and contact your dealer or the nearest service center.
8. This equipment is not suitable for use in locations where children are likely to be present.
9. DO NOT:
  - Drop the device against a hard surface.
  - In a site where the ambient temperature exceeds the rated temperature.

## Anti-Static Precautions

**WARNING:**

Failure to take ESD precautions during the installation of the product may result in permanent damage to the product and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the product. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the product is opened and any of the electrical components are handled, the following anti-static precautions are strictly adhered to.

- Wear an anti-static wristband: Wearing a simple anti-static wristband can help to prevent ESD from damaging any electrical component.
- Self-grounding: Before handling any electrical component, touch any grounded conducting material. During the time the electrical component is handled, frequently touch any conducting materials that are connected to the ground.
- Use an anti-static pad: When configuring or working with an electrical component, place it on an anti-static pad. This reduces the possibility of ESD damage.
- Only handle the edges of the electrical component. When handling the electrical component, hold the electrical component by its edges. Please ensure the following safety precautions are adhered to at all times.

## Maintenance and Cleaning

When maintaining or cleaning the product, please follow the guidelines below.

### **WARNING:**

- For safety reasons, turn-off the power and unplug the box PC before cleaning.
- If you dropped any material or liquid such as water onto the box PC when cleaning, unplug the power cable immediately and contact your dealer or the nearest service center. Always make sure your hands are dry when unplugging the power cable.

### Maintenance and Cleaning

Prior to cleaning any part or component of the product, please read the details below.

- Except for the box PC, never spray or squirt liquids directly onto any other components. To clean the box PC, gently wipe it with a piece of soft dry cloth or a slightly moistened cloth.
- The interior of the device does not require cleaning. Keep fluids away from the device interior.
- Be cautious of all small removable components when vacuuming the device.
- Never drop any objects or liquids through the openings of the device.
- Be cautious of any possible allergic reactions to solvents or chemicals used when cleaning the device.
- Avoid eating, drinking and smoking within vicinity of the device.

## Cleaning Tools

Some components in the box PC may only be cleaned using a product specifically designed for the purpose. In such case, the product will be explicitly mentioned in the cleaning tips. Below is a list of items to use when cleaning the box PC.

- Cloth: Although paper towels or tissues can be used, a soft, clean piece of cloth is recommended when cleaning the device.
- Water or rubbing alcohol: A cloth moistened with water or rubbing alcohol can be used to clean the device.
- Using solvents: The use of solvents is not recommended when cleaning the device as they may damage the plastic parts.
- Vacuum cleaner: Using a vacuum specifically designed for computers is one of the best methods of cleaning the device. Dust and dirt can restrict the airflow in the device and cause its circuitry to corrode.
- Cotton swabs: Cotton swabs moistened with rubbing alcohol or water are excellent tools for wiping hard to reach areas.
- Foam swabs: Whenever possible, it is best to use lint free swabs such as foam swabs for cleaning.

# 7. Product Application

For detailed instructions on the operation of the Watchdog Timer features of this box PC, please refer to the comprehensive guide available in the "AvalueIOAPI" manual. Please reaching out to your respective distributors, Avalue technical support team, or Avalue customer service representatives for further information. Feel free to inquire about this supplementary resource to enhance your understanding of the Watchdog Timer Application for optimal utilization of your box PC.