

BC680R

12th/13th Gen Intel® Core™ Processors ATX Motherboard
with Intel® R680E Chipset

User's Manual

1st Ed –12 January 2024

FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.

(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

Copyright Notice

Copyright © 2023 Avalue Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

Trademark Acknowledgement

Brand and product names are trademarks or registered trademarks of their respective owners.

Disclaimer

Avalue Technology Inc. reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. Avalue Technology assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or masks work rights to these products, and makes no representations or warranties that

these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. Avalue Technology Inc. makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

Life Support Policy

Avalue Technology's PRODUCTS ARE NOT FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS WITHOUT THE PRIOR WRITTEN APPROVAL OF Avalue Technology Inc.

As used herein:

1. Life support devices or systems are devices or systems which, (a) are intended for surgical implant into body, or (b) support or sustain life and whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.
2. A critical component is any component of a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness.

A Message to the Customer

Avalue Customer Services

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.avalue.com.tw/>

BC680R User's Manual

Product Warranty

Avalue warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Avalue, or which have been subject to misuse, abuse, accident or improper installation. Avalue assumes no liability under the terms of this warranty as a consequence of such events. Because of Avalue's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If any of Avalue's products is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time, and freight. Please consult your dealer for more details. If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU type and speed, Avalue's products model name, hardware & BIOS revision number, other hardware and software used, etc.) Note anything abnormal and list any on-screen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information available.
3. If your product is diagnosed as defective, obtain an RMA (return material authorization) number from your dealer. This allows us to process your good return more quickly.
4. Carefully pack the defective product, a complete Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Content

| | |
|--|-----------|
| 1. Getting Started | 8 |
| 1.1 Safety Precautions | 8 |
| 1.2 Packing List..... | 8 |
| 1.3 Document Amendment History | 9 |
| 1.4 Manual Objectives..... | 10 |
| 1.5 System Specifications | 11 |
| 1.6 Architecture Overview—Block Diagram | 15 |
| 2. Hardware Configuration | 16 |
| 2.1 Product Overview..... | 17 |
| 2.2 Jumper and Connector List..... | 18 |
| 2.3 Setting Jumpers & Connectors | 20 |
| 2.3.1 Clear CMOS (CLCMOS1)..... | 20 |
| 2.3.2 AT/ATX Power Mode Select (JPSON1)..... | 20 |
| 2.3.3 COM POWER SETTING (JCOMPWR1~6) | 21 |
| 2.3.4 CPU fan connector (CPUFAN1)..... | 21 |
| 2.3.5 System fan connector (CHA_FAN 1)..... | 22 |
| 2.3.6 System fan connector (CHA_FAN 2)..... | 22 |
| 2.3.7 System Panel (F_PANEL)..... | 23 |
| 2.3.8 ATX Power connector (ATXPWR1) | 23 |
| 2.3.9 ATX Power connector (ATXPWR1) | 24 |
| 2.3.10 Serial Port connectors (COM1~6)..... | 24 |
| 2.3.11 Serial ATA Connector (SATA2, SATA4)..... | 25 |
| 2.3.12 Serial ATA Connector (SATA1, SATA3)..... | 25 |
| 2.3.13 USB connectors (USB2_HR1, USB2_HR2, USB2_HR3, USB2_HR4) | 26 |
| 2.3.14 USB3.2 connector (USB89)..... | 26 |
| 2.3.15 8 bit GPIO header (JDIO1)..... | 27 |
| 2.3.16 Front Audio connector (FP_AUDIO1)..... | 27 |
| 2.3.17 Amplifier connector (JAMP1)..... | 28 |
| 2.3.18 SM bus connector (SMB1) | 28 |
| 2.3.19 LAN LED status connector (LAN_LED1)..... | 29 |
| 2.3.20 Chassis intrusion connector (JCASE1) | 29 |
| 3. BIOS Setup | 30 |
| 3.1 BIOS setup..... | 31 |
| 3.6.1 Main Menu..... | 31 |
| 3.6.1.1 System Date | 31 |
| 3.6.1.2 System Time..... | 31 |
| 3.6.2 Advanced Menu | 32 |

BC680R User's Manual

| | | |
|-------------|--|----|
| 3.6.2.1 | CPU Configuration..... | 32 |
| 3.6.2.2 | CPU - Power Management Control..... | 33 |
| 3.6.2.3 | PCH-FW Configuration..... | 34 |
| 3.6.2.4 | Thunderbolt(TM) Configuration | 35 |
| 3.6.2.5 | Trusted Computing | 35 |
| 3.6.2.6 | ACPI Settings | 36 |
| 3.6.2.7 | NCT6126D Super IO Configuration..... | 37 |
| 3.6.2.7.1 | Serial Port 1 Configuration | 38 |
| 3.6.2.7.2 | Serial Port 2 Configuration | 39 |
| 3.6.2.7.3 | Serial Port 3 Configuration | 40 |
| 3.6.2.7.4 | Serial Port 4 Configuration | 41 |
| 3.6.2.7.5 | Serial Port 5 Configuration | 42 |
| 3.6.2.7.6 | Serial Port 6 Configuration | 43 |
| 3.6.2.8 | Hardware Monitor | 44 |
| 3.6.2.8.1 | Hardware Monitor | 44 |
| 3.6.2.8.2 | Smart Fan Function | 45 |
| 3.6.2.9 | S5 RTC Wake Settings..... | 47 |
| 3.6.2.12 | USB Configuration..... | 50 |
| 3.6.2.13 | Network Stack Configuration..... | 51 |
| 3.6.2.14 | IP Configuration..... | 52 |
| 3.6.2.15 | NVMe Configuration | 53 |
| 3.6.2.16 | Remote Server Configuration | 53 |
| 3.6.3 | Chipset | 54 |
| 3.6.3.1 | System Agent (SA) Configuration..... | 55 |
| 3.6.3.1.1 | Memory Configuration | 55 |
| 3.6.3.2 | PCH-IO Configuration..... | 60 |
| 3.6.3.2.1 | PCH-IO Configuration..... | 61 |
| 3.6.3.2.1.1 | PCI Express Root Port 1(x4 Slot 3)..... | 61 |
| 3.6.3.2.1.2 | PCI Express Root Port 5(x1 Slot 1)..... | 62 |
| 3.6.3.2.1.3 | PCI Express Root Port 6(x1 Slot 5)..... | 63 |
| 3.6.3.2.1.4 | PCI Express Root Port 7(x1 Slot 6)..... | 64 |
| 3.6.3.2.1.5 | PCI Express Root Port 8(x1 Key E)..... | 65 |
| 3.6.3.2.1.6 | PCI Express Root Port 13(x4 Key M)..... | 66 |
| 3.6.3.2.1.7 | PCI Express Root Port 21(x4 Slot 4)..... | 67 |
| 3.6.3.2.1.8 | PCI Express Root Port 25(x4 Slot 7)..... | 68 |
| 3.6.3.2.2 | SATA Configuration..... | 69 |
| 3.6.3.2.3 | USB Configuration..... | 70 |
| 3.6.3.2.4 | HD Audio Configuration..... | 71 |
| 3.6.3.2.5 | Seriallo Configuration | 71 |
| 3.6.4 | Security | 72 |

| | | |
|-----------|--|-----------|
| 3.6.5 | Boot | 73 |
| 3.6.6 | Save & Exit | 75 |
| 3.6.6.1 | Save Changes and Exit | 75 |
| 3.6.6.2 | Discard Changes and Exit | 75 |
| 3.6.6.3 | Save Changes and Reset | 75 |
| 3.6.6.4 | Restore Defaults | 75 |
| 4. | Drivers Installation..... | 76 |
| 4.1 | Install Chipset Driver | 77 |
| 4.2 | Install VGA Driver..... | 78 |
| 4.3 | Install ME Driver | 79 |
| 4.4 | Install Audio Driver (For Realtek ALC888S HD Audio)..... | 80 |
| 4.5 | Install LAN Driver | 81 |
| 4.6 | Install Serial IO Driver | 82 |
| 4.7 | Install Intel_DTT | 83 |
| 4.8 | Install GNA..... | 84 |
| 5. | Mechanical Drawing | 85 |
| 5.1 | Mechanical Drawing..... | 86 |

1. Getting Started

1.1 Safety Precautions

Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

1.2 Packing List

Before you begin installing your single board, please make sure that the following materials have been shipped:

- 1 x BC680R Motherboard
- 1 x I/O Shield



If any of the above items is damaged or missing, contact your retailer.

1.3 Document Amendment History

| Revision | Date | By | Comment |
|-----------------|---------------|--------|-----------------|
| 1 st | November 2023 | Avalue | Initial Release |

1.4 Manual Objectives

This manual describes in details Avalue Technology BC680R Single Board.

We have tried to include as much information as possible but we have not duplicated information that is provided in the standard IBM Technical References, unless it proved to be necessary to aid in the understanding of this board.

We strongly recommend that you study this manual carefully before attempting to set up BC680R or change the standard configurations. Whilst all the necessary information is available in this manual we would recommend that unless you are confident, you contact your supplier for guidance.

Please be aware that it is possible to create configurations within the CMOS RAM that make booting impossible. If this should happen, clear the CMOS settings, (see the description of the Jumper Settings for details).

If you have any suggestions or find any errors regarding this manual and want to inform us of these, please contact our Customer Service department with the relevant details.

1.5 System Specifications

| System | |
|---------------------------|---|
| CPU | Intel® 12/13th Gen Core™ i9/i7/i5/i3 Processor, supports LGA 1700 CPU Up to 65W Max |
| BIOS | AMI uEFI BIOS, 256Mbit SPI Flash ROM |
| System Chipset | Intel® R680E chipsets |
| I/O Chip | Nuvoton NCT6126D (eSPI super IO) |
| System Memory | 4 x DIMM Up to 128GB Max Dual Channel DDR5 4400 MHz with ECC Support (Optional ECC Support depending on selected CPU) |
| Watchdog Timer | H/W Reset, 5~255 seconds/5~255 minutes |
| H/W Status Monitor | CPU temperature monitoring Voltages monitoring CPU fan speed control |
| RAID | Support RAID 0, 1, 5, 10 |
| TPM | TPM 2.0 |
| iAMT | Intel® AMT 16 |
| Other | 1 x Thunderbolt Header(optional) |
| Expansion Slot | |
| M.2 | 1 x M.2 2230 E Key with CNVi Support (PCIe x1 + USB 2.0) |
| PCIe | 1 x Gen 5 PCIe x16 (x16 Physical Black) (Slot 2) 2 x Gen 4 PCIe x4 (x16 Physical Orange) (Slot 4 & 7) 1 x Gen 3 PCIe x4 (x16 Physical Brown) (Slot 3) 1 x Gen 3 PCIe x4 (x16 Physical Yellow) (Slot 3) 1 x Gen 3 PCIe x1 (x16 Physical Yellow) (Slot 6) 2 x Gen 3 PCIe x1 Open Ended (Slot 1 & 5) |
| Storage | |
| M.2 | 1 x M.2 2242/2280/22110 M Key NVMe (PCIe x4 + SATA III) 1 x M.2 2242/2280/22110 M Key NVMe (PCIe x4 Only) |
| SATA | 4 x SATA III |
| Edge I/O | |
| LAN | 2 x 2.5 Gigabit Ethernet |
| USB 3.2 | 6 x USB 3.2 Gen 2x1 Type-A Connectors 1 x USB 3.2 Gen 2x2 Type-C Connector |
| DP | 2 x DP++ |
| HDMI | 2 x HDMI 2.0b |
| Audio | Line out, Mic in |
| Onboard I/O | |

BC680R User's Manual

| | |
|-------------------------------|---|
| COM | <p>COM1/2/4/5/6 support RS232</p> <p>5 x 2 x 5 pin, pitch 2.00mm connector for COM1~2 and COM4~COM6 to support RS232</p> <p>5 x 2 x 3 pin, pitch 2.54mm connector for COM1~2 and COM4~COM6 pin9 RI/5V/12V jumper select.</p> <p><u>COM3: support RS232/422/485</u></p> <p>1 x 2 x 5 pin, pitch 2.00mm connector for COM3 to support RS232/RS422/RS485 by BIOS Selection</p> <p>1 x 2 x 3 pin, pitch 2.54mm connector for COM3 pin9 RI/5V/12V jumper select.</p> |
| USB 2.0 | 4 x 2 x 5 pin, pitch 2.54mm connector for 8 x USB 2.0 |
| USB 3.2 | 1 x 2 x 10 pin, pitch 2.00mm connector for 2 x USB 3.2 Gen 1x1 |
| GPIO | 1 x 2 x 6 pin, pitch 2.00mm connector for GPIO: 8 bits |
| CPU/System FAN | <p>1 x 1 x 4 pin, pitch 2.54mm CPU fan connector with smart fan function supported</p> <p>1 x 1 x 4 pin, pitch 2.54mm System fan connector with smart fan function supported</p> <p>1 x 1 x 4 pin, pitch 2.54mm System fan connector with smart fan function supported</p> |
| Buzzer | Onboard Buzzer |
| Front Panel | 1 x 2 x 5 pin, pitch 2.54mm connector for front panel |
| RTC Battery | 1 x Horizontal type battery connector (CR2032 Coin Battery) |
| AT/ATX Selector | <p>1 x 1 x 3 pin pitch 2.00mm connector for AT/ATX jumper</p> <p>1 x 2 x 12 pin ATX power connector</p> <p>1 x 2 x 4 pin ATX 12V power connector</p> |
| Clear CMOS | 1 x 1 x 3pin, pitch 2.00mm connector for CMOS Clear |
| I2C | 1 x 1 x 4 pin, pitch 2.00mm connector for I2C |
| SMBus | 1 x 1 x 5 pin, pitch 2.54mm connector for SMBus |
| Chassis Intrusion | 1 x 1 x 2 pin, pitch 2.54mm connector for Chassis Intrusion Switch |
| PS/2 KB&MS | 1 x 1 x 6 pin, pitch 2.54mm connector for PS/2 KB&MS |
| LAN LED | 1 x 2 x 5 pin, pitch 2.54mm connector for LAN LED status connector |
| BIOS SPI | 1 x 2 x 4 pin, pitch 2.54mm connector for BIOS SPI |
| eSPI | 1 x 2 x 5 pin, pitch 2.00mm connector for eSPI |
| SMBus | 1 x 1 x 5 pin, pitch 2.00mm connector for SMBus |
| ME | 1 x 1 x 3 pin, pitch 2.00mm connector for ME |
| Audio | <p>1 x 2 x 5 pin, pitch 2.54mm connector for front Audio</p> <p>1 x 1 x 4 pin, pitch 2.00mm connector for Amplifier</p> |
| Display | |
| Graphic Chipset | Intel® 12th /13th Generation CPU integrated |
| Spec. & Resolution | <p>2 x HDMI 2.0b 4K@60Hz</p> <p>2 x Dual Mode DisplayPort 1.4a 4K@60Hz</p> |
| Multiple Display | 4 Independent Displays |

| Ethernet | |
|---|--|
| LAN Chipset | 2 x Intel® i225-LM 2.5G Gigabit Controller |
| LAN Spec. | Intel® i225-LM: 10/100/1000/2500 Base-Tx GbE compatible |
| Mechanical & Environmental Specification | |
| Power Requirement | +12V / +5V / 5VSB /+3.3V /-12V |
| ACPI | Single power ATX Support S0, S3, S4, S5 |
| Power Mode | AT / ATX mode Switchable Through Jumper |
| Operating Temp. | 0~60°C (32~140°F), 0.5m/s airflow **Note: Intel PTAT suggests** Turbo off Workload – IA 100% / GT 100% PL2(Power Limit) set as default |
| Storage Temp. | -20~ +80°C (-4 ~ 176°F) |
| Operating Humidity | 40°C @ 5% to 90% Relative Humidity, Non-condensing |
| Size (L x W) | 12" x 9.6" (304.8mm x 243.84mm) |
| Weight | 1.85lbs (0.84kg) |
| Vibration Test | <p>Package Vibration Test Reference IEC60068-2-64 Testing procedures Test Fh: Vibration broadband random Test</p> <ol style="list-style-type: none"> 1. PSD: 0.026G²/Hz, 2.16 Grms 2. Non-operation mode 3. Test Frequency: 5-500Hz 4. Test Axis: X,Y and Z axis 5. 30 min. per each axis 6. IEC 60068-2-64 Test: Fh <p>Random Vibration Operation Reference IEC60068-2-64 Testing procedures Test Fh : Vibration broadband random Test</p> <ol style="list-style-type: none"> 1. PSD: 0.00202023G²/Hz 0.5 Grms 2. Operation mode 3. Test Frequency : 5-500Hz 4. Test Axis : X,Y and Z axis 5. 30 minutes per each axis 6. IEC 60068-2-64 Test:Fh <p>Random Vibration Non Operation Reference IEC60068-2-64 Testing procedures</p> |

BC680R User's Manual


| | |
|------------------------------|--|
| | <p>Test Fh : Vibration broadband random Test</p> <ol style="list-style-type: none"> 1. PSD: 0.00202023G²/Hz 0.5 Grm 2. Non Operation mode 3. Test Frequency : 5-500Hz 4. Test Axis : X,Y and Z axis 5. 30 minutes per each axis 6. IEC 60068-2-64 Test:Fh |
| <p>Drop Test</p> | <p>Package Drop</p> <p>Reference ISTA 2A, Method : IEC-60068-2-32 Test: Ed</p> <p>Drop Test</p> <ol style="list-style-type: none"> 1 One corner , three edges, six faces 2 ISTA 2A, IEC-60068-2-32 Test:Ed |
| <p>OS Information</p> | <p>BIOS Support:</p> <p>Win11 64bit UEFI</p> <p>**Note: Windows 11 is not a LTSC release and will be supported on the Intel CCG Client roadmap.</p> <p>NEX Network & Edge customers may install non-LTSC releases(e.g. Win11) on NEX Network & Edge processors.**</p> <p>Win10 64bit UEFI</p> <p>Linux</p> |



Note: Specifications are subject to change without notice.


1.6 Architecture Overview—Block Diagram

The following block diagram shows the architecture and main components of BC680R.



2. Hardware Configuration


2.1 Product Overview



2.2 Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board's jumpers and connectors.

Jumpers

| Label | Function | Note |
|------------|----------------------|----------------------------|
| CLCMOS1 | Clear CMOS | 3 x 1 header, pitch 2.00mm |
| JPSON1 | AT/ATX Mode Select | 3 x 1 header, pitch 2.00mm |
| JCOMPWR1~6 | COM1~6 POWER SETTING | 3 x 2 header, pitch 2.00mm |


Connectors

| Label | Function | Note |
|----------|-----------------------------|----------------------------|
| CPU_FAN1 | CPU Fan connector | 4 x 1 wafer, pitch 2.54mm |
| CHA_FAN1 | Chassis Fan connector | 4 x 1 wafer, pitch 2.54mm |
| CHA_FAN2 | Chassis Fan connector | 4 x 1 wafer, pitch 2.54mm |
| F_PANEL1 | Intel Front Panel connector | 5 x 2 header, pitch 2.54mm |
| ATX1 | ATX power connectors | 12 x 2 wafer, pitch 4.20mm |


| | | |
|-----------------------------------|---|-------------------------------------|
| ATX12V1 | 12V ATX power connectors | 4 x 2 wafer, pitch 4.20mm |
| COM1~6 | Serial Port Connector | 5 x 2 header, pitch 2.00mm |
| SATA1~4 | SATA Connector | Male connector (Red) |
| FP_Audio | Front Panel Audio Connector | 5 x 2 header, pitch 2.54mm |
| JDIO1 | Digital I/O Connector | 6 x 2 wafer, pitch 2.00mm |
| I2C1 | I2C connector | 4 x 1 wafer, pitch 2.00mm |
| USB89 | Front USB 3.2 Header | 10 x 2 header, pitch 2.00mm |
| USB1011~USB1617 | Front USB 2.0 Headers | 5 x 2 header, pitch 2.54mm |
| KBMS1 | PS/2 Header | 5 x 1 wafer, pitch 2.50mm |
| SMB1 | SMBus connector | 5 x 1 wafer, pitch 2.00mm |
| JAMP1 | Amplifier Connector | 4 x 1 wafer, pitch 2.00mm |
| JCASE1 | Chassis Intrusion Header | 2 x 1 wafer, pitch 2.50mm |
| LANLED1 | LAN LED Header | 5 x 2 header, pitch 2.54mm |
| CPU1 | LGA1700 socket | |
| DIMMA1~B2 | DDR5 UDIMM Slot | Dual channel. (2 DIMMs per channel) |
| PCIEX1_1/ PCIEX1_5 | PCIe x1 Gen3 | X1 (Slot 1,5) |
| PCIEX16_2 | PCIe x16 Gen5 | X16 (Slot 2) |
| PCIEX16_3 | PCIe x4 Gen3 | X16 Physical yellow (Slot 3) |
| PCIEx16_4/ PCIEx16_7 | PCIe x4 Gen4 | X16 Physical yellow (Slot 4,7) |
| PCIEx16_6 | PCIe x1 Gen3 | X16 Physical yellow (Slot 6) |
| HDMI1/2 | HDMI port Connector x 2 | |
| DP1/2 | Display port connector x 2 | |
| USB56 | USB 3.2 Type A Connector x 2 | |
| USB7 | USB 3.2 Type C Connector x 1 | |
| LAN1_USB12/ LAN2_USB34 | RJ-45 Ethernet Connector x 1 USB3.2 Type A Connector x 2 | 2.5 Gigabit Ethernet |
| AUDIO1 | Audio phone jack | Line-out, Mic-in |

2.3 Setting Jumpers & Connectors


2.3.1 Clear CMOS (CLCMOS1)



Normal*




Clear CMOS




* Default


2.3.2 AT/ATX Power Mode Select (JPSON1)



ATX*




AT




* Default



2.3.3 COM POWER SETTING (JCOMPWR1~6)



* Default





2.3.4 CPU fan connector (CPUFAN1)




| Signal | PIN |
|------------|-----|
| GND | 1 |
| +12V | 2 |
| FAN_SPEED2 | 3 |
| FAN_PWM1 | 4 |

2.3.5 System fan connector (CHA_FAN 1)





| Signal | PIN |
|------------|-----|
| GND | 1 |
| +12V | 2 |
| FAN_SPEED2 | 3 |
| FAN_PWM2 | 4 |

2.3.6 System fan connector (CHA_FAN 2)




| Signal | PIN |
|------------|-----|
| FAN_PWM3 | 4 |
| FAN_SPEED3 | 3 |
| +12V | 2 |
| GND | 1 |

2.3.7 System Panel (F_PANEL)





| Signal | PIN | PIN | Signal |
|----------|-----|-----|----------|
| HHD LED+ | 1 | 2 | +5VSB |
| HDD LED# | 3 | 4 | PWR LED# |
| GND | 5 | 6 | PANSWIN# |
| RST | 7 | 8 | GND |
| NC | 9 | | |

2.3.8 ATX Power connector (ATXPWR1)





| Signal | PIN | PIN | Signal |
|----------|-----|-----|--------|
| +3V | 1 | 13 | +3V |
| +3V | 2 | 14 | -12V |
| GND | 3 | 15 | GND |
| +5V | 4 | 16 | PS_ON |
| GND | 5 | 17 | GND |
| +5V | 6 | 18 | GND |
| GND | 7 | 19 | GND |
| PWRER OK | 8 | 20 | NC |
| +5VSB | 9 | 21 | +5V |
| +12V | 10 | 22 | +5V |
| +12V | 11 | 23 | +5V |
| +3V | 12 | 24 | GND |

2.3.9 ATX Power connector (ATXPWR1)





| Signal | PIN | PIN | Signal |
|--------|-----|-----|--------|
| GND | 4 | 8 | +12V |
| GND | 3 | 7 | +12V |
| GND | 2 | 6 | +12V |
| GND | 1 | 5 | +12V |

2.3.10 Serial Port connectors (COM1~6)




| Signal | PIN | PIN | Signal |
|--------|-----|-----|---------------|
| | | 9 | R13xPOWERxJMP |
| CTS# | 8 | 7 | RTS# |
| DSR# | 6 | 5 | GND |
| DTR# | 4 | 3 | TX |
| RX | 2 | 1 | DCD# |

2.3.11 Serial ATA Connector (SATA2, SATA4)



| PIN | Signal |
|-----|--------|
| 1 | GND |
| 2 | TX+ |
| 3 | TX- |
| 4 | GND |
| 5 | RX- |
| 6 | RX+ |
| 7 | GND |


2.3.12 Serial ATA Connector (SATA1, SATA3)



| PIN | Signal |
|-----|--------|
| 7 | GND |
| 6 | RX+ |
| 5 | RX- |
| 4 | GND |
| 3 | TX- |
| 2 | TX+ |
| 1 | GND |


BC680R User's Manual

2.3.13 USB connectors (USB2_HR1, USB2_HR2, USB2_HR3, USB2_HR4)





| Signal | PIN | PIN | Signal |
|--------|-----|-----|--------|
| USB+5V | 1 | 2 | USB+5V |
| USB - | 3 | 4 | USB - |
| USB + | 5 | 6 | USB + |
| GND | 7 | 8 | GND |
| | | 9 | NC |

2.3.14 USB3.2 connector (USB89)





| Signal | PIN | PIN | Signal |
|----------|-----|-----|----------|
| NC | 10 | 11 | USB+ |
| USB+ | 9 | 12 | USB- |
| USB- | 8 | 13 | GND |
| GND | 7 | 14 | USB3_TX+ |
| USB3_TX+ | 6 | 15 | USB3_TX- |
| USB3_TX- | 5 | 16 | GND |
| GND | 4 | 17 | USB3_RX+ |
| USB3 RX+ | 3 | 18 | USB3_RX- |
| USB3 RX- | 2 | 19 | +5V |
| +5V | 1 | | |

2.3.15 8 bit GPIO header (JDIO1)



| Signal | PIN | PIN | Signal |
|-----------------|-----|-----|----------------|
| SIO_GPIO4 | 2 | 1 | SIO_GPIO0 |
| SIO_GPIO5 | 4 | 3 | SIO_GPIO1 |
| SIO_GPIO6 | 6 | 5 | SIO_GPIO2 |
| SIO_GPIO7 | 8 | 7 | SIO_GPIO3 |
| SMB_DATA_RESUME | 10 | 9 | SMB_CLK_RESUME |
| +5Vsb | 12 | 11 | GND |



2.3.16 Front Audio connector (FP_AUDIO1)



| Signal | PIN | PIN | Signal |
|----------|-----|-----|--------|
| LINE2-JD | 10 | 9 | LINE2L |
| | | 7 | SENSEB |
| MIC2-JD | 6 | 5 | LINE2R |
| +3.3V | 4 | 3 | MIC2R |
| GND | 2 | 1 | MIC2L |


BC680R User's Manual

2.3.17 Amplifier connector (JAMP1)





| PIN | Signal |
|-----|--------|
| 1 | AMP_L- |
| 2 | AMP_L+ |
| 3 | AMP_R- |
| 4 | AMP_R+ |

2.3.18 SM bus connector (SMB1)




| PIN | Signal |
|-----|----------|
| 1 | SMB_CLK |
| 2 | SMB_DATA |
| 3 | SMB_ALT |
| 4 | GND |
| 5 | +3.3V |

2.3.19 LAN LED status connector (LAN_LED1)



| Signal | PIN | PIN | Signal |
|----------|-----|-----|----------|
| +3V_Dual | 1 | 2 | +3V_Dual |
| LAN1_LED | 3 | 4 | GND |
| +3V_Dual | 5 | 6 | +3V_Dual |
| GND | 7 | 8 | GND |
| +3V_Dual | 9 | 10 | +3V_Dual |

2.3.20 Chassis intrusion connector (JCASE1)



| PIN | Signal |
|-----|---------------|
| 1 | SIO_CASEOPEN# |
| 2 | GND |


3. BIOS Setup

3.1 BIOS setup

Once you enter the Aptio Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

3.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.



3.6.1.1 System Date

Use the system date option to set the system date. Manually enter the day, month and year.

3.6.1.2 System Time

Use the system time option to set the system time. Manually enter the hours, minutes and seconds.




Note: The BIOS setup screens shown in this chapter are for reference purposes only, and may not exactly match what you see on your screen.


Visit the Avalue website (www.avalue.com.tw) to download the latest product and BIOS information.

3.6.2 Advanced Menu

This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.




3.6.2.1 CPU Configuration



| Item | Options | Description |
|--|---|--|
| Intel (VMX) Virtualization Technology | Disabled Enabled[Default], | When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology. |
| Active Performance-cores | All[Default], /7/6/5/4/3/2/1 | Number of P-cores to enable in each processor package. Note: Number of Cores and E-cores are looked at together. When both are {0,0}, Pcode will enable all cores. |
| Active Efficient-cores | All[Default], 15/14/13/12/11/10 /9/8/7/6/5/4/3/2/1/0 | Number of E-cores to enable in each processor package. Note: Number of Cores and E-cores are looked at together. When both are {0,0}, Pcode will enable all cores. |
| Hyper-Threading | Disabled Enabled[Default], | Enable or Disable Hyper-Threading Technology. |
| Intel Trusted Execution Technology | Disabled[Default], Enabled | Enabled utilization of additional hardware capabilities provided by Intel (R)Trusted Execution Technology. Changes require a full power cycle to take effect. |

3.6.2.2 CPU - Power Management Control




| Item | Options | Description |
|-------------------------------|--|--|
| Intel(R) SpeedStep(tm) | Disabled Enabled[Default], | Allows more than two frequency ranges to be supported. |

BC680R User's Manual

| | | |
|------------------------------|--|---|
| Turbo Mode | Disabled Enabled[Default], | Enable/Disable processor Turbo Mode (requires EMTTM enabled too). AUTO means enabled. |
| C states | Disabled Enabled[Default], | Enable/Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized. |
| Enhanced C-states | Disabled Enabled[Default], | Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-state. |
| Package C State Limit | C0/C1 C2 C3[Default], C6 C7 C8 C9 C10 Cpu Default | Maximum Package C State Limit Setting. Cpu Default: Leaves to Factory default value Auto: Initializes to deepest available Package C State Limit. |

3.6.2.3 PCH-FW Configuration




| Item | Options | Description |
|--------------------------|--|--|
| ME State | Disabled Enabled[Default], | When Disabled ME will be put into ME Temporarily Disabled Mode. |
| ME UnLock Control | Lock[Default], Unlock | ME UnLock control function. Set UnLock will system shutdown for active function. |

3.6.2.4 Thunderbolt(TM) Configuration



| Item | Option | Description |
|---|--|---|
| Discrete Thunderbolt(TM) Support | Disabled [Default] , Enabled | Enabled or Disabled Discrete Thunderbolt(TM) Support. |

3.6.2.5 Trusted Computing



BC680R User's Manual

| Item | Options | Description |
|--------------------------------|-------------------------------|---|
| TPM Device Selection | dTPM[Default], PTT | Selects TPM device: PTT or dTPM. PTT - Enables PTT in SkuMgr dTPM 1.2 - Disables PTT in SkuMgr Warning ! PTT/dTPM will be disabled and all data saved on it will be lost. |
| Security Device Support | Disabled[Default], Enabled | Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not available. |


3.6.2.6 ACPI Settings



| Item | Options | Description |
|---------------------------|---|--|
| Enable Hibernation | Disabled Enabled[Default], | Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may not be effective with some operating systems. |
| ACPI Sleep State | Suspend Disabled, S3 (Suspend to RAM)[Default] | Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed. |
| S3 Video Repost | Disabled[Default], Enabled | Enable or disable S3 video repost |
| PCIE# Wake from S5 | Disabled[Default], Enabled | Enable or disable PCIE to wake the system from S5. |
| Wake on Ring | Disabled[Default], Enabled | Enables/Disables wake on ring function under ACPI S3/S4/S5. |

3.6.2.7 NCT6126D Super IO Configuration



You can use this item to set up or change the Super IO configuration for serial ports. Please refer to 3.6.2.5.1~ 3.6.2.5.6 for more information.



| Item | Options | Description |
|------------------------------------|---|--|
| WatchDog Count Mode | Second[Default], Minute | Configure watchdog count mode. |
| WatchDog Timeout Value | 0 | Configure watchdog Timeout Value. |
| Chassis Opened Warning | Disabled[Default], Enabled | Select whether to enable Chassis Intrusion Detection. Chassis Intrusion Detection is a utility that can tell whether someone has opened the case (intruded into the chassis). NOTE-If chassis tamper occurs, you can only enter setup to clear this error. |
| ErP/EuP S5 Support | Disabled[Default], Enabled | Enable/Disable ErP/EuP S5 Support NOTE:When MEBx is enable Activate Network Access, this function can not set enable that will cause ME fail on next boot. |
| Serial Port 1 Configuration | Set Parameters of Serial Port 1 (COMA). | |
| Serial Port 2 Configuration | Set Parameters of Serial Port 2 (COMB). | |
| Serial Port 3 Configuration | Set Parameters of Serial Port 3 (COMC). | |
| Serial Port 4 Configuration | Set Parameters of Serial Port 4 (COMD). | |
| Serial Port 5 Configuration | Set Parameters of Serial Port 5 (COME). | |
| Serial Port 6 Configuration | Set Parameters of Serial Port 6 (COMF). | |


BC680R User's Manual

3.6.2.7.1 Serial Port 1 Configuration



| Item | Option | Description |
|-----------------|--|--|
| Serial Port | Disabled Enabled[Default], | Enable or Disable Serial Port (COM) |
| Change Settings | Auto[Default], IO=3F8h; IRQ4; IO=3F8h; IRQ3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ3,4,5,6,7,9,10,11,12; IO=3E8h; IRQ3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ3,4,5,6,7,9,10,11,12; | Select an optimal settings for Super IO Device |



3.6.2.7.2 Serial Port 2 Configuration



| Item | Option | Description |
|------------------------|--|--|
| Serial Port | Disabled Enabled [Default] , | Enable or Disable Serial Port (COM) |
| Change Settings | Auto[Default] , IO=2F8h; IRQ3; IO=3F8h; IRQ3,4,5,6,7,9,10,11,12; IO=2F8h; IRQ3,4,5,6,7,9,10,11,12; IO=3E8h; IRQ3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ3,4,5,6,7,9,10,11,12; | Select an optimal settings for Super IO Device |

BC680R User's Manual


3.6.2.7.3 Serial Port 3 Configuration



| Item | Option | Description |
|-----------------|--|--|
| Serial Port | Disabled Enabled[Default], | Enable or Disable Serial Port (COM) |
| Change Settings | Auto[Default], IO=3E8h; IRQ5; IO=3E8h; IRQ3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ3,4,5,6,7,9,10,11,12; IO=220h; IRQ3,4,5,6,7,9,10,11,12; IO=228h; IRQ3,4,5,6,7,9,10,11,12; | Select an optimal settings for Super IO Device |


| | | |
|-------------------------------|--|------------------------------------|
| <p>COM Mode Select</p> | <p>RS232[Default], RS485 Half Duplex RS422 Full Duplex</p> | <p>Configure the COM port Mode</p> |
|-------------------------------|--|------------------------------------|

3.6.2.7.4 Serial Port 4 Configuration




| Item | Option | Description |
|-------------------------------|---|---|
| <p>Serial Port</p> | <p>Disabled Enabled[Default],</p> | <p>Enable or Disable Serial Port (COM)</p> |
| <p>Change Settings</p> | <p>Auto[Default], IO=2E8h; IRQ10; IO=3E8h; IRQ3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ3,4,5,6,7,9,10,11,12; IO=220h; IRQ3,4,5,6,7,9,10,11,12; IO=228h; IRQ3,4,5,6,7,9,10,11,12;</p> | <p>Select an optimal settings for Super IO Device</p> |

3.6.2.7.5 Serial Port 5 Configuration




| Item | Option | Description |
|-----------------|--|--|
| Serial Port | Disabled Enabled[Default], | Enable or Disable Serial Port (COM) |
| Change Settings | Auto[Default], IO=228h; IRQ=15; IO=3E8h; IRQ3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ3,4,5,6,7,9,10,11,12; IO=220h; IRQ3,4,5,6,7,9,10,11,12; IO=228h; IRQ3,4,5,6,7,9,10,11,12; | Select an optimal settings for Super IO Device |

3.6.2.7.6 Serial Port 6 Configuration




| Item | Option | Description |
|------------------------|---|--|
| Serial Port | Disabled Enabled[Default], | Enable or Disable Serial Port (COM). |
| Change Settings | Auto[Default], IO=220h; IRQ=6; IO=3E8h; IRQ3,4,5,6,7,9,10,11,12; IO=2E8h; IRQ3,4,5,6,7,9,10,11,12; IO=220h; IRQ3,4,5,6,7,9,10,11,12; IO=228h; IRQ3,4,5,6,7,9,10,11,12; | Select an optimal settings for Super IO Device |

3.6.2.8 Hardware Monitor





3.6.2.8.1 Hardware Monitor




| Item | Options | Description |
|--------------------|---|------------------------------------|
| Smart Fan Function | Disabled Enabled[Default], Manual | Smart fan function Enable/Disabled |

3.6.2.8.2 Smart Fan Function



BC680R User's Manual



| Item | Options | Description |
|----------------------------------|--|--------------------------------------|
| CPU_FAN1 Smart Fan Target | Disabled 40C 45C 50C 55C[Default], 60C 65C 70C | CPU Smart FAN Target Temperature |
| CPU_FAN1 MIN.FAN Speed(%) | 12.5% [Default], 25% 37.5% 50% 62.5% 75% 87.5% | CPU Smart FAN minimum settings |
| CHA_FAN1 Smart Fan Target | Disabled 40C 45C 50C 55C[Default], 60C 65C 70C | Chassis Smart FAN Target Temperature |


| | | |
|---|--|---|
| <p>CHA_FAN1 MIN.FAN Speed(%)</p> | <p>12.5%[Default], 25% 37.5% 50% 62.5% 75% 87.5%</p> | <p>Chassis Smart FAN minimum settings</p> |
| <p>CHA_FAN2 Smart Fan Target</p> | <p>Disabled 40C 45C 50C 55C[Default], 60C 65C 70C</p> | <p>Chassis Smart FAN Target Temperature</p> |
| <p>CHA_FAN2 MIN.FAN Speed(%)</p> | <p>12.5%[Default], 25% 37.5% 50% 62.5% 75% 87.5%</p> | <p>Chassis Smart FAN minimum settings</p> |

3.6.2.9 S5 RTC Wake Settings




| Item | Options | Description |
|-----------------------------------|--|--|
| <p>Wake system from S5</p> | <p>Disabled[Default], Fixed Time Dynamic Time</p> | <p>Enable or disable System wake on alarm event. Select FixedTime, system will wake on the hr::min::sec specified. Select Dynamic Time, System will wake on the current time + Increase minute(s).</p> |

3.6.2.10 Serial Port Console Redirection




| Item | Options | Description |
|---------------------|-------------------------------|--|
| Console Redirection | Disabled Enabled[Default], | Console Redirection Enabled or Disabled. |

3.6.2.10.1 Console Redirection Settings




| Item | Options | Description |
|----------------------------------|---|---|
| Terminal Type | VT100 VT100Plus VT-UTF8 ANSI[Default], | Emulation: ANSI: Extended ASCII char set VT100: ASCII char set VT100Plus: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes. |
| Bits per second | 9600 19200 38400 57600 115200[Default], | Select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds. |
| Data Bits | 7 8[Default], | Data Bits |
| Parity | None[Default], Even Odd Mark Space | A parity bit can be sent with the data bits to detect some transmission errors. Even: parity bit is 0 if the num of 1's in the data bits is even. Odd: parity bit is 0 if num of 1's in the data bits is odd. Mark parity bit is always 1. Space: Parity bit is always 0. Mark and Space Parity do not allow for error detection. |
| Stop Bits | 1[Default], 2 | Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit |
| Flow Control | None[Default], Hardware RTS/CTS | Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals. |
| VT-UTF8 Combo Key Support | Disabled Enabled[Default], | Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals |
| Recorder Mode | Disabled Enabled[Default], | With this mode enabled only text will be sent. This is to capture Terminal data. |
| Resolution 100x31 | Disabled Enabled[Default], | Enables or disables extended terminal resolution |
| Putty KeyPad | VT100[Default], LINUX XTERMR6 SCO ESCN VT400 | Select FunctionKey and KeyPad on Putty. |


3.6.2.11 Intel TXT Information



3.6.2.12 USB Configuration


The USB Configuration menu helps read USB information and configures USB settings.





| Item | Options | Description |
|--|--|---|
| USB Mass Storage Driver Support | Disabled Enabled[Default], | Enable/Disable USB Mass Storage Driver Support. |
| Mass Storage Devices | Auto[Default] Floppy Forced FDD Hard Disk CD-ROM | Mass storage device emulation type. 'AUTO' enumerates devices according to their media format. Optical drives are emulated as 'CDROM', drives with no media will be emulated according to a drive type. |


3.6.2.13 Network Stack Configuration



BC680R User's Manual


| Item | Options | Description |
|--------------------|-------------------------------|--|
| Network stack | Disabled Enabled[Default], | Enable/Disable UEFI Network stack. |
| Ipv4 PXE Support | Disabled[Default], Enabled | Enable/Disable Ipv4 PXE Boot Support. If disabled, IPV4 PXE boot support will not be available. |
| Ipv6 PXE Support | Disabled[Default], Enabled | Enable/Disable Ipv6 PXE Boot Support. If disabled, IPV6 PXE boot support will not be available. |
| PXE boot wait time | 0 | Wait time in seconds to press ESC key to abort the PXE boot. Use either +/- or numeric keys set the value. |
| Media detect count | 1 | Number of time the presence of media will be checked. Use either +/- or numeric keys set the value. |

3.6.2.14 IP Configuration




| Item | Options | Description |
|--------------------|---|------------------------------------|
| Auto Configuration | Disabled[Default], Every Boot On demand | Enable/Disable UEFI Network stack. |

3.6.2.15 NVMe Configuration



3.6.2.16 Remote Server Configuration




| Item | Options | Description |
|-----------------------------------|-----------------------------|---|
| Remote Firmware Management | Disable Enable[Default], | Enable to communicate with management server. If Disabled then communication will not happen with management server |


BC680R User's Manual

| | | |
|------------------------------|---|---|
| Auto Server Searching | Disable Enable[Default], | Enable to Obtain DHCP Server IP automatically. Disable to provide Server IP manually. Need to do Clear Enrollment, if server is changed in DHCP |
| Server Port Number | 8443 | Provide the Management server PORT number |
| Server Address | Management server Address to be used if Auto Server Searching is either disabled or failed. If changed, need to do Clear Enrollment, if already enrolled with previous IP | |
| Clear Enrollment | Clear existing Enrollment information | |

3.6.3 Chipset




3.6.3.1 System Agent (SA) Configuration



| Item | Options | Description |
|------|-------------------------------|-----------------|
| VT-d | Disabled Enabled[Default], | VT-d capability |

3.6.3.1.1 Memory Configuration



BC680R User's Manual

| Item | Options | Description |
|------------------|--|--|
| Max TOLUD | Dynamic[Default], 1 GB 1.25 GB 1.5 GB 1.75 GB 2 GB 2.25 GB 2.5 GB 2.75 GB 3 GB 3.25 GB 3.5 GB | Maximum Value of TOLUD, Dynamic assignment would adjust TOLUD automatically based on largest MMIO length of installed graphic controller |


3.6.3.1.2 Graphics Configuration



| Item | Options | Description |
|--------------------------|--|--|
| Primary Display | Auto[Default], IGFX PEG Slot PCIE HG | Select which of IGFX/PEG/PCIE Graphics device should be Primary Display Or select HG for Hybrid Gfx. |
| Internal Graphics | Auto[Default], Disabled Enabled | Keep IGFX enabled based on the setup options. |
| PSMI SUPPORT | Disabled[Default], Enabled | PSMI Enable/Disable |


| | | |
|----------------------------------|--|---|
| <p>DVMT Pre-Allocated</p> | <p>0M 32M 64M 96M 128M 160M 4M 8M 12M 16M 20M 24M 28M 32M/F7 36M 40M 44M 48M 52M 56M 60M[Default],</p> | <p>Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device.</p> |
|----------------------------------|--|---|

3.6.3.1.3 VMD setup menu




| Item | Options | Description |
|------------------------|-------------------------------|----------------------------------|
| Enabled VMD controller | Disabled[Default], Enabled | Enable/Disable to VMD controller |

3.6.3.1.4 PCI Express Configuration



| Item | Options | Description |
|------------------------------|----------------------------|---|
| Detect Non-Compliance Device | Disabled[Default], Enabled | Detect Non-Compliance PCI Express Device in PEG |

3.6.3.1.4.1 PCI Express Root Port 1




| Item | Options | Description |
|--------------------------------|---|---|
| PCI Express Root Port 1 | Disabled Enabled [Default] , | Control the PCI Express Root Port. |
| ASPM | Disabled [Default] , L0s L1 L0sL1 | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto [Default] , Gen1 Gen2 Gen3 Gen4 Gen5 | Configure PCIe Speed |

3.6.3.1.4.2 PCI Express Root Port 1




| Item | Options | Description |
|--------------------------------|---|---|
| PCI Express Root Port 2 | Disabled Enabled [Default] , | Control the PCI Express Root Port. |
| ASPM | Disabled [Default] , L0s L1 L0sL1 | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto [Default] , Gen1 Gen2 Gen3 Gen4 Gen5 | Configure PCIe Speed |

3.6.3.2 PCH-IO Configuration



| Item | Options | Description |
|---|---|--|
| LAN 1 Controller | Enabled[Default], Disabled | Enable or disable onboard NIC. |
| LAN1 PXE OpROM | Enabled[Default], Disabled | Enable or disable boot option for LAN1 Controller. |
| LAN 2 Controller | Disabled Enabled[Default], | Control the PCI Express Root Port. |
| LAN2 PXE OpROM | Enabled[Default], Disabled | Enable or disable boot option for LAN2 Controller. |
| Restore AC Power Loss | Power ON Power Off Last State[Default], | Specify what state to go to when power is re-applied after a power failure (G3 state). |
| Flash Protection Range Registers (FPRR) | Disabled Enabled[Default], | Enable Flash Protection Range Registers |
| GPIO Group Control | Enabled[Default], Disabled | Configure the digital GPIO pins |
| Amplifier GAIN(db) | 15.3dp[Default], 21.2dp 27.2dp 31.8dp | Select Amplifier value |

3.6.3.2.1 PCH-IO Configuration



3.6.3.2.1.1 PCI Express Root Port 1(x4 Slot 3)



| Item | Options | Description |
|------------------------------------|-------------------------------|------------------------------------|
| PCI Express Root Port 1(x4 Slot 3) | Disabled Enabled[Default], | Control the PCI Express Root Port. |

BC680R User's Manual


| | | |
|-------------------------------------|---|---|
| ASPM 1 | Disabled[Default], L1 Auto | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto[Default], Gen1 Gen2 Gen3 Gen4 | Configure PCIe Speed |
| Detect Non-Compliance Device | Disabled[Default], Enabled | Detect Non-Compliance PCI Express Device. If enable, it will take more at POST time. |

3.6.3.2.1.2 PCI Express Root Port 5(x1 Slot 1)




| Item | Options | Description |
|---|---|---|
| PCI Express Root Port 5(x1 Slot 1) | Disabled Enabled[Default], | Control the PCI Express Root Port. |
| ASPM 5 | Disabled[Default], L1 Auto | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto[Default], Gen1 Gen2 Gen3 Gen4 | Configure PCIe Speed |
| Detect Non-Compliance Device | Disabled[Default], Enabled | Detect Non-Compliance PCI Express Device. If enable, it will take more at POST time. |

3.6.3.2.1.3 PCI Express Root Port 6(x1 Slot 5)




| Item | Options | Description |
|---|---|---|
| PCI Express Root Port 6(x1 Slot 5) | Disabled Enabled [Default] , | Control the PCI Express Root Port. |
| ASPM 6 | Disabled [Default] , L1 Auto | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto [Default] , Gen1 Gen2 Gen3 Gen4 | Configure PCIe Speed |
| Detect Non-Compliance Device | Disabled [Default] , Enabled | Detect Non-Compliance PCI Express Device. If enable, it will take more at POST time. |

3.6.3.2.1.4 PCI Express Root Port 7(x1 Slot 6)




| Item | Options | Description |
|---|---|---|
| PCI Express Root Port 7(x1 Slot 6) | Disabled Enabled [Default] , | Control the PCI Express Root Port. |
| ASPM 7 | Disabled [Default] , L1 Auto | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto [Default] , Gen1 Gen2 Gen3 Gen4 | Configure PCIe Speed |
| Detect Non-Compliance Device | Disabled [Default] , Enabled | Detect Non-Compliance PCI Express Device. If enable, it will take more at POST time. |

3.6.3.2.1.5 PCI Express Root Port 8(x1 Key E)




| Item | Options | Description |
|--|---|---|
| PCI Express Root Port 8(x1 Key E) | Disabled Enabled[Default], | Control the PCI Express Root Port. |
| ASPM 8 | Disabled[Default], L1 Auto | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto[Default], Gen1 Gen2 Gen3 Gen4 | Configure PCIe Speed |
| Detect Non-Compliance Device | Disabled[Default], Enabled | Detect Non-Compliance PCI Express Device. If enable, it will take more at POST time. |

3.6.3.2.1.6 PCI Express Root Port 13(x4 Key M)



| Item | Options | Description |
|---|---|---|
| PCI Express Root Port 13(x4 Key M) | Disabled Enabled [Default] , | Control the PCI Express Root Port. |
| ASPM 13 | Disabled [Default] , L1 Auto | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto [Default] , Gen1 Gen2 Gen3 Gen4 | Configure PCIe Speed |
| Detect Non-Compliance Device | Disabled [Default] , Enabled | Detect Non-Compliance PCI Express Device. If enable, it will take more at POST time. |

3.6.3.2.1.7 PCI Express Root Port 21(x4 Slot 4)




| Item | Options | Description |
|--|---|---|
| PCI Express Root Port 21(x4 Slot 4) | Disabled Enabled[Default], | Control the PCI Express Root Port. |
| ASPM 21 | Disabled[Default], L1 Auto | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto[Default], Gen1 Gen2 Gen3 Gen4 | Configure PCIe Speed |
| Detect Non-Compliance Device | Disabled[Default], Enabled | Detect Non-Compliance PCI Express Device. If enable, it will take more at POST time. |

3.6.3.2.1.8 PCI Express Root Port 25(x4 Slot 7)




| Item | Options | Description |
|--|---|---|
| PCI Express Root Port 25(x4 Slot 7) | Disabled Enabled [Default] , | Control the PCI Express Root Port. |
| ASPM 25 | Disabled [Default] , L1 Auto | Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM |
| PCIe Speed | Auto [Default] , Gen1 Gen2 Gen3 Gen4 | Configure PCIe Speed |
| Detect Non-Compliance Device | Disabled [Default] , Enabled | Detect Non-Compliance PCI Express Device. If enable, it will take more at POST time. |

3.6.3.2.2 SATA Configuration



| Item | Options | Description |
|----------------------------|-------------------------------|--|
| SATA Controller(s) | Enabled[Default], Disabled | Enable/Disable SATA Device. |
| SATA Mode Selection | AHCI | Determines how SATA Controller(s) operate. |
| M2 Port | Disabled Enabled[Default], | Enable or Disable SATA Port |
| Port 1 | Disabled Enabled[Default], | Enable or Disable SATA Port |
| Port 2 | Disabled Enabled[Default], | Enable or Disable SATA Port |
| Port 3 | Disabled Enabled[Default], | Enable or Disable SATA Port |
| Port 4 | Disabled Enabled[Default], | Enable or Disable SATA Port |

3.6.3.2.3 USB Configuration




| Item | Options | Description |
|------------------------------|-------------------------------|----------------------------------|
| USB12 Standby Power | Disabled Enabled[Default], | Enable/Disable USB Standby Power |
| USB34 Standby Power | Disabled Enabled[Default], | Enable/Disable USB Standby Power |
| USB56 Standby Power | Disabled Enabled[Default], | Enable/Disable USB Standby Power |
| USB89 Standby Power | Disabled Enabled[Default], | Enable/Disable USB Standby Power |
| USB1011 Standby Power | Disabled Enabled[Default], | Enable/Disable USB Standby Power |
| USB1213 Standby Power | Disabled Enabled[Default], | Enable/Disable USB Standby Power |
| USB1415 Standby Power | Disabled Enabled[Default], | Enable/Disable USB Standby Power |
| USB1617 Standby Power | Disabled Enabled[Default], | Enable/Disable USB Standby Power |

3.6.3.2.4 HD Audio Configuration



| Item | Options | Description |
|----------|-------------------------------|---|
| HD Audio | Disabled Enabled[Default], | Control Detection of HD-Audio device. Disabled = HDA will be unconditionally disabled Enabled = HDA will be unconditionally enabled |


3.6.3.2.5 Seriallo Configuration



BC680R User's Manual


| Item | Options | Description |
|------------------------|---|--|
| I2C0 Controller | Disabled Enabled[Default], Post Code Only | Enables/Disables Seriallo Controller If given device is Function 0 PSF disabling is skipped. PSF default will remain and device PCI CFG Space will still be visible. This is needed to allow PCI enumerator access functions above 0 in a multifunction device. The following devices depend on each other: 12C0 |

3.6.4 Security



| Item | Description |
|-------------------------------|----------------------------|
| Administrator Password | Set Administrator Password |
| User Password | Set User Password |

3.6.5 Boot




| Item | Options | Description |
|-----------------------------|--|--|
| Setup Prompt Timeout | 1 | Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinit waiting. |
| Bootup NumLock State | On[Default], Off | Select the keyboard NumLock state |
| Quiet Boot | Disabled Enabled[Default], | Enables or disables Quiet Boot option |
| Boot mode select | LEGACY UEFI[Default], | Select boot mode LEGACY/UEFI |
| Boot Option #1 | USB Key, CD/DVD, USB CD/DVD, USB Hard Disk, USB Floppy, NVME, Hard Disk[Default], Network, UEFI AP, Disabled | Sets the system boot order |
| Boot Option #2 | USB Key, CD/DVD[Default], USB CD/DVD, USB Hard Disk, USB Floppy, NVME, Hard Disk, Network, UEFI AP, Disabled | Sets the system boot order |

BC680R User's Manual

| | | |
|------------------------------|--|-----------------------------------|
| <p>Boot Option #3</p> | <p>USB Key, CD/DVD, USB CD/DVD[Default], USB Hard Disk, USB Floppy, NVME, Hard Disk, Network, UEFI AP, Disabled</p> | <p>Sets the system boot order</p> |
| <p>Boot Option #4</p> | <p>USB Key, CD/DVD, USB CD/DVD, USB Hard Disk, USB Floppy[Default], NVME, Hard Disk, Network, UEFI AP, Disabled</p> | <p>Sets the system boot order</p> |
| <p>Boot Option #5</p> | <p>USB Key, CD/DVD, USB CD/DVD, USB Hard Disk, USB Floppy, NVME[Default], Hard Disk, Network, UEFI AP, Disabled</p> | <p>Sets the system boot order</p> |
| <p>Boot Option #6</p> | <p>USB Key[Default], CD/DVD, USB CD/DVD, USB Hard Disk, USB Floppy, NVME, Hard Disk, Network, UEFI AP, Disabled</p> | <p>Sets the system boot order</p> |
| <p>Boot Option #7</p> | <p>USB Key, CD/DVD, USB CD/DVD, USB Hard Disk, USB Floppy, NVME, Hard Disk, Network[Default], UEFI AP, Disabled</p> | <p>Sets the system boot order</p> |
| <p>Boot Option #8</p> | <p>USB Key, CD/DVD, USB CD/DVD, USB Hard Disk, USB Floppy, NVME, Hard Disk, Network, UEFI AP[Default], Disabled</p> | <p>Sets the system boot order</p> |

3.6.6 Save & Exit



3.6.6.1 Save Changes and Exit

Exit system setup after saving the changes.

3.6.6.2 Discard Changes and Exit

Exit system setup without saving the changes.

3.6.6.3 Save Changes and Reset

Reset the system after saving the changes.

3.6.6.4 Restore Defaults

Restore/Load default values for all the setup option.

3.6.6.5 Launch EFI Shell from filesystem device

Attempts to launch EFI shell application from one of the available filesystem devices.

3.6.6.6 AMIFWUpdate

Launches AMIFWUpdate.

4. Drivers Installation



Note: Installation procedures and screen shots in this section are for your reference and may not be exactly the same as shown on your screen.

4.1 Install Chipset Driver

All drivers can be found on the Avalue Official Website:


<http://www.avalue.com.tw>.



Note: The installation procedures and screen shots in this section are based on Windows 10 operation system. If the warning message appears while the installation process, click Continue to go on.



Step 1. Click Next.



Step 3. Click Install.



Step 2. Click Accept.




Step 4. Complete setup.

4.2 Install VGA Driver


All drivers can be found on the Avalue Official Website:
<http://www.avalue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system.




Step 1. Click **Begin installation**.



Step 3. Click **Start**.



Step 2. Click **I agree**.



Step 4. Click **Finish** to complete setup.


4.3 Install ME Driver

All drivers can be found on the Avalue Official Website:


<http://www.avalue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system.




Step 1. Click **Next** to continue setup.



Step 2. Click **Next**.



Step 3. Click **Next**



Step 4. Click **Finish** to complete the setup


4.4 Install Audio Driver (For Realtek ALC888S HD Audio)

All drivers can be found on the Avalue Official Website:


<http://www.avalue.com.tw>.



Note: The installation procedures and screen shots in this section are based on Windows 10 operation system.



Step 1. Click **Next** to Install.



Step 2. Select **Finish** to complete Installation.


4.5 Install LAN Driver

All drivers can be found on the Avalue Official Website:


<http://www.avalue.com.tw>.



Note: The installation procedures and screen shots in this section are based on Windows 10 operation system.



Step 1. Click InstallPackage.




Step 2.

4.6 Install Serial IO Driver

All drivers can be found on the Avalue Official Website:
<http://www.avalue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system.



Step 3. Click Next.



Step 1. Click Next to continue installation.



Step 4. Click Next.



Step 2. Click Next.



Step 5. Click Finish to complete setup.


4.7 Install Intel_DTT

All drivers can be found on the Avalue Official Website:


<http://www.avalue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system.



Step 1. Click **Next** to continue installation.



Step 3. Click **Next**.



Step 2. Click **Next**.



Step 4. Click **Finish** to complete setup.


4.8 Install GNA

All drivers can be found on the Avalue Official Website:


<http://www.avalue.com.tw>.




Note: The installation procedures and screen shots in this section are based on Windows 10 operation system.



Step 2. Click **Next** to continue installation.




Step 1. Click **Browse my computer for drivers**.



Step 3. Click **Finish** to complete setup.

5. Mechanical Drawing





Unit: mm

