

PICO-N150A

Pico-ITX Boards

Copyright Notice

This document is copyrighted, 2026. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, GIGAIPC assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

GIGAIPC reserves the right to make changes in the product design without notice to its users.

Acknowledgement

All other products' name or trademarks are properties of their respective owners.

- Microsoft Windows is a registered trademark of Microsoft Corp.
- Intel, Pentium, Celeron, and Xeon are registered trademarks of Intel Corporation
- Core, Atom are trademarks of Intel Corporation
- ITE is a trademark of Integrated Technology Express, Inc.
- IBM, PC/AT, PS/2, and VGA are trademarks of International Business Machines Corporation.
- Arm® and Cortex® are registered trademarks of Arm Limited (or its subsidiaries)
- Android™ is a trademark of Google LLC.

All other product names or trademarks are properties of their respective owners.

Packing List

Before setting up your product, please make sure the following items have been shipped:

Item	Quantity
PICO-N150A MB	1

If any of these items are missing or damaged, please contact your distributor or sales representative immediately.

About this Document

This User's Manual contains all the essential information, such as detailed descriptions and explanations on the product's hardware and software features (if any), its specifications, dimensions, jumper/connector settings/definitions, and driver installation instructions (if any), to facilitate users in setting up their product.

Users may refer to the GIGAIPC.com for the latest version of this document.

Safety Precautions

Please read the following safety instructions carefully. It is advised that you keep this manual for future references

1. All cautions and warnings on the device should be noted.
2. Make sure the power source matches the power rating of the device.
3. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
4. Always completely disconnect the power before working on the system's hardware.
5. No connections should be made when the system is powered as a sudden rush of power may damage sensitive electronic components.
6. If the device is not to be used for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
7. Always disconnect this device from any AC supply before cleaning.
8. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent falls
12. Do not cover the openings on the device to ensure optimal heat dissipation.

13. Watch out for high temperatures when the system is running.
14. Do not touch the heat sink or heat spreader when the system is running
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself to prevent static charge when installing the internal components. Use a grounding wrist strap and contain all electronic components in any static-shielded containers.
17. If any of the following situations arises, please the contact our service personnel:
 - i. Damaged power cord or plug
 - ii. Liquid intrusion to the device
 - iii. Exposure to moisture
 - iv. Device is not working as expected or in a manner as described in this manual
 - v. The device is dropped or damaged
 - vi. Any obvious signs of damage displayed on the device
18. **DO NOT LEAVE THIS DEVICE IN AN UNCONTROLLED ENVIRONMENT WITH TEMPERATURES BEYOND THE DEVICE'S PERMITTED STORAGE TEMPERATURES (SEE CHAPTER 1) TO PREVENT DAMAGE.**

FCC Statement

Warning!



This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Caution:

There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

Attention:

Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.

China RoHS Requirements (CN)

产品中有毒有害物质或元素名称及含量
GIGAIPC Main Board/ Daughter Board/ Backplane

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电 子组件	○	○	○	○	○	○
外部信号 连接器 及线材	○	○	○	○	○	○
○: 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。 X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。 备注: 此产品所标示之环保使用期限, 系指在一般正常使用状况下。						

China RoHS Requirement (EN)

Poisonous or Hazardous Substances or Elements in Products
GIGAIPC Main Board/ Daughter Board/ Backplane

Component	Poisonous or Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCB & Other Components	O	O	O	O	O	O
Wires & Connectors for External Connections	O	O	O	O	O	O
O : The quantity of poisonous or hazardous substances or elements found in each of the component's parts is below the SJ/T 11363-2006-stipulated requirement. X: The quantity of poisonous or hazardous substances or elements found in at least one of the component's parts is beyond the SJ/T 11363-2006-stipulated requirement. Note: The Environment Friendly Use Period as labeled on this product is applicable under normal usage only						

Table Contents

Pico-ITX Boards	1
Copyright Notice	2
Acknowledgement	3
Packing List	4
About this Document	5
Safety Precautions	6
FCC Statement.....	8
China RoHS Requirements (CN).....	9
China RoHS Requirement (EN)	10
 Chapter 1 - Product Specifications	 14
1.1 Specifications	16
 Chapter 2 – Hardware Information	 17
2.1 Jumpers and Connectors	18
2.2.1 USB32 (USB 3.2 Gen 2x1 connector)	20
2.2.2 LAN1, LAN2 (LAN connector)	21
2.2.3 HDMI (HDMI connector)	22
2.2.4 DC_IN (DC IN 1x4pin power connector).....	23
2.2.5 BATTERY (Battery cable Connector)	24
2.2.6 GPIO (General Purpose input/output header).....	25
2.2.7 SYS_PANEL (Front panel header)	26
2.2.8 COM (Serial port header (RS-232/422/485)).....	27
2.2.9 M2E (M.2 Slot, 2230 E-key).....	28
2.2.10 FUSB20 (USB 2.0 headers).....	29

2.2.11	LVDS (LVDS connector).....	30
2.2.12	BKL_CN (Backlight Control connector)	31
2.2.13	M2M (M.2 Slot, 2280 M-key).....	32
2.2.14	SODIMM (DDR5 SO-DIMM slot)	33


Chapter 3 – BIOS 34

3.1	Introduction	35
3.2	The Main Menu.....	36
3.3	Advanced	37
3.3.1	TPM Configuration.....	38
3.3.2	CPU Configuration	40
3.3.3	Memory Configuration	41
3.3.4	IT8613 Super IO Configuration	42
3.3.5	Hardware Monitor	43
3.3.6	S5 RTC Wake Settings	44
3.3.7	Network Stack Configuration-1.....	45
3.3.7	Network Stack Configuration-2	46
3.3.8	NVMe Configuration.....	47
3.3.9	Digital IO Port Configuration	48
3.3.10	Tls Auth Configuration	49
3.3.11	Realtek PCIe GBE Family Controller (MAC:30:56:0F:47: D5:2A)(MAC address may varied based on different motherboard).....	50
3.3.12	Realtek PCIe GBE Family Controller (MAC:30:56:0F:47: D5:2B)(MAC address may varied based on different motherboard).....	51

3.4	Chipset	52
3.5	Security	53
3.6	Boot.....	56
3.7	Save & Exit	57

Chapter 1

Chapter 1 - Product Specifications




1.1 Specifications

Motherboard	PICO-N150A
Form Factor	PICO-ITX 100W x 72Dmm
CPU	Intel® Processor N150 Intel 7, 4 cores, up to 3.60 GHz TDP 6W
Socket	1 x FCBGA1264
Memory	1 x DDR5 SO-DIMM socket, Max. Capacity 16 GB Support Single Channel DDR5 4800 MHz memory modules
Ethernet	2 x GbE LAN Ports (Realtek® RTL8111H)
Video	Integrated Graphics Processor - Intel® Graphics support: 1 x HDMI 2.0 port, supporting a maximum resolution of 4096x2160 @60Hz 1 x LVDS port, supporting a maximum resolution of 1920x1200 @60Hz (2 independent display outputs)
Expansion Slots	1 x 2280 M.2 M-Key (PCIe Gen 3x2) 1 x 2230 M.2 E-Key (PCIe x1, USB 2.0)
Internal I/O	1 x 4-pin box power connector (+12VDC) 1 x Front panel header 1 x COM header (RS-232/422/485) 2 x USB 2.0 headers 1 x GPIO (4-bits) header 1 x Backlight Control header
Rear I/O	2 x USB 3.2 Gen 2x1 2 x RJ45 LAN Ports 1 x HDMI
TPM	Onboard TPM 2.0 security chip INFINEON SLB9670VQ2.0
OS Compatibility	Windows 11 IoT Enterprise LTSC 2024(24H2) (x64)
Operating Properties	Operating temperature: 0°C to 60°C Operating humidity: 60°C @ 20-95% (non-condensing) Non-operating temperature: -40°C to 85°C Non-operating humidity: 85°C @ 95% (non-condensing)

Chapter 2

Chapter 2 – Hardware Information


2.1 Jumpers and Connectors




No	Code	Description
1	USB32	USB 3.2 Gen 2x1 connector
2	LAN1, LAN2	LAN connector
3	HDMI	HDMI connector
4	DC_IN	DC IN 1x4 pin power connector
5	BATTERY	Battery cable connector
6	GPIO	General purpose input / output header
7	SYS_PANEL	Front panel header
8	COM	Serial port header (RS-232/422/485)
9	M2E	M.2 Slot, 2230 E-key
10	FUSB20	USB 2.0 headers
11	LVDS	LVDS Connector
12	BKL_CN	Backlight Control header
13	M2M	M.2 Slot, 2280 M-key
14	SODIMM	DDR5 SO-DIMM Slot

2.2.1 USB32 (USB 3.2 Gen 2x1 connector)

1




USB 3.2 Gen 2x1 Connector




Connector PN	Vendor
18-A5950-6A33-A	TCONN

2.2.2 LAN1, LAN2 (LAN connector)



LAN Connector




Pin No.	Definition
1	TX1+
2	TX1-
3	TX2+
4	TX2-
5	TX3+
6	TX3-
7	TX4+
8	TX4-


State	Description
Orange On	1Gbps data rate
Green On	100Mbps data rate
Off	10Mbps data rate

Connector PN	Vendor
RB1-GB-0008	UDE

2.2.3 HDMI (HDMI connector)

3




HDMI Connector	
	


Connector PN	Vendor
D13-0715-19681	WALTA

Pin No.	Definition	Pin No.	Definition
1	HDMI_D2p	11	GND
2	GND	12	HDMI_CLKn
3	HDMI_D2n	13	CEC
4	HDMI_D1p	14	NC
5	GND	15	HDMI_SCL
6	HDMI_D1n	16	HDMI_SDA
7	HDMI_D0p	17	GND
8	GND	18	5V
9	HDMI_D0n	19	HDMI_HPD
10	HDMI_CLKp		

2.2.4 DC_IN (DC IN 1x4pin power connector)

4




DC IN connector	
	
1 2 3 4	
Pin No.	Definition
1	GND
2	Power
3	Power
4	GND

Connector PN	Vendor
753-81-04TW00	PINREX
Connector type	
1x4pin header, pitch 2.5mm	

2.2.5 BATTERY (Battery cable Connector)

5



Battery cable Connector




Pin No.	Definition
1	3V
2	GND

Connector PN	Vendor
85205-0270L	ACES
A1250WV-S-02PC	JOINT-TECH

Connector type
1x2pin header, pitch 1.25mm

2.2.6 GPIO (General Purpose input/output header)

6





Pin No.	Definition
1	SOGPO_1
2	SOGPI_1
3	SOGPO_2
4	SOGPI_2
5	SMB_CLK
6	SMB_DATA
7	5V
8	GND

Connector PN	Vendor
222-97-04GBE1	PINREX
Connector type	
2x4pin header, pitch 2.0mm	

2.2.7 SYS_PANEL (Front panel header)

7




Pin No.	Definition
1	HD+
2	MPD+
3	HD-
4	MPD-
5	GND
6	PWR_button
7	Reset
8	GND
9	GND
10	GND


Connector PN	Vendor
50238-01041-001	ACES
Connector type	
2x5pin header, pitch 1.0mm	

2.2.8 COM (Serial port header (RS-232/422/485))

8



Serial port Connector




Pin No.	RS-232	RS-422 Full Duplex	RS-485 Half Duplex
1	RXD	TXD+	D+
2	DCD	TXD-	D-
3	DTR	RXD-	—
4	TXD	RXD+	—
5	DSR	—	—
6	GND	—	—
7	CTS	—	—
8	RTS	—	—
9	No Connect	—	—
10	RI	—	—

Connector PN	Vendor
87216-1004-06	ACES


Connector type
2x5pin header, pitch 1.0mm

2.2.9 M2E (M.2 Slot, 2230 E-key)

9



M.2 E Key Connector




Pin No.	Definition	Pin No.	Definition
1	GND	2	3.3V
3	D1p	4	3.3V
5	D1n	6	NC
7	GND	8	NC
9	NC	10	NC
11	NC	12	NC
13	GND	14	NC
15	NC	16	NC
17	NC	18	GND
19	GND	20	NC
21	NC	22	NC
23	NC		
Pin No.	Definition	Pin No.	Definition
33	GND	32	NC
35	PCIE_TXp	34	NC
37	PCIE_TXn	36	NC

39	GND	38	NC
41	PCIE_RXp	40	NC
43	PCIE_RXn	42	NC
45	GND	44	NC
47	PCIE_CLOCKp	46	NC
49	PCIE_CLOCKn	48	NC
51	GND	50	NC
53	PCIE Clock Request	52	PCIRST
55	PCIE wake up	54	BT_Disable
57	GND	56	WLAN_DISABLE
59	NC	58	NC
61	NC	60	NC
63	GND	62	NC
65	NC	64	NC
67	NC	66	NC
69	GND	68	NC
71	NC	70	NC
73	NC	72	3.3V
75	GND	74	3.3V

Connector PN	Vendor
80152-8521	BELLWETHER


2.2.10 FUSB20 (USB 2.0 headers)

10



Pin 1

USB 2.0 Header





Pin No.	Definition
1	5V
2	5V
3	5V
4	5V
5	DXn
6	DYn
7	DXp
8	DYp
9	GND
10	GND

Connector PN	Vendor
87216-1004-06	ACES

Connector type
2x5pin header, pitch 1.0mm

2.2.11 LVDS (LVDS connector)

11



Pin No.	Definition	Pin No.	Definition
1	3.3V	21	A5+
2	5V	22	A4+
3	3.3V	23	A5-
4	5V	24	A4-
5	SPC0	25	GND
6	SPD0	26	GND
7	GND	27	A7+
8	GND	28	A6+
9	A1+	29	A7-
10	A0+	30	A6-
11	A1-	31	GND
12	A0-	32	GND
13	GND	33	CLK2+
14	GND	34	CLK1+
15	A3+	35	CLK2-

Pin No.	Definition	Pin No.	Definition
16	A2+	36	CLK1-
17	A3-	37	GND
18	A2-	38	GND
19	GND	39	12V
20	GND	40	12V



Connector PN	Vendor
712-76-40GWE0	PINREX
A1252WV-SF-2X20PD01	JOINT-TECH

Connector type
2x20pin header, pitch 1.25mm

For each model support LVDS function.
But below model no need to add.
A0~A3 is odd channel 0~3, A4~A7 is even channel.
Note: *The LVDS output connector of the unit is only intended to be connected to an UL/IEC/EN approval equipment with fire enclosure.

2.2.12 BKL_CN (Backlight Control connector)

12




Connector PN	Vendor
721-81-05TW00	PINREX

Connector type
1x5pin header, pitch 2.0mm


Pin No.	Definition
1	5V (12V optional)
2	PWM (3.3V)
3	Backlight enable (3.3V)
4	GND
5	12V

2.2.13 M2M (M.2 Slot, 2280 M-key)

13



M.2 M Key Connector



Pin No.	Definition	Pin No.	Definition
1	GND	2	3.3V
3	GND	4	3.3V
5	NC	6	NC
7	NC	8	NC
9	GND	10	SSD LED
11	NC	12	3.3V
13	NC	14	3.3V
15	GND	16	3.3V
17	NC	18	3.3V
19	NC	20	NC
21	GND	22	NC
23	NC	24	NC
25	NC	26	NC
27	GND	28	NC
29	PCIe1 RXn	30	NC
31	PCIe1 RXp	32	NC


Pin No.	Definition	Pin No.	Definition
33	GND	34	NC
35	PCIe1 TXn	36	NC
37	PCIe1 TXp	38	DEVSLP
39	GND	40	NC
41	PCIe0 RXn	42	NC
43	PCIe0 RXp	44	NC
45	GND	46	NC
47	PCIe0 TXn	48	NC
49	PCIe0 TXp	50	PCI Reset
51	GND	52	PCIe Clock Request
53	PCIe Clockn	54	NC
55	PCIe Clockp	56	NC
57	GND	58	NC

Pin No.	Definition	Pin No.	Definition
67	NC	68	NC
69	Detect	70	3.3V
71	GND	72	3.3V
73	GND	74	3.3V
75	GND		

Connector PN	Vendor
80159-8521	BELLWETHER

2.2.14 SODIMM (DDR5 SO-DIMM slot)

14



Chapter 3

Chapter 3 – BIOS

3.1 Introduction

BIOS (Basic input/output system) provides hardware detailed information and boot-up options, which include firmware to control, set-up and test all hardware settings. Therefore, BIOS is the communication bridge between OS/application software and hardware.

3.1.1 How to Entering into BIOS menu


Once the system is power on, press the key as soon as possible to access into BIOS Setup program.

3.1.2 Function Keys to setup in BIOS Setup program

Function keys	Description
→←	Select Screen
↑↓	Select Item
Enter	Execute command or enter the submenu
+	Increase the numeric value or make changes
—	Decrease the numeric value or make changes
F1	General Help
F2	Previous Values
F3	Load Optimized Defaults Settings
F4	Save changes & Exit the BIOS Setup program
ESC	Exit the BIOS Setup program

3.2 The Main Menu


The main menu shows the basic system information.
Use arrow keys to move among the items.



Items	Description
Project Name	Shows Project name information
BIOS Version	Shows the BIOS version of the system
Build Date and Time	Shows the Build Date and Time when the BIOS was created.
LAN1 MAC Address	Shows LAN1 MAC Address information
LAN2 MAC Address	Shows LAN2 MAC Address information
Total Memory	Shows the total memory size of the installed memory
ME FW version	Shows ME firmware version
System Date	Set the Date for the system (Format : Week - Month - Day - Year)
System Time	Set the time for the system (Format : Hour - Minute - Second)

3.3 Advanced

The Advanced menu is to configure the functions of hardware settings through submenu. Use arrow keys to move among the items, and press <Enter> to access into the related submenu.




3.3.1 TPM Configuration

Use TPM Configuration submenu to choose TPM interface.



Item	Description
TPM Device Selection	PTT : Internal TPM dTPM : External TPM (When using External TPM module or having TPM chip on MB)(Default setting)


Trusted Computing : Shows TPM information, and TPM module configuration setting.



Item	Description
Security Device support	Enabled : Enables TPM feature (Default setting) Disabled : Disables TPM feature
Pending operation	None : No execution will be conducted (Default setting) TPM clear : Set to clear data on TPM


3.3.2 CPU Configuration

This submenu shows detailed CPU informations.




Item	Description
Intel (VMX) Virtualization Technology	Virtualization enhanced by Intel® Virtualization Technology will allow a platform to run multiple operating systems and applications in independent partitions. With virtualization, one computer system can function as multiple virtual systems. Enabled : Enables Intel Virtualization Technology (Default setting) Disabled : Disables Intel Virtualization Technology
Intel® Speed Shift Technology	Enabled : Enables Intel® Speed Shift Technology (Default setting) Disabled : Disables Intel® Speed Shift Technology
Intel® Speedstep™	Enabled : Enables Intel® Speedstep™ (Default setting) Disabled : Disables Intel® Speedstep™
Turbo Mode	Enabled : Enables Turbo Mode (Default setting) Disabled : Disables Turbo Mode
C states	Command CPU to enter into low power consumption mode when CPU is under idle mode. Enabled : Enables CPU C states function (Default setting) Disabled : Disables CPU C states function

3.3.3 Memory Configuration




Item	Description
In-Band ECC Support	Enable or Disable In-Band ECC Support function. Disabled : Disables In-Band ECC Support (Default setting) Enabled : Enables In-Band ECC Support

3.3.4 IT8613 Super IO Configuration




Item	Description
Super IO Chip	Shows Super I/O chip model
Serial Port 1 Configuration	Press [Enter] to configure advanced items : Enable or Disable Serial Port Enabled : Enables Serial Port function (Default setting) Disabled : Disables Serial Port function Device settings : Display the specified Serial Port base I/O address and IRQ COM Port Mode : Choose RS-232, RS-422, or RS-485 feature

3.3.5 Hardware Monitor




Item	Description
CPU Temperature	Shows current CPU temperature
System Temperature	Shows current System temperature

3.3.6 S5 RTC Wake Settings




Item	Description
Wake system from S5	Enable or Disable System to wake on a specific time. Disabled : Disables system to wake on a specific time (Default setting) Fixed Time : Enables system to wake on a specific time (Format : hr : min : sec)

3.3.7 Network Stack Configuration-1



Item	Description
Network Stack	When system is power on, install LAN driver under UEFI mode Disabled : Disables UEFI Network Stack (Default setting) Enabled : Enables UEFI Network Stack
IPv4 PXE Support	When Network stack is enabled : Disabled : Disables Ipv4 PXE Support Enabled : Enables Ipv4 PXE Support (Default setting)
IPv6 PXE Support	When Network stack is enabled : Disabled : Disables Ipv6 PXE Support Enabled : Enables Ipv6 PXE Support (Default setting)

3.3.7 Network Stack Configuration-2




Item	Description
Network Stack	When system is power on, install LAN driver under UEFI mode Disabled : Disables UEFI Network Stack (Default setting) Enabled : Enables UEFI Network Stack
IPv4 HTTP Support	When Network stack is enabled : Disabled : Disables Ipv4 HTTP Support Enabled : Enables Ipv4 HTTP Support (Default setting)
IPv6 HTTP Support	When Network stack is enabled : Disabled : Disables Ipv6 HTTP Support Enabled : Enables Ipv6 HTTP Support (Default setting)

3.3.8 NVMe Configuration

NVMe Configuration shows information when your M.2 NVMe PCIe SSD is installed.




3.3.9 Digital IO Port Configuration



Item	Description
OS control Digital IO	Disabled : If Digital IO Output value/level is modified in OS, they will not be memorized and kept. (Default setting) Enabled : If Digital IO Output value/level is modified in OS, they will be memorized and kept.
SOGPO_1 (Pin 1) SOGPI_1 (Pin 2) SOGPO_2 (Pin 3) SOGPI_2 (Pin 4)	Configure Digital IO Input or Output values for each pin.


3.3.10 Tls Auth Configuration



Item	Description
Enroll Cert	Press [Enter] to configure advanced items : Server CA Configuration : Enroll Cert : 1. Enroll Cert Using File 2. Cert GUID : Input digit character in 11111111-2222-3333-4444-1234567 890ab format. 3. Commit Changes and Exit 4. Discard Changes and Exit

3.3.11 Realtek PCIe GBE Family Controller (MAC:30:56:0F:47:D5:2A) (MAC address may varied based on different motherboard)


Shows Realtek Ethernet controller information



NOTE : MAC address may varied based on different motherboard


3.3.12 Realtek PCIe GBE Family Controller (MAC:30:56:0F:47:D5:2B) (MAC address may varied based on different motherboard)

Shows Realtek Ethernet controller information




NOTE : MAC address may varied based on different motherboard

3.4 Chipset



Item	Description
VT-d	Enabled : Enables VT-d function (Default setting) Disabled : Disables VT-d function
DVMT Pre-Allocated	Use DVMT Pre-Allocated to set the amount of system memory which is installed to the integrated graphics processor Option items : 32M , 64M, 128M, 256M (Default setting)
Onboard LAN1 Onboard LAN2	Enable/Disable onboard LAN controller Enabled : Enables onboard LAN controller (Default setting) Disabled : Disables onboard LAN controller
Restore AC Power Loss	To set which option the system should returns if a sudden power loss occurred Power off : Do not power on when the power is back (Default setting) Power on : System power on when the power is back Last state : Restore the system to the state before power loss occurs
LVDS Support	Disabled : Disables LVDS Support (Default setting) Enabled : Enables LVDS Support
Watchdog Timer	Enable/Disable Watchdog Timer function Enabled : Enables Watchdog Timer function Disabled : Disabled Watchdog Timer function (Default setting)
BIOS Lock	Enable/Disable BIOS Lock function Enabled : Enables BIOS Lock function (Default setting) Disabled : Disabled BIOS Lock funtion


3.5 Security



Item	Description
Administrator Password	To set up Administrator's password Minimum length : 3 Maximum length : 20
User Password	To set up User's password Minimum length : 3 Maximum length : 20
Secure Boot	Press <Enter> to configure the advanced items



Item	Description
Secure Boot	Secure Boot requires all the applications that are running during the booting process to be pre-signed with valid digital certificates Enabled : Enables Secure Boot function Disabled : Disables Secure Boot function (Default setting)
Secure Boot Mode	Standard : Standard mode Custom : Custom mode (Default setting)
Restore Factory Keys	To restore factory settings Yes : Agree to restore factory settings No : Cancel to restore factory settings
Reset To Setup Mode	Yes : Agree to setup mode No : Cancel to setup mode
Key Management	Enables expert users to modify Secure boot policy variables without full authentication Press <Enter> to configure the advanced items



Item	Description
Factory Key Provision	Install factory default Secure Boot keys after the platform reset and while the system is in Setup mode Enabled : Enables Factory Key Provision (Default setting) Disabled : Disables Factory Key Provision
Restore Factory Keys	To restore factory settings
Reset To Setup Mode	Delete all Secure boot key databases from NVRAM
Enroll Efi Image	Allow the image to run in Secure Boot mode
Export Secure Boot variables	Copy NVRAM content of Secure Boot variables to files in a root folder on a file system device

Item	Description
Platform Key (PK)	These items allows you to enroll factory defaults or load Certificates from a file.
Key Exchange Keys (KEK)	
Authorized Signatures (db)	
Forbidden Signatures (dbx)	
Authorized TimeStamps (dbt)	
OsRecovery Signatures (dbr)	
MS UEFI CA key	
	Enabled : Enables MS UEFI CA Key (Default setting) Disabled : Disables MS UEFI CA Key


3.6 Boot

This Boot menu allows you to set/change system boot options



Item	Description
Full Screen LOGO Show	Enable/Disable full screen LOGO show on POST screen Enabled : Enables Full screen LOGO Show on POST screen Disabled : Disables Full screen LOGO Show on POST screen (Default setting)
Built-in EFI Shell	Enabled : Enables Built-in EFI Shell Disabled : Disables Built-in EFI Shell (Default setting)
Boot Option Priorities	Shows the information of the storage that be installed in the system Choose/set the boot priority

3.7 Save & Exit



Item	Description
Save Changes and Reset	After configuring all the options that you wish to change, choose this option to save all the changes and reboot the system Yes : Agree to save and reset No : Cancel to save and reset
Discard Changes and Reset	Choose this option to reboot the system without saving any changes Yes : Agree to discard changes and reset No : Cancel to discard changes and reset
Restore Defaults	Restore/Load default values for all the setup options Yes : Agree to load optimized defaults No : Cancel to load optimized defaults
Me FW Image Re-Flash	Enable/Disable Me FW image re-flash function Enabled : Enables Me FW image re-flash function Disabled : Disables Me FW image re-flash function (Default setting)