


User Manual



UNO-2271G V3 電腦

Intel® Pocket-Size Gateway with
Intel® Atom x7211RE

ADVANTECH

Enabling an Intelligent Planet

Copyright

The documentation and the software included with this product are copyrighted 2025 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. The information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties that may result from its use.

Acknowledgments

Intel® is the trademark of Intel® Corporation.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Support

For more information on this and other Advantech products, please visit our website at <http://www.advantech.com>

For technical support services, please visit our support website at <http://support.advantech.com/>

This manual applies to the following models. These are abbreviated as UNO-2271G V3 products in this article.

*Model name:

UNO-2271G V3

*Part number:

UNO-2271G-I331AE

UNO2271GI3312401-T UNO2271GI3312402-T UNO2271GI3312501-T

UNO2271GI3312502-T UNO2271GI3312503-T UNO2271GI3312504-T

UNO2271GI3312505-T UNO2271GI3312506-T UNO2271GI3312507-T

UNO2271GI3312508-T UNO2271GI3312601-T UNO2271GI3312602-T

UNO2271GI3312603-T UNO2271GI3312604-T UNO2271GI3312605-T

UNO2271GI3312606-T UNO2271GI3312607-T UNO2271GI3312608-T

UNO2271GI3312701-T UNO2271GI3312702-T UNO2271GI3312703-T

UNO2271GI3312704-T UNO2271GI3312705-T UNO2271GI3312706-T

UNO2271GI3312707-T UNO2271GI3312708-T UNO2271GI3312801-T

UNO2271GI3312802-T UNO2271GI3312803-T UNO2271GI3312804-T

UNO2271GI3312805-T UNO2271GI3312806-T UNO2271GI3312807-T

UNO2271GI3312808-T UNO2271GI3312901-T UNO2271GI3312902-T

UNO2271GI3312903-T UNO2271GI3312904-T UNO2271GI3312905-T

UNO2271GI3312906-T UNO2271GI3312907-T UNO2271GI3312908-T

UNO2271GI3313005-T UNO2271GI3313006-T UNO2271GI3313007-T

UNO2271GI3313008-T

Part No. 2001227100

Printed in Taiwan

Edition 1

March 2025

Product Warranty (2 years)

Advantech warrants the original purchaser that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products that have been repaired or altered by persons other than repair personnel authorized by Advantech, or products that have been subject to misuse, abuse, accident, or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced free of charge during the warranty period. For out-of-warranty repairs, customers will be billed according to the cost of replacement materials, service time, and freight. Please consult your dealer for more details.

If you believe your product to be defective, follow the steps outlined below.

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages displayed when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain a return merchandise authorization (RMA) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a completed Repair and Replacement Order Card, and a proof of purchase date (such as a photocopy of your sales receipt) into a shippable container. Products returned without a proof of purchase date are not eligible for warranty service.
5. Write the RMA number clearly on the outside of the package and ship the package prepaid to your dealer.

Declaration of Conformity

CE

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This type of cable is available from Advantech. Please contact your local supplier for ordering information.

Test conditions for passing also include the equipment being operated within an industrial enclosure. In order to protect the product from damage caused by electrostatic discharge (ESD) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference. In this event, users are required to correct the interference at their own expense.

警告使用者

警告：為避免電磁干擾，本產品不應安裝或使用於住宅環境。

Technical Support and Assistance

1. Visit the Advantech website at www.advantech.com/support to obtain the latest product information.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before calling:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Safety Precautions - Static Electricity

Follow these simple precautions to protect yourself from harm and the products from damage.

- To avoid electrical shock, always disconnect the power from the PC chassis before manual handling. Do not touch any components on the CPU card or other cards while the PC is powered on.
- Disconnect the power before making any configuration changes. A sudden rush of power after connecting a jumper or installing a card may damage sensitive electronic components.

Safety Instructions

1. Read these safety instructions carefully.
2. Retain this user manual for future reference.
3. Disconnect the equipment from all power outlets before cleaning. Use only a damp cloth for cleaning. Do not use liquid or spray detergents.
4. For pluggable equipment, the power outlet socket must be located near the equipment and easily accessible.
5. Protect the equipment from humidity.
6. Place the equipment on a reliable surface during installation. Dropping or letting the equipment fall may cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. Do not cover the openings.
8. Ensure that the voltage of the power source is correct before connecting the equipment to a power outlet.
9. Position the power cord away from high-traffic areas. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage from transient overvoltage.
12. Never pour liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If any of the following occurs, have the equipment checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated the equipment.
 - The equipment has been exposed to moisture.
 - The equipment is malfunctioning, or does not operate according to the user manual.
 - The equipment has been dropped and damaged.
 - The equipment shows obvious signs of breakage.
15. Do not leave the equipment in an environment with a storage temperature of below -40° C (-40° F) or above 85° C (185° F) as this may damage the components. The equipment should be kept in a controlled environment.
16. CAUTION: Batteries are at risk of exploding if incorrectly replaced. Replace only with the same or equivalent type as recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.
17. In accordance with IEC 704-1:1982 specifications, the sound pressure level at the operator's position does not exceed 70 dB (A).
18. This product is intended to be supplied by an UL certified power supply or dc source with SELV output, rated 10 Vdc, 4A minimum and Tma 40 degree. If you need further assistance, please contact Advantech for further information.
19. Ensure that the voltage of the power source is correct before connecting the equipment to a power outlet. The power outlet socket should have a grounded connection.
20. For use in pollution free environments and indoor use.
21. This equipment is not suitable for use in locations where children are likely to be present.
22. If the equipment is used in a manner not specified by the Advantech, the protection provided by the equipment may be impaired.

23. The equipment contains no user-serviceable parts. Do not open, Return to manufacturer for servicing.
24. Do not block air ventilation holes.
25. This is open type equipment and should be installed in a suitable enclosure.
26. Restricted Access Area: The equipment should only be installed in a Restricted Access Area.
27. This product is intended to be supplied by an UL Listed power supply suitable for use at Tma 60° C min. whose output meets ES1 (or SELV) is rated: (1) 10-30Vdc, 4A min. (DC IN) or 50-57Vdc, 0.51A min. (PoE IN), if need further assistance, please contact Advantech for further information.



Caution: Hot surface. Do not touch for Top Heatsink.

DISCLAIMER: These instructions are provided according to IEC 704-1 standards. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

Consignes de sécurité

1. Lire attentivement les instructions de sécurité.
2. Conserver ce manuel pour utilisation ultérieure,
3. Débranchez cet équipement de toute prise secteur avant le nettoyer. Utilisez seulement un chiffon humide. N'utilisez pas de détergent liquide ou pulvérisé pour le nettoyage.
4. Gardez cet équipement à l'abri de l'humidité.
5. Placez cet équipement sur une surface fiable pendant l'installation. Le faire ou bien le laisser tomber peut causer des dégâts.
6. Les ouvertures sur l'enceinte servent à la convection de l'air. Protégez l'équipement contre surchauffe. NE COUVREZ PAS LES OUVERTURES.
7. Assurez-vous que la tension de la source d'alimentation est correcte avant de connecter l'équipement à une prise de courant. La prise de courant doit avoir une connexion à la terre.
8. Placez le câble d'alimentation de manière à ce que personne ne puisse marcher dessus. Ne placez rien sur le câble d'alimentation.
9. Toutes les mises en garde et tous les avertissements sur l'équipement doivent être notés.
10. Si l'équipement n'est pas utilisé pendant une longue période, débranchez-le de la source d'alimentation pour éviter tout endommagement dû à une surtension transitoire.
11. Ne jamais verser de liquide dans une ouverture. Cela pourrait provoquer un incendie ou un choc électrique.
12. N'ouvrez jamais l'équipement. Pour des raisons de sécurité, l'équipement doit être ouvert uniquement par du personnel qualifié.
13. Si l'une des situations suivantes se présente, faites vérifier l'équipement par le personnel de service:
 - un liquide a pénétré dans l'équipement.
 - L'équipement a été exposé à l'humidité.
 - L'équipement ne fonctionne pas bien, ou vous ne pouvez pas le faire fonctionner selon le manuel de l'utilisateur.
 - L'équipement ne fonctionne pas bien, ou vous ne pouvez pas le faire fonctionner selon le manuel d'utilisation.

- L'équipement est tombé et endommagé.
 - L'équipement présente des signes évidents de rupture.
14. NE LAISSEZ PAS CET ÉQUIPEMENT DANS UN ENVIRONNEMENT OU LA TEMPÉRATURE DE STOCKAGE PEUT ÊTRE INFÉRIEURE À -40° C (-40° F) OU BIEN SUPÉRIEURE À 85° C (185° F). CECI POURRAIT ENDOMMAGER L'EQUIPEMENT. L'ÉQUIPEMENT DEVRAIT ÊTRE DANS UN ENVIRONNEMENT CONTRÔLÉ.
 15. Ce produit est destiné à être alimenté par une source d'alimentation certifiée UL ou par une source cc convenant à une utilisation à une température minimale de 40 degrés Celsius, dont la sortie est conforme à la norme SELV et dont la puissance nominale est de 10 Vdc, 7.7 A, en cas de besoin. contactez Advantech pour plus d'informations.
 16. Pour une utilisation dans des environnements non polluant et à l'intérieur.
 17. C'est appareil ne doit pas être utilisé dans des endroits où se trouvent des enfants.
 18. Si l'équipement est utilisé d'une manière non spécifiée par le fabricant, la protection fournie par l'équipement peut être altéré.
 19. L'équipement ne contient aucune pièce réparable par l'utilisateur. Ne pas ouvrir, retourner au fabricant pour réparation.
 20. Ne bloquez pas les ou es de ventilation.
 21. Il s'agit d'un équipement de type ouvert et doit être installé dans un boîtier approprié.



Attention: Surface chaude, ne pas toucher pour le dissipateur thermique supérieur.

22. **ATTENTION:** Danger d'explosion si la batterie est mal remplace. Remplacer unique- ment par le meme type ou equivalent recommandé par le fabricant. Jeter les piles usagées selon les instructions du fabricant.

安全指示

1. 請仔細閱讀此安全操作說明。
2. 請妥善保存此用戶手冊供日後參考。
3. 用濕抹布清洗設備前，請確認拔除電源線。請勿使用液體或去污噴霧劑清洗設備。
4. 對於使用電源線的設備，設備周圍必須有容易接觸到的電源插座。
5. 請勿在潮濕環境中試用設備。
6. 請在安裝前確保設備放置在可靠的平面上，意外摔落可能會導致設備損壞。
7. 設備機殼的開孔適用於空氣對，從而防止設備過熱。請勿覆蓋開孔。
8. 當您連接設備到電源插座前，請確認電源插座的電壓符合要求。
9. 請將電源線佈置在人們不易絆倒的位置，請勿在電源線上覆蓋任何雜物。
10. 請注意設備上所有的警告標示。
11. 如果長時間不使用設備，請拔除與電源插座的連結，避免設備被超標的電壓波動損壞。
12. 請勿讓任何液體流入通風口，以免引起火災或短路。
13. 請勿自行打開設備。為了確保您的安全，請透過經認證的工程師來打開設備。
14. 如遇下列情況，請由專業人員維修：
 - 電源線或插頭損壞；
 - 設備內部有液體流入；
 - 設備曾暴露在過度潮濕環境中使用；
 - 設備無法正常工作，或您無法透過用戶手冊來正常工作；
 - 設備摔落或損壞；
 - 設備有明顯外觀損；
15. 請勿將設備儲存在超出建議溫度範圍的環境，即不要低於 -40°C (-40°F) 或高於 85°C (185°F)，否則可能會造成設備損壞。
16. 注意：若電池更換不正確，將有爆炸危險。因此，只可以使用製造商推薦的同一種或者同等型號的電池進行替換。請按照製造商的指示處理舊電池。
17. 根據 IEC 704 - 1:1982 規定，操作員所在位置音量不可高於 70 分貝。
18. 限制區域：請勿將設備安裝於限制區域使用。
19. 免責聲明：請安全訓示符合 IEC 704 - 1 要求。研華公司對其內容之準確性不承擔任何法律責任。
20. 消費者若使用电源适配器供电，则应购买配套使用获得 CCC 认证并满足标准要求的电源适配器。



警告：機殼高溫。請勿在使用過程中觸碰上方散熱鰭片。

限用物質含有情況標示聲明書

Declaration of the Presence Condition of the Restricted Substances Marking

設備名稱：電腦		型號（型式）：UNO-2271G-I331AE				
Equipment name		Type designation (Type)				
單元 Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛 Lead (Pb)	汞 Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁶⁺)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
電路板	—	○	○	○	○	○
內外殼 （外殼、內 部框架 … 等）	—	○	○	○	○	○
其它固定 組件（螺 絲、夾具、 卡榫）	—	○	○	○	○	○
揚聲器 / 蜂鳴器	○	○	○	○	○	○
備考 1. “超出 0.1 wt %” 及 “超出 0.01 wt %” 係指限用物質之百分比含量超出百分比含量基準值。 Note 1. “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition. 備考 2. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。 Note 2. “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence. 備考 3. “—” 係指該項限用物質為排除項目。 Note 3. The “-” indicates that the restricted substance corresponds to the exemption.						

Contents

Chapter 1	Overview.....	1
1.1	Introduction	2
1.2	Safety Precautions	2
1.3	Packing List.....	3
1.4	Hardware Specifications	3
1.4.1	General	3
	Table 1.1: General Hardware Spec	3
1.4.2	System Hardware	4
	Table 1.2: System Hardware Spec	4
1.4.3	I/O Interfaces	5
	Table 1.3: I/O Interfaces	5
1.4.4	Environment.....	5
	Table 1.4: Environment	5
1.4.5	Certification.....	5
	Table 1.5: Certification.....	5
1.4.6	Extension Kit (Optional)	6
	Table 1.6: UNO-2271G-RP1EB.....	6
	Table 1.7: UNO-2271G-RS2EB.....	6
	Table 1.8: UNO-2271G-EKDE.....	7
1.5	Dimensions	7
	Figure 1.1 UNO-2271G V3 Dimensions	7
Chapter 2	Hardware Functionality	9
2.1	Introduction	10
2.1.1	Base Unit's Internal Connectors	10
	Figure 2.1 Diagram of Connector Locations on UNO-2271G V3 (Top Side).....	10
	Figure 2.2 Diagram of Key Components Location on UNO-2271G V3 (Bottom Side).....	10
	Table 2.1: Key Components, Connectors on Motherboard	11
2.1.2	Base Unit's External I/O Connector	11
	Figure 2.3 Front I/O of UNO-2271G V3	11
	Figure 2.4 Side I/O of UNO-2271G V3	11
2.1.3	Expansion Kit's Internal Connectors (Optional)	12
	Figure 2.5 Locations Internal I/O Connectors/Switches for UNO- 2271G-RS2EB (Top Side) (Optional)	12
	Figure 2.6 Locations Internal I/O Connectors/Switches for UNO- 2271G-RS2EB (Bottom Side) (Optional)	13
	Figure 2.7 Locations Internal I/O Connectors/Switches for UNO- 2271G-RP1EB (Top Side) (Optional)	13
	Figure 2.8 Locations Internal I/O Connectors/Switches for UNO- 2271G-RP1EB (Bottom Side) (Optional)	14
	Table 2.2: Internal Connectors and Jumper Switches.....	14
Chapter 3	Initial Setup	17
3.1	Chassis Grounding.....	18
	Figure 3.1 Chassis Grounding Connection Diagram	18
3.2	Connecting Power	18
3.3	Open and Close Bottom Cover	19
3.3.1	Install M.2 B+M to E Key Converter (Optional)	20

3.4	Installing a 2nd Stack Extension Kit (Optional)	22
3.4.1	Pre-work before 2nd Stack Assembly	22
3.4.2	Installing a 2nd Stack Extension Kit (UNO-2271G-EKDE)	23
3.4.3	Installing a 2nd Stack Extension Kit (UNO-2271G-RP1EB)	26
3.4.4	Installing a 2nd Stack Extension Kit (UNO-2271G-RS2EB)	29
3.5	Installing Internal Component	33
3.5.1	Installing M.2 2242 Module	33
3.5.2	Installing the M.2 B-Key Module on Extension Kit (UNO-2271G-RP1EB/UNO-2271G-RS2EB)	35
3.5.3	Installing the M.2 E-key Module on Extension Kit (UNO-2271G-RS2EB)	36
3.6	Antenna Installation (Optional)	37
3.7	BIOS Setting	38

Appendix A System Settings/Pin Assignments .. 39

A.1	Power Connector (DCIN1)	40
	Table A.1: Power Connector Pin Assignments	40
A.2	LAN: Ethernet Connector (LAN 1& LAN 2)	40
	Table A.2: Ethernet Connector Pin Assignments	40
	Table A.3: LAN LED Light Definition	40
A.3	USB Connector (USB1)	41
A.3.1	USB 3.2 Connector	41
	Table A.4: USB 3.2 Connector Pin Assignments	41
A.3.2	USB Type C	42
	Table A.5: USB Type C	42
A.4	HDMI Connector (HDMI1)	43
	Table A.6: Display Port Adapter Cable Pin Assignments	43
A.5	M.2 B-key Connector (M.2_B1)	44
	Table A.7: M.2 B Key Connector Pin Assignments	44
A.6	M.2 E-Key Connector (CN40)	45
	Table A.8: M.2 E key Connector Pin Assignments	45
A.7	COM Port RS232/422/485 Settings	46
	Table A.9: COM Connector Pin Assignments	46
A.7.1	RS232/422/485 Setting (SW8/SW1)	47
	Table A.10: RS232/422/485 Setting (SW8/SW1)	47
A.7.2	COM Port RS422/485 Termination Resistor Setting	48
	Table A.11: COM Port RS422/485 Termination Resistor Setting	48
A.8	Internal Switch	48
A.8.1	AT/ATX Setting(SW4)	48
	Table A.12: AT/ATX Setting (SW4)	48
A.8.2	Clear CMOS Setting (SW3)	49
	Table A.13: Clear CMOS Function (SW3)	49
A.9	Board to Board Connector (Reserved for Expansion) (BTB1)	49
	Table A.14: Expansion Board to Board Connector Pin Assignments	49
A.10	BIOS Operation	50
A.10.1	Introduction	50
A.10.2	Entering BIOS Setup	50
	Figure A.1 Main Setup Screen	50
A.10.3	Advanced BIOS Features	51
	Figure A.2 Advanced BIOS Features Setup Screen	51
	Figure A.3 CPU Configuration	52
	Figure A.4 Power & Performance	52
	Figure A.5 CPU – Boot Performance Mode	53
	Figure A.6 PCH-FW Configuration	54
	Figure A.7 TPM Device Selection	55
	Figure A.8 ACPI Settings	56
	Figure A.9 NCT61260 Super IO Configuration	56

	Figure A.10Serial Port 1 Configuration	57
	Figure A.11Serial Port 2 Configuration	57
	Figure A.12S5 RTC Wake Settings	58
	Figure A.13USB Configuration.....	59
	Figure A.14Network Stack Configuration.....	60
A.10.4	Chipset.....	60
	Figure A.15Chipset	60
	Figure A.16System Agent (SA) Configuration	61
	Figure A.17Memory Configuration	61
	Figure A.18PCH-IO Configuration	62
	Figure A.19M.2 E-key/LAN 3	63
	Figure A.20LAN 1	63
	Figure A.21LAN 2	64
	Figure A.22M.2 B-key	64
	Figure A.23BTB2	65
	Figure A.24SATA Configuration.....	65
A.10.5	Security	66
	Figure A.25Security	66
A.10.6	Boot Options	67
	Figure A.26Boot Options.....	67
A.10.7	Save and Exit.....	67
	Figure A.27Save and Exit	67

Chapter 1

Overview

This chapter overviews specifications for UNO-2271G V3.

- Introduction
- Safety Precautions
- Accessories
- Hardware Specifications
- Dimensions

1.1 Introduction

Advantech's new UNO-2 series serves as modular Integrated Edge Computers, providing configuration flexibility for customers seeking to cost-effectively optimize their services. The new integrated DIN-rail mounting kit is designed to be more rugged and user-friendly, making it a perfect fit for control cabinets.

The new UNO-2271G V3 model features a rugged design with an industrial-grade Intel® Atom® dual-core x7211RE processor, built-in 8GB LPDDR5, and 64GB eMMC. It supports a wide temperature range (-20 to 60°C / -4 to 140°F) and offers sufficient I/O, including 2 x LAN, 1 x USB 3.2 Gen 2, and 1 x USB Type-C (1.5A), which supports DP, USB, and DP Alt Mode, plus 1 x HDMI and 1 x 2-pin terminal block. It also supports 1 x M.2 B-key slot (PCIe x1 / SATA / USB 3.2) to enable expansion.

An optional second-stack extension kit supports 2 x RS-232/422/485 and 1 x PoE+ (802.3at) or 1 x iDoor module, such as industrial Fieldbus, as well as additional I/O and peripheral modules. This expandability makes Advantech's UNO-2 series an excellent choice for various industrial applications. Additionally, UNO-2's flexible expandability and control functions meet emerging demands for Industry 4.0.

1.2 Safety Precautions

Below are a few safety precautions for preventing injury when making connections. In most cases, users can use a standard cable for connection.

Warning! *Always disconnect the power cord from the chassis before manual handling. Do not connect the chassis while the system power is on. A sudden rush of power can damage sensitive electronic components. Only experienced electronics personnel should open the chassis.*



Warning! *Toujours à la terre pour éliminer toute charge d'électricité statique avant toucher UNO-2271G V3. Appareils électroniques modernes sont très sensibles à charges d'électricité statique. Utilisez un bracelet antistatique à tout moment. Placez tous composants électroniques sur une surface antistatique ou dans un statique-sac blindé.*



Caution! *Always ground yourself to remove any static electric charge before touching UNO-2271G V3. Modern electronic devices are very sensitive to static electric charges. Use a grounding wrist strap at all times. Place all electronic components on a static-dissipative surface or in a static shielded bag.*



Caution! *Toujours débrancher le cordon d'alimentation de votre boîtier lorsque vous êtes travailler. Ne branchez pas lorsque l'appareil est allumé. Un afflux soudain de puissance peut endommager les composants électroniques sensibles. Seulement connu personnel de l'électronique devraient ouvrir le châssis.*



1.3 Packing List

Please refer to below packing list:


- UNO-2271G V3
- 1 x 2-pin plug-in block for power wiring
- 1 x Startup manual
- Warranty card


If anything is missing or damaged, contact your distributor or sales representative immediately.

1.4 Hardware Specifications

1.4.1 General

Table 1.1: General Hardware Spec	
Dimensions (W x D x H)	100 x 70 x 41.5 mm/3.9 x 2.8 x 1.63 in
Weight (Net)	0.5 kg (1.1 lbs)
Mounting	Stand/Wall mount (Optional Din-rail mount/VESA mount)
Power Requirement	10 - 30V _{DC}
Power Consumption	12W (typical), 40W (Max) with 2nd stack expansion module (UNO-2271G-RP1EB): Max to 33.3W (PoE input Max to 25.5W) with 2nd stack expansion module (UNO-2271G-RS2EB): Max to 34.8W





1.4.2 System Hardware

Table 1.2: System Hardware Spec

BIOS	AMI EFI X64
Watchdog Timer	Programmable 255 levels timer interval, from 1 to 255 sec
Hardware Security	TPM 2.0
Processor	Intel® Atom Dual core x7211RE
Memory	Onboard 8GB LPDDR5
Graphics Engine	Intel® UHD Graphics
Ethernet	2 x Intel® i226-IT GbE, IEEE 802.3AZ/802.1AS
LED Indicators	1x RUN, 1 x Power, and LAN (active, status)
Storage	Onboard 64GB eMMC Optional: 1 x M.2 B+M key 2242 (SATA/PCIe)
Expansion	1 x M.2 B+M key 2242 (SATA/PCIe)

Note: There's no SIM card holder on UNO-2271G V3 mainboard. To support M.2 LTE/5G functions, need additionally add 2nd stack extension kit.

1.4.3 I/O Interfaces

Table 1.3: I/O Interfaces	
LAN Ports	2 x 10/100/1000/2500BASE-T Fast Ethernet (RJ45)
USB Ports	1 x USB 3.2 Gen2 X1 1 x USB Type C (1.5A), supports DP & USB, DP ALT mode
Displays	1 x HDMI (1920 x 1080 @60Hz)
Power Connector	1 x 2-pin terminal block

1.4.4 Environment

Table 1.4: Environment	
Operating Temperature*	-20 ~ 60° C (-4 ~ 140° F) @5~85% RH with 0.7 m/s airflow
Storage Temperature	-40 ~ 85° C (-40 ~ 185° F)
Relative Humidity	10~95% RH @ 40° C/104° F, non-condensing
Shock Protection	Operating, IEC 60068-2-27, 50G, half sine, 11ms
Vibration Protection	Operating, IEC 60068-2-64, 2Grms, random, 5 ~500Hz
Ingress Protection	IP30

1.4.5 Certification

Table 1.5: Certification	
Certification	CE, FCC, UL, CCC, BSMI

1.4.6 Extension Kit (Optional)

UNO-2271G V3 features a modularized design. Advantech offers two optional 2nd stack extension kits for users to expand the functionality using an Advantech iDoor module.




Table 1.6: UNO-2271G-RP1EB

Part number	UNO-2271G-RP1EB
Description	2nd stack extension kit to support POE PD, COM, M.2 B key
Ports	1 x POE (802.3AT), 1 x COM
Dimensions (W x D x H)	30 x 70 x 100 mm (11.8 x 27.6 x 39.3 in)
Weight	0.3 kg (0.66 lbs)

Note! Due to max 25.5W supply via POE, USB ports should be limited to connect with USB2.0 devices only.





Table 1.7: UNO-2271G-RS2EB

Part number	UNO-2271G-RS2EB
Description	2nd stack extension kit to support COM, M.2 B key, M.2 E key
Ports	2 x COM, 1 x M.2 B key, 1 x M.2 E key
Dimensions (W x D x H)	30 x 70 x 100 mm (11.8 x 27.6 x 39.3 in)
Weight	0.2 kg (0.44 lbs)


**Table 1.8: UNO-2271G-EKDE**

Part number	UNO-2271G-EKDE
Description	2nd stack extension kit to support 1 x iDoor module w/ powder coat
Ports	1 x iDoor installation space
Dimensions (W x D x H)	30 x 70 x 100 mm (11.8 x 27.6 x 39.3 in)
Weight	0.1 kg (0.22 lbs)

Note! Most of the iDoor modules can handle system operating temperatures of 60° C (140° F). (Exception: PoE iDoor, USB 3.0 iDoor).



1.5 Dimensions

**Figure 1.1 UNO-2271G V3 Dimensions**

Chapter 2

Hardware Functionality

This chapter details setup instructions for UNO-2271G V3's hardware functions. It includes connecting peripherals and indicators.

- Introduction
- External I/O Connector
- Internal I/O Connector
- LED Indicators
- Reset Buttons
- Antenna Hole

2.1 Introduction

The following diagram demonstrates the location of UNO-2271G V3's motherboard and extension kit's internal/external connectors.

2.1.1 Base Unit's Internal Connectors




Figure 2.1 Diagram of Connector Locations on UNO-2271G V3 (Top Side)






Figure 2.2 Diagram of Key Components Location on UNO-2271G V3 (Bottom Side)

Table 2.1: Key Components, Connectors on Motherboard

Category	Label	Function
External	DCIN1	DC Input power Connector
	PWR1	Power Button Connector
	RST1	Reset
	LAN1	RJ45 Connector
	LAN2	RJ45 Connector
	HDMI1	HDMI Connector
	USB3C1	USB3.2 Connector
	USB3C2	TypeC Connector
Internal	BAT1	Battery Connector
	SW3	Clear CMOS
	SW4	AT/ATX mode
	BTB1	2nd stack connector
	BTB2	reserved
	M.2-B1	M.2 Key B Connector for Storage / iDoor expansion

2.1.2 Base Unit's External I/O Connector

**Figure 2.3 Front I/O of UNO-2271G V3****Figure 2.4 Side I/O of UNO-2271G V3**

2.1.2.1 Power Connector

UNO-2271G V3 comes with a Phoenix connector that carries 10 - 30 V_{DC} external power input, and features reversed wiring protection. Therefore, the system will not accrue damage from reversed polarity of ground lines and power lines. (Please refer to User Manual - Appendix A.1 for pin assignments)

2.1.2.2 LAN: Ethernet Connector

UNO-2271G V3 is equipped with two Gigabit LAN controllers. An Intel® i226 IT Ethernet controller that complies with 10/100/1000/2500BASE-T Fast Ethernet (RJ45) is used as the controller chip. The Ethernet port is a standard RJ-45 jack. Additionally, LED indicators are provided on the front of the device to indicate the system's Link (off/green/orange) and Active (green) status. (Please refer to User Manual- Appendix A.2 for pin assignments.)

2.1.2.3 USB Connector

UNO-2271G V3 features 2 x USB ports for Rev. 3.2 specifications. The USB connectors support plug-and-play and hot-swap-ping functionality for external devices. Additionally, this can be enabled/disabled in the BIOS menu. (Please refer to User Manual- Appendix A.3 for pin assignments.)

2.1.2.4 HDMI Connector

UNO-2271G V3 provides 1 x HDMI connector for a high resolution interface, 1920 x 1080 @60Hz. (Please refer to User Manual- Appendix A.4 for pin assignments.)

2.1.3 Expansion Kit's Internal Connectors (Optional)




Figure 2.5 Locations Internal I/O Connectors/Switches for UNO-2271G-RS2EB (Top Side) (Optional)




Figure 2.6 Locations Internal I/O Connectors/Switches for UNO-2271G-RS2EB (Bottom Side) (Optional)




Figure 2.7 Locations Internal I/O Connectors/Switches for UNO-2271G-RP1EB (Top Side) (Optional)




Figure 2.8 Locations Internal I/O Connectors/Switches for UNO-2271G-RP1EB (Bottom Side) (Optional)

Table 2.2: Internal Connectors and Jumper Switches

Label	Function
CN4	COM Port Terminal Connector (RS232/422/485)
CN37	LAN Signal Connector
CN2	M.2 B key for 2242/3042/3052 Connector
CN40	M.2 E key for 2230 Connector
CN3	SIM card slot
SW8/SW1	COM port setting switch
CN1	Internal board to board Connector

2.1.3.1 M.2 B-key Connector

There is one M.2 B Key connector for M.2 cards, labeled “CN2” on the expansion board. This M.2 interface is a SATA signal co-lay with a USB3.0 signal. It will automatically detect which device you installed and determine the appropriate SATA or USB signal to use. Therefore, it supports the installation of M.2 2242 (w/SATA signal) or 3042/3052 module (w/ USB Signal).

(Please refer to user manual-chapter 3.3 & 3.5 for installation details and User Manual-Appendix A.6 for pin assignments.)

2.1.3.2 COM Connector

The second stack extension kit of UNO-2271G V3 provides has 2 COM RS232/422/485 ports of terminal block type. They offer transmission speeds of 50 ~115.2 kbps.

The default mode for both COM ports (COM1&COM2) is RS-232 Mode. Settings can be adjusted via an on-board switch (SW1).

(Please refer to User Manual- Appendix A.8 for RS232/422/485 settings).

2.1.3.3 LED Indicators

Three LEDs indicate the status of the system’s power, RTC battery, and programmable LED for user’s configurations.

- PWR (Power): Green indicates “normal” and orange indicates “standby”.
- RUN: Users can configure the LED indicator’s behavior through GPO signal controls. Green indicates under programming.

2.1.3.4 Reset Buttons

Press the “Reset” button to initiate a hardware reset.

2.1.3.5 Antenna Hole

This product offers two antenna mounting holes covered by pre-cut holes for users to install an antenna kit for LTE or wireless functions.

Chapter 3

Initial Setup

This chapter explains how to initialize the UNO-2271G V3.

- Chassis Grounding
- Connecting Power
- Open and Close Bottom Cover
- Installing a 2nd Stack Extension Kit
- Installing Internal Component
- Antenna Installation (Optional)
- BIOS Settings

3.1 Chassis Grounding

UNO-2271G V3 provides EMI protection and a stable grounding base and there is an easy-to-connect chassis grounding point for this purpose.




Figure 3.1 Chassis Grounding Connection Diagram

Use the grounding cable (16 AWG) from the accessory bag to connect the chassis ground with the Earth ground.

3.2 Connecting Power

This product is intended to be supplied by an approved power adapter or DC power source. This adapter is rated at 10 - 30 V_{DC}, 4A-1.33A and has a T_{max} of 60° C (140° F). If you need further assistance or information, please contact Advantech.

Note! It is recommended to choose a 60W adapter when selected iDoor expansion module (e.g. PCM-24R2PE) is installed. Recommended PN: 96PSA-A120W19T2-3.




Follow the following instructions:

1. Insert the positive and negative wires into the V+ and V- contacts on the terminal block connector.
2. Tighten the wire-clamp screws to prevent the DC wires from coming loose.

Take the following guidelines into consideration before wiring the device:

1. The terminal block is suitable for 16-24 AWG (8A). The torque value is 2.5 lb-in. Use copper conductors only.
2. The temperature rating of the input connection cable should be higher than 105° C (221° F).




3.3 Open and Close Bottom Cover

The steps for opening and closing the bottom cover of UNO-2271G V3 are demonstrated below.


Unscrew (1930008736*4) & stopper (1990036188S000*1).

Remove BTM cover(1960101339N011*1).




3.3.1 Install M.2 B+M to E Key Converter (Optional)


1. Unscrew (1930001062*1) & remove Bracket (1960102502T000)




2. Install B to E card & lock screw (1930001062*1)



3. Install E card & lock screw (1930008738*1)




4. Remove AL Chunk (1960116779N000*1)&screw(1930005541*1)




3.4 Installing a 2nd Stack Extension Kit (Optional)

3.4.1 Pre-work before 2nd Stack Assembly

1. Unscrew (1930008736*4) & stopper (1990036188S000*1)
Remove BTM cover(1960101339N011*1)




2. Remove AL Chunk(1960116779N000*1)&screw(1930005541*1)




3.4.2 Installing a 2nd Stack Extension Kit (UNO-2271G-EKDE)


1. Re-- install AI Chunk(1960116779N000*1) & lock screw(1930005541*1)




2. Install EXP rear cover(1960116833N001*1) & Lock screw (1930008736*3).



3. Install EXP front cover(1960101372N002*1) & Lock screw (1930008736*2).




4. Put on BTM cover(1960101339N011*1).
Lock screw (1930008736*3) & stopper (1990036188S000*3).




3.4.3 Installing a 2nd Stack Extension Kit (UNO-2271G-RP1EB)


1. Re-install AI Chunk(1960116779N000*1) & lock screw (1930005541*1)



2. Install UNO-2271G-RP1EB & Lock screw (1930008736*3).




3. Put on BTM cover(1960101339N011*1).
Lock screw (1930008736*3) & stopper (1990036188S000*3).




3.4.4 Installing a 2nd Stack Extension Kit (UNO-2271G-RS2EB)


1. Re-install AI Chunk(1960116779N000*1) & lock screw(1930005541*1).




2. Install UNO-2271G-RS2EB & Lock screw (1930008736*3)




3. (for M.2 LTE or 5G must be install) AL Chunk(1960117266N000*1)
Lock screw (1930005541*1) & Put on the thermal Pad (1990041984N000*1)






4. Put on BTM cover(1960101339N011*1).
Lock screw (1930008736*3) & stopper (1990036188S000*3).




3.5 Installing Internal Component

3.5.1 Installing M.2 2242 Module


1. Unscrew (1930008736*4) & stopper (1990036188S000*1).
Remove BTM cover(1960101339N011*1).



2. Unscrew (1930008738*1).




3. Insert 2242 module & Lock screw (1930008738*1).




3.5.2 Installing the M.2 B-Key Module on Extension Kit (UNO-2271G-RP1EB/UNO-2271G-RS2EB)

Installing M.2 3042 card

1. Remove the pre-installed screw.




2. Insert the M.2 3042 card at the location of “CN2” and lock the screw.




Installing M.2 3052 card

1. Remove the pre-installed screw.




2. Insert the M.2 3042 card at the location of “CN2” and lock the screw.




3.5.3 Installing the M.2 E-key Module on Extension Kit (UNO-2271G-RS2EB)

Installing M.2 2230 card

1. Remove the pre-installed screw.




2. Insert the M.2 2230 card at the location of “CN40” and lock the screw.




3.6 Antenna Installation (Optional)

UNO-2271G V3 reserves pre-cut antenna hole for wireless connection. Follow the steps below for installation the SMA cable and antenna.


1. Unscrew (1930008736*4) & stopper (1990036188S000*1).
Remove BTM cover(1960101339N011*1).



2. Remove the plug of the antenna's pre-cut hole(s) on the rear panel.



3. Assemble SMA cable on the pre-cut hole.



3.7 BIOS Setting

With the BIOS Setup program, you can modify BIOS settings and control the special features of your computer. The Setup program uses a number of menus for making changes and turning special features on or off.

Press the “ESC” key upon the first boot up to enter the BIOS setup screen, after then, press the “Del” key during the Power On Self Test (POST) process to enter the BIOS setup screen, otherwise the system will continue the POST process.

(Please refer to User Manual- Appendix A.10)

Appendix **A**

System Settings/Pin Assignments

A.1 Power Connector (DCIN1)



Table A.1: Power Connector Pin Assignments

Pin	Signal	Description
1	Power IN V+	10 - 30 V _{DC}
2	Power IN V- (GND)	

A.2 LAN: Ethernet Connector (LAN 1 & LAN 2)




Table A.2: Ethernet Connector Pin Assignments

RJ45 Pin	Signal	Description
1	MDI0+	■ In BASE-T: Media Dependent Interface[0]: ■ 1000BASE-T: In MDI configuration, MDI[0]+/- corresponds to BI_DA+/- and in MDI-X configuration MDI[0]+/- corresponds to BI_DB+/-.
2	MDI0-	■ 10BASE-T and 100BASE-TX: In MDI configuration, MDI[0]+/- is used for the transmit pair and in MDIX configuration MDI[0]+/- is used for the receive pair.
3	MDI1+	■ In BASE-T: Media Dependent Interface[1]: ■ 1000BASE-T: In MDI configuration, MDI[1]+/- corresponds to BI_DB+/- and in MDI-X configuration MDI[1]+/- corresponds to BI_DA+/-.
6	MDI1-	■ 10BASE-T and 100BASE-TX: In MDI configuration MDI[1]+/- is used for the receive pair and in MDI-X configuration MDI[1]+/- is used for the transmit pair.
4	MDI2+	■ In BASE-T: Media Dependent Interface[3:2]: ■ 1000BASE-T: In MDI and in MDI-X configuration, MDI[2]+/- corresponds to BI_DC+/- and MDI[3]+/- corresponds to BI_DD+/-.
5	MDI2-	
7	MDI3+	
8	MDI3-	■ 100BASE-TX: Unused. ■ 10BASE-T: Unused.

Table A.3: LAN LED Light Definition

Left LED				Right LED	
10Mbps (off)	100Mbps (off)	1000Mbps (Orange)	2500Mbps (Green)	Link (Green)	Active (Green Flash)

A.3 USB Connector (USB1)

A.3.1 USB 3.2 Connector




Table A.4: USB 3.2 Connector Pin Assignments

Pin	Signal Name	Description
1	VBUS	Power
2	D-	USB 2.0 differential pair
3	D+	
4	GND	Ground for power return
5	StdA_SSRX-	SuperSpeed receiver differential pair
6	StdA_SSRX+	
7	GND_DR1AN	Ground for signal return
8	StdA_SSTX-	SuperSpeed transmitter differential pair
9	StdA_SSTX+	

A.3.2 USB Type C




Table A.5: USB Type C

Pin	Signal Name	Pin	Signal Name
A1	GND	B1	GND
A2	USBC_TXP1_CON	B2	USBC_TXP2_CON
A3	USBC_TXN1_CON	B3	USBC_TXN2_CON
A4	+VUSB_C1	B4	+VUSB_C1
A5	TCPC0_CC1_CONN	B5	TCPC0_CC2_CONN
A6	USB2_P	B6	USB2_P
A7	USB2_N	B7	USB2_N
A8	TCP0_SBU1_CONN	B8	TCP0_SBU2_CONN
A9	+VUSB_C1	B9	+VUSB_C1
A10	USBC_RXN2_CON	B10	USBC_RXN1_CON
A11	USBC_RXP2_CON	B11	USBC_RXP1_CON
A12	GND	B12	GND

A.4 HDMI Connector (HDMI1)




Table A.6: Display Port Adapter Cable Pin Assignments

Pin	Signal Name
1	TMDS1_a_P0
2	GND
3	TMDS1_a_N0
4	TMDS1_a_P1
5	GND
6	TMDS1_a_N1
7	TMDS1_a_P2
8	GND
9	TMDS1_a_N2
10	TMDS1_CLK_a_P
11	GND
12	TMDS1_CLK_a_N
13	NC
14	NC
15	TMDS1_DDCCLK
16	TMDS1_DDCCDAT
17	GND
18	+V5
19	TMDS1_HPD

A.5 M.2 B-key Connector (M.2_B1)





Table A.7: M.2 B Key Connector Pin Assignments

Pin	Signal Name	Pin	Signal Name
1	M2_SATA1_DET	2	+V3.3_M2
3	GND	4	+V3.3_M2
5	GND	6	M2_LTE_PWR_OFF#
7	M2_LTE_USB_DP	8	M2_LTE_W1_DISABLE_N
9	M2_LTE_USB_DN	10	+V3.3_M2
11	GND	12	Mechanical notch B
13	Mechanical notch B	14	Mechanical notch B
15	Mechanical notch B	16	Mechanical notch B
17	Mechanical notch B	18	Mechanical notch B
19	Mechanical notch B	20	NC
21	NC	22	NC
23	WAKE_ON_WAN#	24	NC
25	NC	26	M2_LTE_W2_DISABLE_N
27	GND	28	NC
29	USB_Z_SSRX1-	30	M2_SIM1_RESET
31	USB_Z_SSRX1+	32	M2_SIM1_CLK
33	GND	34	M2_SIM1_DATA
35	USB_C_SSTX1-	36	M2_SIM1_PWR
37	USB_C_SSTX1+	38	NC
39	GND	40	M2_SIM2_DET
41	SATA1_RX+	42	NC
43	SATA1_RX-	44	NC
45	GND	46	NC
47	SATA1_C_TX-	48	NC
49	SATA1_C_TX+	50	NC
51	GND	52	NC
53	NC	54	NC
55	NC	56	NC
57	GND	58	NC
59	NC	60	NC
61	NC	62	NC
63	NC	64	NC
65	NC	66	M2_SIM1_DET
67	LTE_RST#_P67	68	NC

Table A.7: M.2 B Key Connector Pin Assignments

69	NC	70	+V3.3_M2
71	GND	72	+V3.3_M2
73	GND	74	+V3.3_M2
75	NC		

A.6 M.2 E-Key Connector (CN40)


Table A.8: M.2 E key Connector Pin Assignments


Pin	Signal Name	Pin	Signal Name
1	GND	2	+V3.3SB_M2E
3	M2E_USB_D+	4	+V3.3SB_M2E
5	M2E_USB_D-	6	M2E_LED_1#
7	GND	8	NC
9	NC	10	NC
11	NC	12	NC
13	NC	14	NC
15	NC	16	M2E_LED_2#
17	NC	18	GND
19	NC	20	NC
21	NC	22	NC
23	NC	24	Mechanical notch E
25	Mechanical notch E	26	Mechanical notch E
27	Mechanical notch E	28	Mechanical notch E
29	Mechanical notch E	30	Mechanical notch E
31	Mechanical notch E	32	NC
33	GND	34	NC
35	PCIE_M2_TX1+	36	NC
37	PCIE_M2_TX1-	38	NC
39	GND	40	NC
41	PCIE_M2_RX1+	42	NC
43	PCIE_M2_RX1-	44	NC
45	GND	46	NC
47	CLK_M2_PCIE1+	48	NC
49	CLK_M2_PCIE1-	50	M2E_SUSCLK
51	GND	52	M2E_PERST0#
53	M2E_CLKREQ0#	54	M2E_z_W_DISABLE2#
55	M2E_PEWAKE0#	56	M2E_z_W_DISABLE1#

Table A.8: M.2 E key Connector Pin Assignments

57	GND	58	M2E_I2C_DATA
59	NC	60	M2E_I2C_CLK
61	NC	62	M2E_ALERT#
63	GND	64	NC
65	NC	66	M2E_PERST1#
67	NC	68	M2E_CLKREQ1#
69	GND	70	M2E_PEWAKE1#
71	NC	72	+V3.3SB_M2E
73	NC	74	+V3.3SB_M2E
75	GND		

A.7 COM Port RS232/422/485 Settings

The default setting for the COM port is RS-232. This can be changed to RS-422 or RS-485 modes can be configured by adjusting switch on the motherboard.

**Table A.9: COM Connector Pin Assignments**

Pin	COM1 Mode	Signal Name	Pin	COM2 Mode	Signal Name
1	RS232	CTS	2	RS232	CTS
	RS422	T-		RS422	T-
	RS485	D-		RS485	D-
3	RS232	RXD	4	RS232	RXD
	RS422	T+		RS422	T+
	RS485	D+		RS485	D+
5	RS232	TXD	6	RS232	TXD
	RS422	R+		RS422	R+
	RS485			RS485	
7	RS232	RTS	8	RS232	RTS
	RS422	R-		RS422	R-
	RS485			RS485	
9	RS232	GND	10	RS232	GND
	RS422	GND		RS422	GND
	RS485	GND		RS485	GND

A.7.1 RS232/422/485 Setting (SW8/SW1)

Note:








SW8 For UNO-2271G-RS2EB

SW1 For UNO-2271G-RP1EB

Bit 1~5 for COM 1


Bit 6~10 for COM2

Table A.10: RS232/422/485 Setting (SW8/SW1)

			
Description		This switch is used to select RS232/422/485 mode setting	
Default		RS232 mode	
COM1	RS232 Mode	Bit 1 ON Bit 2,3,4,5,6,7,8,9,10 OFF	
	RS485 Mode	Bit 2,4,5 ON Bit 1,3,6,7,8,9,10 OFF	
	RS422 Mode	Bit 1,2,4,5 ON Bit 3,6,7,8,9,10 OFF	
COM2	RS232 Mode	Bit 6 ON Bit 1,2,3,4,5,7,8,9,10 OFF	
	RS485 Mode	Bit 7,9,10 ON Bit 1,2,3,4,5,7,8 OFF	
	RS422 Mode	Bit 6,7,9,10 ON Bit 1,2,3,4,5,8 OFF	

A.7.2 COM Port RS422/485 Termination Resistor Setting

Table A.11: COM Port RS422/485 Termination Resistor Setting

SW1//SW8	Termination Resistor Setting	
Description	This switch is used to select Termination Resistor (120 ohm) for long distance transmission or device matching.	
Default	Bit3 off & Bit8 off	
COM1	Bit3 on	
COM2	Bit8 on	


A.8 Internal Switch

A.8.1 AT/ATX Setting(SW4)

SW4 can be used for AT/ATX setting. The default setting is AT mode. See the following table for switching configuration

Table A.12: AT/ATX Setting (SW4)

Description	Instruction
AT mode (default)	PIN1-PIN2
ATX mode	PIN2-PIN3



A.8.2 Clear CMOS Setting (SW3)




Table A.13: Clear CMOS Function (SW3)

(2-3)	Enable (Clear CMOS)
(1-2)	Disable (Default)

A.9 Board to Board Connector (Reserved for Expansion) (BTB1)

Table A.14: Expansion Board to Board Connector Pin Assignments

Pin	Signal Name	Pin	Signal Name
1	ESPI_CLK	2	ESPI_ALERT0#
3	ESPI_IO0	4	ESPI_IO1
5	ESPI_IO2	6	ESPI_IO3
7	ESPI_CS0#	8	ESPI_RST0#
9	PMC_SUSCLK	10	PMC_SLP_S3#
11	GP_H00	12	PCIE_WAKE#
13	PLTRST_M.2#	14	M2B1_CLKREQ2#
15	GND	16	USB2_P0+
17	USB2_P0-	18	GND
19	USB2_P4+	20	USB2_P4-
21	CLK100M_M2E1_D2+	22	CLK100M_M2E1_D2-
23	GND	24	PCIE4_TX+
25	PCIE4_TX-	26	GND
27	PCIE4_RX+	28	PCIE4_RX-
29	GND	30	SATA1_TX+
31	SATA1_TX-	32	GND
33	SATA1_RX+	34	SATA1_RX-
35	GND	36	USB31_P2_TX+
37	USB31_P2_TX-	38	GND
39	USB31_P2_RX+	40	USB31_P2_RX-

A.10 BIOS Operation

A.10.1 Introduction

With the AMI BIOS Setup Utility, you can modify BIOS settings and control the specific features of your computer. The Setup Utility uses a number of menus for making changes and turning the specific features on or off. This chapter describes the basic navigation of the UNO-2271G V3 setup screens.

AMI's BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This information is stored in the NVRAM area so it retains the setup information when the power is turned off.

A.10.2 Entering BIOS Setup

Press to enter AMI BIOS Setup Utility, the Main Menu will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.

When users first enter the BIOS Setup Utility, they enter the Main setup screen. Users can always return to the Main setup screen by selecting the Main tab. There are two Main Setup options described in this section. The Main BIOS Setup screen is shown below.

Press to enter AMI BIOS Setup Utility, the Main Menu will appear on the screen. Use arrow keys to select among the items and press <Enter> to accept or enter the sub-menu.



Figure A.1 Main Setup Screen

The Main BIOS setup screen has two main frames. The left frame displays all the options that can be configured. Grayed-out options cannot be configured; options in blue can be. The right frame displays the key legend.

The key legend above is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often a text message will accompany it.

■ **System time/System date**

End user can use System time/System date options to change the system time and date. Highlight System Time or System Date using the keys. Enter new values through the keyboard, press the key or the keys to move between fields. The date must be entered in MM/DD/YY format. The time must be entered in HH:MM:SS format

A.10.3 Advanced BIOS Features

Setup Select the Advanced tab from the UNO-2271G V3 setup screen to enter the Advanced BIOS setup screen. You can select any of the items in the left frame of the screen, such as CPU configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screens are shown below. The sub menus are described on the following pages.




Figure A.2 Advanced BIOS Features Setup Screen

A.10.3.1 CPU Configuration




Figure A.3 CPU Configuration

A.10.3.2 Power & Performance



Figure A.4 Power & Performance



Figure A.5 CPU – Boot Performance Mode

CPU Power Management Control:

- **Boot performance mode**
Select the performance state that the BIOS will set starting from reset vector.
- **Intel® SpeedStep(tm)**
Allows more than two frequency ranges to be supported
- **Turbo mode**
- **C states**
Enable/Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.

A.10.3.3PCH-FW Configuration




Figure A.6 PCH-FW Configuration

A.10.3.4 TPM Device Selection



Figure A.7 TPM Device Selection

- **Select TPM Device (fTPM or dTPM)**
fTPM – Enables fTPM. dTPM – Disables fTPM and enables dTPM.
- **Warning:** fTPM/dTPM will be disabled, and all data saved on it will be lost.

A.10.3.5ACPI Settings



Figure A.8 ACPI Settings

A.10.3.6NCT6126D Super IO Configuration






Figure A.9 NCT61260 Super IO Configuration

- **Serial Port 1 Configuration**
Set Parameters of Serial Port 1.

**Figure A.10 Serial Port 1 Configuration**

- **Serial Port 2 Configuration**
Set Parameters of Serial Port 2.

**Figure A.11 Serial Port 2 Configuration**

A.10.3.7 S5 RTC Wake Settings




Figure A.12 S5 RTC Wake Settings

- **Wake System from S5**
Enable or disable System wake on alarm event. Select FixedTime, system will wake on the hr:min:sec specified. Select DynamicTime, System will wake on current time + Increase minute(s).

A.10.3.8 USB Configuration




Figure A.13 USB Configuration

- **XHCI Hand-Off**
This is a workaround for OS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
- **USB Mass Storage Driver Support**
Enable/ Disable USB Mass Storage Driver Support.
- **USB Hardware Delays and Time-Outs**
USB transfer time-out: The time-out value for Control, Bulk, and Interrupt transfers. Device reset time-out: USB mass storage device Start Unit command time-out. Device power-up delay: Maximum time the device will take before it properly reports itself to the Host Controller. "Auto" uses default value: for a Root port it is 100ms, for a Hub port the delay is taken from hub descriptor.
- **Mass Storage Devices: USB**
Mass storage device emulation type. "AUTO" enumerates devices according to their media format. Optical drives are emulated as "CDROM", drives with no media will be emulated according to a drive type.

A.10.3.9Network Stack Settings



Figure A.14 Network Stack Configuration

- **Network Stack**
Enable/Disable UEFI Network Stack.

A.10.4Chipset



Figure A.15 Chipset

A.10.4.1 System Agent(SA) Configuration

■ System Agent (SA) Configuration



Figure A.16 System Agent (SA) Configuration




Figure A.17 Memory Configuration

A.10.4.2 PCH-IO Configuration




Figure A.18 PCH-IO Configuration

- **PCI Express Configuration**
 - M.2 E-key/LAN 3: for 2nd stack extension kit
 - LAN 1: for Base Unit
 - LAN 2: for Base Unit
 - BTB2: for reserved
 - M.2 B-key: for Base Unit



Figure A.19 M.2 E-key/LAN 3




Figure A.20 LAN 1



Figure A.21 LAN 2




Figure A.22 M.2 B-key



Figure A.23 BTB2

A.10.4.3 SATA Configuration

■ SATA Configuration

SATA Controller(s): Enable/Disable SATA Device.

SATA Mode Selection: Determines how SATA controller (s) operate. Aggressive

LPM Support: Enable PCH to aggressively enter link power state.



Figure A.24 SATA Configuration

A.10.5 Security




Figure A.25 Security

- **Secure Boot**
Secure Boot feature is Active if Secure Boot is Enabled. Platform Key (PK)s enrolled and the System is in User mode. The mode change requires platform reset.
- **Secure Boot Mode**
Secure Boot mode options: Standard or Custom. In Custom mode, Secure Boot Policy Variables can be configured by a physically present user without full authentication.
 - Restore Factory Keys: Force System to User Mode. Install factory default Secure Boot key databases.
 - Key Management: Enables expert users to modify Secure Boot Policy variables without full authentication

A.10.6 Boot Options



Figure A.26 Boot Options

A.10.7 Save and Exit



Figure A.27 Save and Exit

www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, such as electronically, by photocopying, recording, or otherwise, without prior written permission from the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2025