

MI997AF

**Intel® 12th Gen Core™ i7/i5/i3 /
Celeron Mini-ITX Motherboard**

User's Manual

Version 1.0A
(May 2024)

Copyright

© 2024 IBASE Technology, Inc. All rights reserved.

No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of IBASE Technology, Inc. (hereinafter referred to as "IBASE").

Disclaimer

IBASE reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, IBASE does not guarantee this document is error-free.

IBASE assumes no liability for incidental or consequential damages arising from misapplication or inability to use the product or the information contained herein, nor for any infringements of rights of third parties, which may result from its use.

Trademarks

All the trademarks, registrations and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Compliance



This product has passed CE tests for environmental specifications and limits. This product is in accordance with the directives of the European Union (EU). In a domestic environment, this product may cause radio interference in which case users may be required to take adequate measures.



This product has been tested and found to comply with the limits for a Class B device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications.

WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive of for waste electrical and electronic equipment (WEEE - 2012/19/EU). Instead, it should be disposed of by returning it to a municipal recycling collection point. Check local regulations for disposal of electronic products.

Green IBASE



This product is compliant with the current RoHS restrictions and prohibits use of the following substances in concentrations exceeding 0.1% by weight (1000 ppm) except for cadmium, limited to 0.01% by weight (100 ppm).

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent chromium (Cr6+)
- Polybrominated biphenyls (PBB)
- Polybrominated diphenyl ether (PBDE)

Important Safety Information

Carefully read the precautions before using the board.

Environmental conditions:

- Use this product in environments with ambient temperatures between 0°C and 60°C.
- Do not leave this product in an environment where the storage temperature may be below -20° C or above 80° C. To prevent from damages, the product must be used in a controlled environment.

Care for your IBASE products:

- Before cleaning the PCB, unplug all cables and remove the battery.
- Clean the PCB with a circuit board cleaner or degreaser, or use cotton swabs and alcohol.
- Vacuum the dust with a computer vacuum cleaner to prevent the fan from being clogged.



WARNING

Attention during use:

- Do not use this product near water.
- Do not spill water or any other liquids on this product.
- Do not place heavy objects on the top of this product.

Anti-static precautions

- Wear an anti-static wrist strap to avoid electrostatic discharge.
- Place the PCB on an anti-static kit or mat.
- Hold the edges of PCB when handling.
- Touch the edges of non-metallic components of the product instead of the surface of the PCB.
- Ground yourself by touching a grounded conductor or a grounded bit of metal frequently to discharge any static.



CAUTION

Danger of explosion if the internal lithium-ion battery is replaced by an incorrect type. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions or recycle them at a local recycling facility or battery collection point.

Warranty Policy

- **IBASE standard products:**

24-month (2-year) warranty from the date of shipment. If the date of shipment cannot be ascertained, the product serial numbers can be used to determine the approximate shipping date.

- **3rd-party parts:**

12-month (1-year) warranty from delivery for the 3rd-party parts that are not manufactured by IBASE, such as CPU, CPU cooler, memory, storage devices, power adapter, panel and touchscreen.

- * PRODUCTS, HOWEVER, THAT FAIL DUE TO MISUSE, ACCIDENT, IMPROPER INSTALLATION OR UNAUTHORIZED REPAIR SHALL BE TREATED AS OUT OF WARRANTY AND CUSTOMERS SHALL BE BILLED FOR REPAIR AND SHIPPING CHARGES.

Technical Support & Services

1. Visit the IBASE website at www.ibase.com.tw to find the latest information about the product.
2. If you need any further assistance from your distributor or sales representative, prepare the following information of your product and elaborate upon the problem.
 - Product model name
 - Product serial number
 - Detailed description of the problem
 - The error messages in text or in screenshots if there is any
 - The arrangement of the peripherals
 - Software in use (such as OS and application software, including the version numbers)
3. If repair service is required, please log in to the RMA system of the website or contact your distributor or sales representative for assistance.

Table of Contents

Chapter 1	General Information	1
1.1	Introduction	2
1.2	Features	2
1.3	Packing List	3
1.4	Optional Accessories	3
1.5	Specifications	4
1.6	Block Diagram	6
1.7	Product View	7
1.8	Board Dimensions	10
Chapter 2	Hardware Configuration	11
2.1	Essential Installations Before You Begin	12
2.1.1	Installing the Memory	12
2.2	Setting the Jumpers	13
2.3	Jumper & Connector Locations	14
2.4	Jumpers Quick Reference	16
2.4.1	Clear CMOS Contents (JP1)	16
2.4.2	Clear ME Contents (JP2)	17
2.4.3	ATX & AT Power Mode Selection (JP3)	17
2.4.4	LVDS Panel Power Selection (JP4)	18
2.4.5	LVDS Power Brightness Selection (JP5)	18
2.4.6	Sierra EM9191 5G Card USB/PCIe Select (JP6)	19
2.4.7	Flash Descriptor Security Override (J10)	20
2.4.8	PWM Programming (J11)	21
2.5	Connectors Quick Reference	22
2.5.1	COM1 & COM2 RS-232/422/485 Ports (CN1)	23
2.5.2	DisplayPort & HDMI Port (CN2)	24
2.5.3	USB 3.2 Connector (CN3)	24
2.5.4	DisplayPort (CN4)	25
2.5.5	2.5 Gigabit LAN (Intel I226-LM) + USB3.2 (CN5)	25
2.5.6	2.5 Gigabit LAN (Intel I226-V) + USB3.2 (CN6)	26
2.5.7	HD Audio Connector (CN7)	26
2.5.8	Front Panel Settings Connector (J2)	27
2.5.9	COM3 (J1) & COM4 (J3) RS-232 Ports	28
2.5.10	DDR5 SO-DIMM Slot (J4 / J7)	29
2.5.11	SPI Flash Connector (J5)	29

2.5.12	80 Port Debug (J6)	30
2.5.13	Digital I/O Connector (J8)	30
2.5.14	M.2 M2280 Slot (J9, J22)	31
2.5.15	M.2 E2230 Slot (J12)	32
2.5.16	USB 2.0 Connector (J13)	32
2.5.17	SIM Slot (J14)	33
2.5.18	M.2 B-key 3052 Slot (J15)	33
2.5.19	LVDS Connectors (J17, J16) (Channel A, Channel B)	34
2.5.20	LCD Backlight Connector (J18)	35
2.5.21	SATA Power Connector (J19)	35
2.5.22	Audio Pin Header for Chassis Front Panel (J20)	36
2.5.23	DC-In Power Connector (J21)	37
2.5.24	Factory use only (J23)	37
2.5.25	SATA III Connector (SATA1, SATA2)	38
2.5.26	Fan Power Connectors (CPU_FAN1, SYS_FAN1)	38
2.5.27	PCIe (x1) Slot (PCIE1)	39
Chapter 3	Drivers Installation	41
3.1	Introduction	42
3.2	Intel® Chipset Software Installation Utility	42
3.3	VGA Driver Installation	44
3.4	Realtek HD Audio Driver Installation	46
3.5	LAN Drivers Installation	48
3.6	Intel® ME Drivers Installation	50
3.7	Intel® Serial IO Drivers Installation	51
3.8	Intel® Thunderbolt Drivers Installation	52
Chapter 4	BIOS Setup	53
4.1	Introduction	54
4.2	BIOS Setup	54
4.3	Main Settings	55
4.4	Advanced Settings	55
4.5	Chipset Settings	70
4.6	Security Settings	73
4.7	Boot Settings	75
4.8	Save & Exit Settings	76
4.9	MEBx	77

Appendix 79

- A. I/O Port Address Map 80
- B. Interrupt Request Lines (IRQ) 82
- C. Watchdog Timer Configuration 83
- D. Onboard Connector Types 87
- E. MI997AFUSB Power Control Bit Mapping..... 88

This page is intentionally left blank.

Chapter 1

General Information

The information provided in this chapter includes:

- Features
- Packing List
- Optional Accessories
- Specifications
- Block Diagram
- Product View
- Board Dimensions

1.1 Introduction

The MI997AF Mini ITX motherboard is based on 12th Gen Intel® Core i7/i5/i3™ / Celeron processors. With support for two DDR5 slots accommodating up to 64GB memory, it supports independent displays with HDMI (2.0a), LVDS and 2x DisplayPort(1.4a) (DP++) interface. This high-performance platform meets demands in next-generation applications in imaging, AI, and edge computing. Connectivity and expansion are provided by 2x Intel 2.5G LAN, 6x USB 3.x, 4x COM, 2x SATA III, 1x PCI-E (x1) [Gen.3.0]; 4x M.2 (B-key, E-key and 2x M-Key) .



1.2 Features

- 12th Gen Intel® Core i7/i5/i3 and Celeron® Processors
- 2x DDR5 SO-DIMM sockets, Max. 64GB
- Intel® processor integrated graphics supports HDMI (2.0a), LVDS and 2x DisplayPort (1.4a) (DP++)
- Dual Intel® 2.5G LAN
- 6x USB 3.x, 2x USB 2.0, 4x COM, 2x SATA III
- 1x PCI-E (x1) [Gen.3.0]; 4x M.2 (B-key, E-key and 2x M-Key)
- Watchdog timer, Digital I/O, iAMT(16.0) , fTPM
- 12V~24V DC input

1.3 Packing List

Your MI997AF package should include the items listed below. If any of the items below is missing, contact the distributor or dealer from whom you purchased the product.

- MI997 x 1
- IO Shield x 1
- SATA cable x 1
- COM cable x 1
- USB 2.0 cable x 1

1.4 Optional Accessories

- Audio Cable
- Cooler
- 330W Power Adaptor
(This is suitable for 45W TDP and 15W TDP CPU skus)
- 150W Power Adaptor (This is recommended to pair with 15W TDP CPU skus only)
- Power Cable


1.5 Specifications

Model	
MI997AF	LGA1700 Mini-ITX Motherboard w /HDMI, LVDS, 2x DisplayPort, Dual 2.5GbE, 2 x SATA, iAMT (16.0), fTPM
Specifications	
CPU Socket	LGA1700
CPU	12th Gen Intel® Core™ i7/i5/i3 / Celeron® CPU
Memory	2x DDR5 SO-DIMM sockets Supports DDR5-4800 module, Max. 64GB
BIOS	AMI
Watchdog Timer	256 levels
Hardware Monitor	Yes
Storage Interface	SATA III & NVMe
Expansion Slots	1x PCI-E (x1) [Gen.3.0]
Mini Type Slots	• 2x M.2 (M-key, type:2280, PCI-E(4x) Gen.4) • 1x M.2 (E-Key, type:2230, USB 2.0 + PCI-E(1x)) • 1x M.2 (B-Key, type:3052, USB 3.2 + PCI-E(1x))
Graphics	12th Gen Intel Core i7/i5/i3 / Celeron processor integrated
Video Output	1x HDMI (2.0a) + 2x DisplayPort (1.4a) (DP++) + LVDS
Ethernet	• LAN 1: Intel® I226LM, supports 2.5G and iAMT • LAN 2: Intel® I226V, supports 2.5G only
I/O Chipset	Fintek F81964D-I
Serial Port	4x COM ports : 2x RS232/422/485 + 2x RS232
USB 2.0	2x USB 2.0 via pin header
USB 3.X	6x USB 3.2 @ edge connector
Serial ATA	2x SATA III
Audio	Built-in HDA controller+Realtek ALC888S (7.1 ch.)
TPM	Supports fTPM
Others	12V~24V DC-in, Digital I/O (4-in/4-out), SIM socket

Physical	
Dimensions (L x W)	170mm x 170mm (6.7"x 6.7")
Environmental	
Operating Temperature	0 ~ 60 °C (32 ~ 140 °F)
Storage Temperature	-20 ~ 80 °C (-4 ~ 176 °F)


All specifications are subject to change without prior notice.


1.6 Block Diagram



1.7 Product View

Top View






Rear View



No.	Function
1. CN1	COM1 & COM2 RS-232/422/485 Ports
2. CN2	DisplayPort & HDMI Port
3. CN4	DisplayPort
4. CN3	USB 3.2 Connector
5. CN5	2.5 Gigabit LAN (Intel I226-LM) + USB 3.2
6. CN6	2.5 Gigabit LAN (Intel I226-V) + USB 3.2
7. CN7	HD Audio Connector

1.8 Board Dimensions



Chapter 2

Hardware Configuration

This section provides information on jumper settings and connectors on the MI997AF and other installation information in order to set up a workable system. The topics covered are:

- Essential installations
- Jumper and connector locations
- Jumper settings and information of connectors


2.1 Essential Installations

Follow the instructions below to install the memory modules.


2.1.1 Installing the Memory

To install the modules, locate the memory slot on the board and perform the following steps:

1. Align the key of the memory module with that on the memory slot and insert the module slantwise.



2. Gently push the module in an upright position until the clips of the slot close to hold the module in place when the module touches the bottom of the slot.




To remove the module, press the ejector tabs at both ends outwards.

2.2 Setting the Jumpers


Set up and configure your MI997AFby using jumpers for various settings and features according to your needs and applications. Contact your supplier if you have doubts about the best configuration for your use.

2.2.1 How to Set Jumpers

Jumpers are short-length conductors consisting of several metal pins with a non-conductive base mounted on the circuit board. Jumper caps are used to have the functions and features enabled or disabled. If a jumper has 3 pins, you can connect either PIN1 to PIN2 or PIN2 to PIN3 by shorting.









A 3-pin jumper



A jumper cap


Refer to the illustration below to set jumpers.


Pin closed	Oblique view	Illustration
Open		 1 2 3
1-2		 1 2 3
2-3		 1 2 3

When two pins of a jumper are encased in a jumper cap, this jumper is **closed**, i.e., turned **On**.

When a jumper cap is removed from two jumper pins, this jumper is **open**, i.e., turned **Off**.

2.3 Jumper & Connector Locations






2.4 Jumpers Quick Reference


Jumper	Function
JP1	Clear CMOS
JP2	Clear ME
JP3	AT/ATX Select
JP4	LVDS Panel Power Selection
JP5	LVDS Power Brightness Selection
JP6	Sierra EM919x 5G card USB/PCIe Select
J10	Flash Descriptor Security Override
J11	PWM Programming

2.4.1 Clear CMOS Contents (JP1)




Function	Pin closed	Illustration
Normal	1-2	1
Clear CMOS	2-3	1

2.4.2 Clear ME Contents (JP2)




Function	Pin closed	Illustration
Normal	1-2	1
Clear ME	2-3	1

2.4.3 ATX & AT Power Mode Selection (JP3)




Function	Pin closed	Illustration
ATX (default)	1-2	1
AT	2-3	1

2.4.4 LVDS Panel Power Selection (JP4)




Function	Pin closed	Illustration
3.3V (default)	1-2	1
5V	2-3	1

2.4.5 LVDS Power Brightness Selection (JP5)




Function	Pin closed	Illustration
3.3V (default)	1-2	1
5V	2-3	1

2.4.6 Sierra EM9191 5G Card USB/PCIe Select (JP6)



Function	Pin closed	Illustration
USB	1-2	1
PCIe (default)	2-3	1


2.4.7 Flash Descriptor Security Override (J10)



Flash Descriptor Security Override	Pin	Illustration
Disabled (default)	Open	 1
Enabled	Close	 1

Note: J10 is for factory use only.

2.4.8 PWM Programming (J11)




Note: J11 is for factory use only.

2.5 Connectors Quick Reference

Connector	Function
CN1	COM1 & COM2 RS-232/422/485 Ports
CN2	DisplayPort & HDMI Port
CN3	USB 3.2 Connector
CN4	DisplayPort
CN5	2.5 Gigabit LAN (Intel I226-LM) + USB 3.2
CN6	2.5 Gigabit LAN (Intel I226-V) + USB 3.2
CN7	HD Audio Connector
J1, J3	COM3 & COM4 RS-232 Ports
J2	Front Panel Settings Connector
J4, J7	DDR5 SO-DIMM Slots
J5	SPI Flash Connector (Factory use only)
J6	80 Port Debug (Factory use only)
J8	Digital I/O Connector
J9, J22	M.2 M2280 Slots
J15	M.2 B-key 3052 Slot
J12	M.2 E2230 Slot
J13	USB 2.0 Connector (DF11-8S-PA66H)
J14	SIM Slot
J17, J16	LVDS Connectors (Channel A, Channel B)
J18	LCD Backlight Connector
J19	SATA Power Connector
J20	Audio Pin Header for Chassis Front Panel
J21	DC-In Power Connector
J23	Factory use only
SATA1, SATA2	SATA III Connectors
CPU_FAN1, SYS_FAN1	Fan Power Connectors
PCIE1	PCIe (x1) Slot

2.5.1 COM1 & COM2 RS-232/422/485 Ports (CN1)




Pin	Signal Name	Pin	Signal Name
1	DCD, Data carrier detect	6	DSR, Data set ready
2	RXD, Receive data	7	RTS, Request to send
3	TXD, Transmit data	8	CTS, Clear to send
4	DTR, Data terminal ready	9	RI, Ring indicator
5	Ground		


COM1/COM2 RS-232/422/485 are jumperless, configurable in BIOS.

Pin	Signal Name		
	RS-232	RS-422	RS-485
1	DCD	TX-	DATA-
2	RX	TX+	DATA+
3	TX	RX+	NC
4	DTR	RX-	NC
5	Ground	Ground	Ground
6	DSR	NC	NC
7	RTS	NC	NC
8	CTS	NC	NC
9	RI	NC	NC


2.5.2 DisplayPort & HDMI Port (CN2)




2.5.3 USB 3.2 Connector (CN3)




2.5.4 DisplayPort (CN4)




2.5.5 2.5 Gigabit LAN (Intel I226-LM) + USB3.2 (CN5)




2.5.6 2.5 Gigabit LAN (Intel I226-V) + USB3.2 (CN6)



2.5.7 HD Audio Connector (CN7)



2.5.8 Front Panel Settings Connector (J2)



Pin	Signal	Pin	Signal
1	Power BTN-	2	Power BTN+
3	HDD LED+	4	HDD LED-
5	Reset BTN-	6	Reset BTN+
7	Power LED+	8	Power LED-

J2 is utilized for system indicators to provide light indication of the computer activities and switches to change the computer status. It provides interfaces for the following functions:

ATX Power ON Switch (Pins 1 and 2)

The 2 pins make an “ATX Power Supply On/Off Switch” for the system that connects to the power switch on the case. When pressed, the power switch will force the system to power on. When pressed again, it will power off the system.

Hard Disk Drive LED Connector (Pins 3 and 4)

This connector connects to the hard drive activity LED on control panel. This LED will flash when the HDD is being accessed.


Reset Switch (Pins 5 and 6)

The reset switch allows you to reset the system without turning the main power switch off and then on again. Orientation is not required when making a connection to this header.

Power LED (Pins 7 and 8)


This connector connects to the system power LED on control panel. This LED will light when the system turns on.

2.5.9 COM3 (J1) & COM4 (J3) RS-232 Ports




Pin	Signal Name	Pin	Signal Name
1	DCD, Data carrier detect	2	RXD, Receive data
3	TXD, Transmit data	4	DTR, Data terminal ready
5	Ground	6	DSR, Data set ready
7	RTS, Request to send	8	CTS, Clear to send
9	RI, Ring indicator	10	Not Used

2.5.10 DDR5 SO-DIMM Slot (J4 / J7)




2.5.11 SPI Flash Connector (J5)




Note: J5 is for factory use only.

2.5.12 80 Port Debug (J6)




Note: J6 is for factory use only.

2.5.13 Digital I/O Connector (J8)




Pin	Signal	Pin	Signal
1	Ground	2	+5V(0.5A)
3	OUT3	4	OUT1
5	OUT2	6	OUT0
7	IN3	8	IN1
9	IN2	10	IN0

2.5.14 M.2 M2280 Slot (J9, J22)




*J9/J22 supports NVME

2.5.15 M.2 E2230 Slot (J12)



*J12 supports USB2.0 & PCIE x1


2.5.16 USB 2.0 Connector (J13)




* Connector type: DF11-8S-PA66H

Pin	Signal	Pin	Signal
1	VCC(0.5A)	2	Ground
3	D0-	4	D1+
5	D0+	6	D1-
7	Ground	8	VCC(0.5A)

2.5.17 SIM Slot (J14)




2.5.18 M.2 B-key 3052 Slot (J15)




*J15 supports Sierra EM9191 5G modules.

2.5.19 LVDS Connectors (J17, J16) (Channel A, Channel B)




Pin	Signal	Pin	Signal
1	TX0+	2	TX0-
3	Ground	4	Ground
5	TX1+	6	TX1-
7	Ground	8	Ground
9	TX2+	10	TX2-
11	Ground	12	Ground
13	TXC+	14	TXC-
15	Ground	16	Ground
17	TX3+	18	TX3-
19	+3.3 / +5V	20	+3.3 / +5V

2.5.20 LCD Backlight Connector (J18)




Pin	Signal Name	Pin	Signal Name
1	+12V	3	Brightness Control
2	Backlight Enable	4	Ground

2.5.21 SATA Power Connector (J19)




Pin	Signal Name	Pin	Signal Name
1	+5V	3	Ground
2	Ground	4	+12V

2.5.22 Audio Pin Header for Chassis Front Panel (J20)




Pin	Signal Name	Pin	Signal Name
1	MIC IN_L	2	Ground
3	MIC IN_R	4	DET
5	LINE_R	6	Sense Ground
7	Sense	8	KEY
9	LINE_L	10	Sense Ground

2.5.23 DC-In Power Connector (J21)




Pin	Signal Name	Pin	Signal Name
1	Ground	2	Ground
3	+12 ~ +24V	4	+12 ~ +24V


2.5.24 Factory use only (J23)



2.5.25 SATA III Connector (SATA1, SATA2)




2.5.26 Fan Power Connectors (CPU_FAN1, SYS_FAN1)



Pin	Signal Name
1	Ground
2	+12V
3	Rotation detection
4	Control

2.5.27 PCIe (x1) Slot (PCIE1)



This page is intentionally left blank.

Chapter 3

Drivers Installation

This chapter introduces installation of the following drivers:

- Intel® Chipset Software Installation Utility
- VGA Driver
- HD Audio Driver
- LAN Drivers
- Intel® ME Drivers
- Intel® Serial I/O Drivers
- Intel® Thunderbolt Drivers Drivers

3.1 Introduction

This section describes the installation procedures for software and drivers. The contents of this section include the following:

Note: After installing your Windows operating system, you must install the Intel® Chipset Software Installation Utility first before proceeding with the drivers installation.

3.2 Intel® Chipset Software Installation Utility


The Intel® Chipset drivers should be installed first before the software drivers to install INF files for Plug & Play function for Intel chipset components. Follow the instructions below to complete the installation.

1. Go to the product's download page. Download the compressed drivers file to your computer. Double-click the file to decompress it. After decompression, double-click 'CDGuide' to access the main drivers page, as shown below. Click **Intel** on the left pane and then **Intel(R) AlderLake-P Chipset Drivers**, and **Intel(R) Chipset Software Installation Utility** on the right pane.





2. When the *Welcome* screen to the Intel® Chipset Device Software appears, click **Next**.
3. Accept the *License Agreement* and click **Accept**.
4. On the *Readme File Information* screen, click **Install**.



5. When installation has been completed, press **Finish** to complete the setup process.

3.3 VGA Driver Installation


1. Click **Intel** on the left pane and then **Intel(R) AlderLake-P Chipset Drivers**, and **Intel(R) HD Graphics Driver** on the right pane.



2. When the **Intel Graphics Driver Installer** screen appears, click **Begin installation**.



3. Click **I agree** to accept the INTEL SOFTWARE LICENSE AGREEMENT.
4. In the Pre-Install stage, "The installer will install the following components:
 - Intel® Graphics Driver
 - Intel® Graphics Command CenterClick **Start** to start installing the new graphics driver.
5. The next screen will indicate that the new graphics driver is being installed. When the message "**Installation complete!**" appears, restart your system in order to apply the driver changes.



3.4 Realtek HD Audio Driver Installation


- Before installing the audio drivers, run the batch file - **Intel_Sound.bat** in the directory shown in the picture below:

I-12_Gen-P-1.0\Intel\AlderLake-P\Sound\Windows 10_11

Right-click Intel_Sound.bat and **run the batch file as administrator**.

Drive (D:) > I-12_Gen-P-1.0 > Intel > AlderLake-P > Sound > Windows 10_11


Name	Date modified	Type	Size
IntcDMic.sys	4/20/2022 11:51 AM	System file	731 KB
intcoed	4/20/2022 11:51 AM	Security Catalog	138 KB
IntcOED	4/20/2022 11:37 AM	Setup Information	58 KB
IntcOED.sys	4/20/2022 11:51 AM	System file	1,146 KB
intcsdw	4/20/2022 11:51 AM	Security Catalog	43 KB
IntcSDW	4/20/2022 11:37 AM	Setup Information	156 KB
IntcSDW.sys	4/20/2022 11:51 AM	System file	901 KB
intcsdwbus	4/20/2022 11:51 AM	Security Catalog	40 KB
IntcSdwBus	4/20/2022 11:37 AM	Setup Information	24 KB
IntcSdwBus.sys	4/20/2022 11:51 AM	System file	498 KB
intcsst	4/20/2022 11:51 AM	Security Catalog	42 KB
IntcSST	4/20/2022 11:37 AM	Setup Information	147 KB
IntcSST.sys	4/20/2022 11:51 AM	System file	807 KB
intcusb	4/20/2022 11:51 AM	Security Catalog	43 KB
IntcUSB	4/20/2022 11:37 AM	Setup Information	121 KB
IntcUSB.sys	4/20/2022 11:51 AM	System file	870 KB
Intel_Sound	12/16/2022 5:41 AM	Windows Batch File	1 KB



2. After running the batch file, install the audio drivers. Click **Intel** on the left pane and then **Intel(R) AlderLake-P Chipset Drivers** on the right. Click **Intel** on the left pane and then **Intel(R) AlderLake-P Chipset Drivers**, and **Realtek High Definition Audio Driver** on the right pane.



3. On the *Welcome* screen of the InstallShield Wizard, click **Next** to install the drivers.




4. When the audio driver has been installed, click **Finish** to restart the computer.

3.5 LAN Drivers Installation


1. Click **Intel** on the left pane and then **Intel(R) AlderLake-P Chipset Drivers**, and **Intel PRO LAN Network Drivers** on the right pane.



2. Click **Intel Drivers and Software**.



3. When the *Welcome to the install wizard for Intel(R) Network Connection* screen appears, click **Next**. On the next screen, accept the terms in the License Agreement and click **Next**.
4. On the *Setup Options* screen, select the program features you want to be installed. Then click **Next** to continue.



5. On the *Ready to Install the Program* screen, click **Install** to begin the installation.
6. When the *Install wizard Completed* screen appears, click **Finish**.

3.6 Intel® ME Drivers Installation

1. Click **Intel** on the left pane and then **Intel(R) AlderLake-P Chipset Drivers**, and **Intel(R) ME Drivers** on the right pane.



2. When the *Welcome* screen to the **Intel® Management Engine Components** appears, click **Next**.

You are about to install the following product:

Intel® Management Engine Components 2242.3.34.0

3. Accept the terms in the License Agreement and click **Next**.
4. On the next screen, click **Next** to install to the default folder.
5. Click **Finish** when the necessary components have been successfully installed.

- Intel® Management Engine Interface
- Serial Over LAN
- Intel® Wireless Manageability Driver
- Local Management Service
- Intel® Dynamic Application Loader

3.7 Intel® Serial IO Drivers Installation

1. Click **Intel** on the left pane and then **Intel(R) AlderLake-P Chipset Drivers**, and **Intel(R) Serial IO Drivers** on the right pane.




2. When the *Welcome* screen to the Intel® Serial IO appears, click **Next**.


You are about to install the following product:

Intel® Serial IO 30.100.2148.1

3. Accept the terms in the license agreement and click **Next**.
4. On the **Readme File Information** and **Confirmation** screens, click **Next**.



5. Click **Finish** when the **Completion** screen appears.




3.8 Intel® Thunderbolt Drivers Installation

1. Click **Intel** on the left pane and then **Intel(R) AlderLake-P Chipset Drivers**, and **Intel(R) Thunderbolt Drivers** on the right pane.



2. Accept the terms in the license agreement and click **Install**.
3. When installation has been completed, click **Restart**.



- 1.

Chapter 4

BIOS Setup

This chapter describes the different settings available in the AMI BIOS that comes with the board. The topics covered in this chapter are as follows:

- Main Settings
- Advanced Settings
- Chipset Settings
- Security Settings
- Boot Settings
- Save & Exit

4.1 Introduction

The BIOS (Basic Input/Output System) installed in the ROM of your computer system supports Intel® processors. The BIOS provides critical low-level support for standard devices such as disk drives, serial ports and parallel ports. It also provides password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

4.2 BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Press the key immediately allows you to enter the Setup utility. If you are a little bit late pressing the key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup.

If you still need to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again.

The following message will appear on the screen:

```
Press <DEL> to Enter Setup
```

In general, press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help, and <Esc> to quit.

When you enter the BIOS Setup utility, the *Main Menu* screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

Warning: It is strongly recommended that you avoid making any changes to the chipset defaults.

These defaults have been carefully chosen by both AMI and your system manufacturer to provide the absolute maximum performance and reliability. Changing the defaults could make the system unstable and crash in some cases.


4.3 Main Settings



BIOS Setting	Description
System Language	Choose the system default language.
System Date	Sets the date. Use the <Tab> key to switch between the date elements.
System Time	Set the time. Use the <Tab> key to switch between the time elements.

4.4 Advanced Settings


This section allows you to configure, improve your system and allows you to set up some system features according to your preference.




4.4.1 CPU Configuration

Aptio Setup - AMI		
Advanced		
CPU Configuration		
ID	0xB0671	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.
Brand String	13th Gen Intel(R) Cor...	
VMX	Supported	
SMX/TXT	Supported	
Intel (VMX) Virtualization Technol	[Enabled]	
Active Performance-cores	[All]	
Active Efficient-cores	[All]	
Hyper-Threading	[Enabled]	
Legacy Game Compatibility Mode	[Disabled]	

BIOS Setting	Description
Intel (VMX) Virtualization Technology	When enable, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.
Active Performance-cores Active Efficient-cores	Number of P-cores to enable in each processor package. Note: Number of Cores and E-cores are looked at together. When both are (0,0), Pcode will enable all cores
Hyper-Threading	Enable or disable Hyper-Threading Technology.
Legacy Game Compatibility Mode	When enable, pressing the scroll lock key will toggle the Efficient-cores between being parked when Scroll Lock LED is on and un-parked when LED is off.



4.4.2 CPU Configuration



BIOS Setting	Description
Efficient-core Information	Displays the E-core Information
Performance-core Information	Displays the P-core Information
Intel (VMX) Virtualization Technology	When enable, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.
Active Performance-cores Active Efficient-cores	Number of P-cores to enable in each processor package. Note: Number of Cores and E-cores are looked at together. When both are (0,0), Pcode will enable all cores
Hyper-Threading	Enable or disable Hyper-Threading Technology.
AES	Enable/Disable AES (Advanced Encryption Standard)

4.4.3 Power & Performance

Advanced	
CPU - Power Management Control	Configurable Processor Base Power (cTDP) Configurations
Intel(R) SpeedStep(tm) [Enabled]	
Intel(R) Speed Shift Technology [Enabled]	
► Config TDP configurations	

Advanced	
Config TDP Configurations	Configurable Processor Base Power (cTDP) Mode as
Configurable TDP Boot Mode [Nominal]	Nominal/Level/Leve2/Deactivate
Power Limit 1 15.0W (MSR 15.0)	TDP selection. Deactivate
Power Limit 2 55.0W (MSR 55.0)	option will set MSR to Nominal and MMIO to Zero.

BIOS Setting	Description
Intel(R) SpeedStep(tm)	Allows more than two frequency ranges to be supported.
Intel(R) Speed Shift Technology	Enable/Disable Intel(R) Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.
Config TDP Configuration	Configurable Processor Base Power (cTDP) Configurations
Configurable TDP Boot Mode	Configurable Processor Base Power (cTDP) Mode as Nominal/ Level/ Leve2 / Deactivate TDP selection. Deactivate option will set MSR to Nominal and MMIO to Zero.

4.4.4 PCH-FW Configuration




4.4.5 Trusted Computing

Advanced		
TPM 2.0 Device Found	600.10	Enables or Disables BIOS support for security device. OS will not show Security Device. TCG EFI protocol and INTIA interface will not be available.
Firmware Version:	INTC	
Vendor:		
Security Device Support	[Enable]	
Active PCR banks	SHA256	
Available PCR banks	SHA256,SHA384,SH3	
SHA256 PCR Bank	[Enabled]	
SHA384 PCR Bank	[Disabled]	
SH3_256 PCR Bank	[Disabled]	
Pending operation	[None]	
Platform Hierarchy	[Enabled]	
Storage Hierarchy	[Enabled]	
Endorsement Hierarchy	[Enabled]	
Physical Presence Spec Version	[1.3]	++: Select Screen F1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values
TPM 2.0 InterfaceType	[CRB]	
Device Select	[Auto]	


BIOS Setting	Description
Security Device Support	Enables / Disables BIOS support for security device. OS will not show security device. TCG EFI protocol and INTIA interface will not be available.
SHA256 / SHA384 / SH3_256 PCR Bank	Option: Enabled / Disabled
Pending operation	Schedule an operation for the security device. Note: Your computer will reboot during restart in order to change state of security device.
Platform Hierarchy	Enables / Disables platform hierarchy.
Storage Hierarchy	Enables / Disables storage hierarchy.
Endorsement Hierarchy	Enables / Disables endorsement hierarchy.
Physical Presence Spec Version	Selects to show the PPI Spec Version (1.2 or 1.3) that the OS supports. Note: Some HCK tests might not support 1.3.
Device Select	TPM 1.2 will restrict support to TPM 1.2 devices only. TPM 2.0 will restrict support to TPM 2.0 devices only. Auto will support both with the default being set to TPM 2.0 devices if not found, and TPM 1.2 device will be enumerated.

4.4.6 ACPI Settings



BIOS Setting	Description
Enable Hibernation	Enables / Disables the system ability to hibernate (OS/S4 Sleep State). This option may be not effective with some OS.

4.4.7 LVDS Configuration



BIOS Setting	Description
LVDS Control	Enables / Disables LVDS.
Panel Color Depth	Options: 18 BIT, 24 BIT
LVDS Channel Type	Options: Single, Dual
Panel Type	Options: 800 x 480 / 800 x 600 / 1024 x 768 / 1280 x 768 / 1280 x 960 / 1280 x 1024 / 1366 x 768 / 1440 x 900 / 1600 x 900 / 1600 x 1200 / 1680 x 1050 / 1920 x 1080 / 1920 x 1200


Note: LVDS brightness control can only be controlled in Windows.

4.4.8 F81964 Super IO Configuration




BIOS Setting	Description
Serial Port Configuration	Sets parameters of Serial Ports. Enables / Disables the serial port and select an optimal setting for the Super IO device.

4.4.7.1. Serial Port 1 Configuration




BIOS Setting	Description
Serial Port Mode Select	Serial Port Loop Back/RS232/RS422/ RS485 mode select

4.4.7.2. Serial Port 2 Configuration




BIOS Setting	Description
Serial Port Mode Select	Serial Port Loop Back/RS232/RS422/ RS485 mode select


4.4.7.3. Serial Port 3 Configuration



4.4.7.4. Serial Port 4 Configuration




4.4.9 Hardware Monitor



BIOS Setting	Description
CPU Fan Smart Fan Control	Enables / Disables CPU smart fan control. Options: Disabled / 50 °C / 60 °C / 70 °C / 80 °C
System Smart Fan Control	Enables / Disables system smart fan control. Options: Disabled / 50 °C / 60 °C / 70 °C / 80 °C
Temperatures / Voltages	These fields are the parameters of the hardware monitoring function feature of the motherboard. The values are read-only values as monitored by the system and show the PC health status.

4.4.10 AMI Graphic Output Protocol Policy




4.4.11 USB Configuration



BIOS Setting	Description
Legacy USB Support	• Enabled enables Legacy USB support. • Auto disables legacy support if there is no USB device connected. • Disabled keeps USB devices available only for EFI applications.
XHCI Hand-off	This is a workaround for OSeS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.
USB Mass Storage Driver Support	Enables / Disables the support for USB mass storage driver.
USB Transfer time-out	The time-out value (1 / 5 10 / 20 secs) for Control, Bulk, and Interrupt transfers.
Device reset time-out	Gives seconds (10 / 20 / 30 / 40 secs) to delay execution of Start Unit command to USB mass storage device.
Device power-up delay	The maximum time the device will take before it properly reports itself to the Host Controller. Auto uses default value for a Root port it is 100ms. But for a Hub port, the delay is taken from Hub descriptor.

4.4.12 Network Stack Configuration




BIOS Setting	Description
Network Stack	Enables / Disables UEFI Network Stack.
IPv4 PXE Support	Enables / Disables IPv4 PXE Boot Support. If disabled, Ipv4 PXE boot option will not be created.
IPv4 HTTP Support	Enables / Disables IPv4 HTTP Boot Support. If disabled, Ipv4 HTTP boot option will not be created.
IPv6 PXE Support	Enables / Disables IPv6 PXE Boot Support. If disabled, Ipv4 PXE boot option will not be created.
IPv6 HTTP Support	Enables / Disables IPv6 HTTP Boot Support. If disabled, Ipv4 HTTP boot option will not be created.
PXE boot wait time	Assigns a period of time to press ESC key to abort the PXE boot.
Media detect count	Assigns a number of times to check the presence of media.

4.4.13 NVMe Configuration




4.5 Chipset Settings




BIOS Setting	Description
System Agent (SA) Configuration	System Agent (SA) parameters
PCH-IO Configuration	PCH parameters

4.5.1 System Agent (SA) Configuration




BIOS Setting	Description
Graphics Configuration	Configures the graphics settings.
VT-d	VT-d capability, Enabled/Disabled



4.5.1.1. Graphics Configuration



BIOS Setting	Description
Graphics Turbo IMON Current	Graphics turbo IMON current values supported (14-31)
GTT Size	Sets the GTT size as 2 MB, 4 MB, or 8 MB.
Aperture Size	Sets the aperture size. Note: Above 4 GB MMIO BIOS assignment is automatically enabled when selecting 2048 MB aperture. To use this feature, disable CSM support.
PSMI Support	PSM Enable/Disable
DVMT Pre-Allocated	Select MT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device




4.5.2 PCH-IO Configuration




BIOS Setting	Description
PCH-IO Configuration	PCH Parameters
SATA Configuration	SATA Devices Options Settings
USB Configuration	USB Configuration Settings

4.5.2.1. SATA Configuration:




BIOS Setting	Description
SATA Controller(s)	Enables / Disables the SATA device.
SATA Mode Selection	Determines how SATA controller(s) operate.
Serial ATA Ports	Enables / Disables SATA ports.
Hot Plug	Designates the port as Hot Pluggable.
J15 USB 3.0 Control	Enable/Disable this USB Physical Connector (physical port). Once disabled, any USB devices plugged into the connector will not be detected by BIOS or OS.
Power-On after Power failure	Specify what state to go to when power is re-applied after a power failure (S3 state)

4.6 Security Settings



BIOS Setting	Description
Administrator Password	Sets an administrator password for the setup utility.
User Password	Sets a user password.
Secure Boot	Configures Secure Boot.

4.6.1 Secure Boot




BIOS Setting	Description
Secure Boot	Secure Boot feature is Active if Secure Boot is enabled. Platform Key (PK) Is enrolled and the system is in User mode. The mode change requires platform reset.
Secure Boot Mode	Secure Boot mode options: Standard or Custom. In Custom mode, Secure Boot policy variables can be configured by a physically present user without full authentication.
Restore Factory Keys	Forces system to user mode. Install factory default Secure Boot key databases.
Key Management	Enables expert users to modify Secure Boot Policy variables without full authentication.

4.7 Boot Settings




BIOS Setting	Description
Setup Prompt Timeout	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
Bootup NumLock State	Selects the keyboard NumLock state.
Quiet Boot	Enables / Disables Quiet Boot option.
Boot Option Priorities	Sets the system boot order.

4.8 Save & Exit Settings



BIOS Setting	Description
Save Changes and Exit	Exits system setup after saving the changes.
Discard Changes and Exit	Exits system setup without saving any changes.
Save Changes and Reset	Resets the system after saving the changes.
Discard Changes and Reset	Resets system setup without saving any changes.
Save Changes	Saves changes done so far to any of the setup options.
Discard Changes	Discards changes done so far to any of the setup options.
Restore Defaults	Restores / Loads defaults values for all the setup options.
Save as User Defaults	Saves the changes done so far as User Defaults.
Restore User Defaults	Restores the user defaults to all the setup options.
Launch EFI Shell from filesystem device	Attempts to launch EFI Shell application (Shell.efi) from one of the available filesystem devices.

4.9 MEBx



This page is intentionally left blank.

Appendix

This section provides the mapping addresses of peripheral devices and the sample code of watchdog timer configuration.

A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. The following table lists the I/O port addresses used.

Address	Device Description
0x00000A00-0x00000A0F	Motherboard resources
0x00000A10-0x00000A1F	Motherboard resources
0x00000A10-0x00000A1F	Motherboard resources
0x0000002E-0x0000002F	Motherboard resources
0x0000004E-0x0000004F	Motherboard resources
0x00000061-0x00000061	Motherboard resources
0x00000063-0x00000063	Motherboard resources
0x00000065-0x00000065	Motherboard resources
0x00000067-0x00000067	Motherboard resources
0x00000070-0x00000070	Motherboard resources
0x00000080-0x00000080	Motherboard resources
0x00000092-0x00000092	Motherboard resources
0x000000B2-0x000000B3	Motherboard resources
0x00000068-0x00000069F	Motherboard resources
0x0000164E-0x0000164F	Motherboard resources
0x00000040-0x00000043	System timer
0x00000050-0x00000053	System timer
0x0000FFF8-0x0000FFFF	Intel(R) Active Management Technology - SOL (COM14)
0x000003F8-0x000003FF	Communications Port (COM1)
0x000002F8-0x000002FF	Communications Port (COM2)
0x000003E8-0x000003EF	Communications Port (COM3)
0x000002E8-0x000002EF	Communications Port (COM4)
0x00000000-0x00000CF7	PCI Express Root Complex
0x00000D00-0x0000FFFF	PCI Express Root Complex

Address	Device Description
0x00001854-0x00001857	Motherboard resources
0x00002000-0x000020FE	Motherboard resources
0x00003000-0x0000303F	Intel(R) Iris(R) Xe Graphics
0x00003090-0x00003097	Standard SATA AHCI Controller
0x00003080-0x00003083	Standard SATA AHCI Controller
0x00003060-0x0000307F	Standard SATA AHCI Controller
0x00000060-0x00000060	Standard PS/2 Keyboard
0x00000064-0x00000064	Standard PS/2 Keyboard
0x00000020-0x00000021	Programmable interrupt controller
0x00000024-0x00000025	Programmable interrupt controller
0x00000028-0x00000029	Programmable interrupt controller
0x0000002C-0x0000002D	Programmable interrupt controller
0x00000030-0x00000031	Programmable interrupt controller
0x00000034-0x00000035	Programmable interrupt controller
0x00000038-0x00000039	Programmable interrupt controller
0x0000003C-0x0000003D	Programmable interrupt controller
0x000000A0-0x000000A1	Programmable interrupt controller
0x000000A4-0x000000A5	Programmable interrupt controller
0x000000A8-0x000000A9	Programmable interrupt controller
0x000000AC-0x000000AD	Programmable interrupt controller
0x000000B0-0x000000B1	Programmable interrupt controller
0x000000B4-0x000000B5	Programmable interrupt controller
0x000000B8-0x000000B9	Programmable interrupt controller
0x000000BC-0x000000BD	Programmable interrupt controller
0x000000D0-0x000000D1	Programmable interrupt controller

B. Interrupt Request Lines (IRQ)

The following table shows the IRQ used by the devices on board.

Level	Function
IRQ 0	System timer
IRQ 1	Standard PS/2 Keyboard
IRQ 3	Communications Port (COM2)
IRQ 4	Communications Port (COM1)
IRQ 5	Communications Port (COM3)
IRQ 6	Communications Port (COM4)
IRQ 12	Microsoft PS/2 Mouse
IRQ 14	Intel(R) Serial IO GPIO Host Controller - INTC1055
IRQ 16	High Definition Audio Controller
IRQ 19	Intel(R) Active Management Technology - SOL (COM14)
IRQ 256~IRQ 511	Microsoft ACPI-Compliant System
IRQ 4294967266	Intel(R) Management Engine Interface #1
IRQ 4294967267	Intel(R) Iris(R) Xe Graphics
IRQ 4294967268~78	Intel(R) Ethernet Controller I226-V #4
IRQ 4294967279~89	Intel(R) Ethernet Controller I226-LM #2
IRQ 4294967290	Intel(R) USB 3.10 eXtensible Host Controller - 1.20 (Microsoft)
IRQ 4294967291	Intel(R) USB 3.20 eXtensible Host Controller - 1.20 (Microsoft)
IRQ 4294967292	Standard SATA AHCI Controller
IRQ 4294967293	PCI Express Root Port
IRQ 4294967294	PCI Express Root Port

C. Watchdog Timer Configuration

The Watchdog Timer (WDT) is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven.

Under normal circumstance, you will need to restart the WDT at regular intervals before the timer counts to zero.

Sample Code:

```
//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include <dos.h>
#include <conio.h>
#include <stdio.h>
#include <stdlib.h>
#include "F81964.H"
//-----
int main (int argc, char *argv[]);
void EnableWDT(int);
void DisableWDT(void);
//-----
int main (int argc, char *argv[])
{
    unsigned char bBuf;
    unsigned char bTime;
    char **endptr;

    char SIO;

    printf("Fintek 81964 watch dog program\n");
    SIO = Init_F81964();
    if (SIO == 0)
    {
        printf("Can not detect Fintek 81964, program abort.\n");
        return(1);
    }
    if (SIO == 0)

    if (argc != 2)
    {
        printf("Parameter incorrect!!\n");
        return (1);
    }
}
```

```

    bTime = strtol(argv[1], endptr, 10);
    printf("System will reset after %d seconds\n", bTime);

    if (bTime)
    {
        EnableWDT(bTime);
    }
    else
    {
        DisableWDT();
    }
    return 0;
}
//-----
void EnableWDT(int interval)
{
    unsigned char bBuf;

    bBuf = Get_F81964_Reg(0x2B);
    bBuf &= (~0x20);
    Set_F81964_Reg(0x2B, bBuf);           //Enable WDTO

    Set_F81964_LD(0x07);                  //switch to logic device 7
    Set_F81964_Reg(0x30, 0x01);          //enable timer

    bBuf = Get_F81964_Reg(0xF5);
    bBuf &= (~0x0F);
    bBuf |= 0x52;
    Set_F81964_Reg(0xF5, bBuf);           //count mode is second

    Set_F81964_Reg(0xF6, interval);       //set timer

    bBuf = Get_F81964_Reg(0xFA);
    bBuf |= 0x01;
    Set_F81964_Reg(0xFA, bBuf);           //enable WDTO output

    bBuf = Get_F81964_Reg(0xF5);
    bBuf |= 0x20;
    Set_F81964_Reg(0xF5, bBuf);           //start counting
}
//-----
void DisableWDT(void)
{
    unsigned char bBuf;

    Set_F81964_LD(0x07);                  //switch to logic device 7

    bBuf = Get_F81964_Reg(0xFA);
    bBuf &= ~0x01;
    Set_F81964_Reg(0xFA, bBuf);           //disable WDTO output

    bBuf = Get_F81964_Reg(0xF5);
    bBuf &= ~0x20;
    bBuf |= 0x40;
    Set_F81964_Reg(0xF5, bBuf);           //disable WDT
}
//-----
//

```

```

// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include "F81964.H"
#include <dos.h>
//-----
unsigned int F81964_BASE;
void Unlock_F81964 (void);
void Lock_F81964 (void);
//-----
unsigned int Init_F81964(void)
{
    unsigned int result;
    unsigned char ucDid;

    F81964_BASE = 0x4E;
    result = F81964_BASE;

    ucDid = Get_F81964_Reg(0x20);
    if (ucDid == 0x07)                //Fintek 81964
    {
        goto Init_Finish;
    }

    F81964_BASE = 0x2E;
    result = F81964_BASE;

    ucDid = Get_F81964_Reg(0x20);
    if (ucDid == 0x07)                //Fintek 81964
    {
        goto Init_Finish;
    }

    F81964_BASE = 0x00;
    result = F81964_BASE;

Init_Finish:
    return (result);
}
//-----
void Unlock_F81964 (void)
{
    outportb(F81964_INDEX_PORT, F81964_UNLOCK);
    outportb(F81964_INDEX_PORT, F81964_UNLOCK);
}
//-----
void Lock_F81964 (void)
{
    outportb(F81964_INDEX_PORT, F81964_LOCK);
}
//-----
void Set_F81964_LD( unsigned char LD)
{
    Unlock_F81964();
    outportb(F81964_INDEX_PORT, F81964_REG_LD);
    outportb(F81964_DATA_PORT, LD);
    Lock_F81964();
}

```

```
//-----
void Set_F81964_Reg( unsigned char REG, unsigned char DATA)
{
    Unlock_F81964();
    outportb(F81964_INDEX_PORT, REG);
    outportb(F81964_DATA_PORT, DATA);
    Lock_F81964();
}
//-----

unsigned char Get_F81964_Reg(unsigned char REG)
{
    unsigned char Result;
    Unlock_F81964();
    outportb(F81964_INDEX_PORT, REG);
    Result = inportb(F81964_DATA_PORT);
    Lock_F81964();
    return Result;
}
//-----

//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#ifndef F81964_H
#define F81964_H 1
//-----
#define F81964_INDEX_PORT (F81964_BASE)
#define F81964_DATA_PORT (F81964_BASE+1)
//-----
#define F81964_REG_LD 0x07
//-----
#define F81964_UNLOCK 0x87
#define F81964_LOCK 0xAA
//-----
unsigned int Init_F81964(void);
void Set_F81964_LD( unsigned char);
void Set_F81964_Reg( unsigned char,
unsigned char); unsigned char
Get_F81964_Reg( unsigned char);
//-----
#endif // F81964_H
```

D. Onboard Connector Types

Function	Connector	Onboard Type	Compatible Mating Type for Reference
DC-In Power Connector	J21	Hao Guo Xing Ye ATX4PT-NY46	Molex 39-01-2040
USB 2.0 Connector	J13	Hao Guo Xing Ye DF11-8S-PA66H	Hirose DF11-8DS-2C
SATA Power Connector	J19	Hao Guo Xing Ye WAFER25-104S-2442-ST	AMP 171822-4
Digital I/O Connector	J8	E-CALL E-CALL_0196-01-200-100	Dupont 10P 2.0 mm-pitch (female)
Front Panel Settings Connector	J2	E-CALL 0126-01-203-080	Dupont 8P 2.54 mm-pitch (female)
COM3 & COM4 RS-232 Port	J1, J3	Hao Guo Xing Ye DF11-10S-PA66H	HRS DF11-10DS-2C
Audio Connector	J20	E-CALL 0126-01-2821009	Dupont 10P 2.54 mm-pitch (female)
Fan Power Connectors	CPU_FAN1 SYS_FAN1	TechBest W2-03I104132S1WT(A)-L	Molex 47054-1000
LCD Backlight Connector	J18	E-CALL 0110-161-040	JST PHR-4
LVDS Connectors	J17, J16	Hirose DF20EG-20DP-1V	Hirose DF20A-20DS-1C

E. MI997AFUSB Power Control Bit Mapping.

Function	Connector	Software Mapping
M.2 –E Key	J12	bit_3
USB 3.2	CN6 (A)	bit_4